

Yale[®]

HOISTS


OPERATING & MAINTENANCE INSTRUCTIONS WITH PARTS LIST

Publication Part No. LEW-1-680-1

Published August 2005

LEW-1 Series Electric Wire Rope Hoists and Trolleys

**For LEW Models:
1 h.p. and under**



IMPORTANT - CAUTION

To safeguard against the possibility of personal injury or property damage, follow the recommendations and instructions of this manual. This manual contains important information for the correct installation, operation and maintenance of this equipment. All persons involved in the installation, operation and maintenance of this equipment should be thoroughly familiar with the contents of this manual. Keep this manual for reference and further use.

▲WARNING

To prevent personal injury, do not use the equipment shown in this manual to lift, support or otherwise transport people, or to suspend unattended loads over people.

Table of Contents

| | | |
|---------------------|---|-------------|
| SECTION I | INTRODUCTION | Page |
| Paragraph | 1-1 General | 2 |
| Paragraph | 1-2 Safety Standards | 2 |
| Paragraph | 1-3 Hoist Construction and Features | 2 |
| Paragraph | 1-4 Basic Hoist Data | 2 & 3 |
| Paragraph | 1-5 Application Information | 3 |
| Paragraph | 1-6 Warranty | 3 |
| SECTION II | INSTALLATION | |
| Paragraph | 2-1 Safety Notes | 3 |
| Paragraph | 2-2 Trolley Installation | 3 |
| Paragraph | 2-3 Power Supply Connection | 3 & 4 |
| Paragraph | 2-4 Vent Plug | 4 |
| Paragraph | 2-5 Wire Rope Lubrication | 4 |
| Paragraph | 2-6 Testing | 4 |
| SECTION III | OPERATION | |
| Paragraph | 3-1 General | 8 |
| Paragraph | 3-2 Safety Notes | 8 |
| Paragraph | 3-3 Handling The Load | 8 |
| Paragraph | 3-4 Overload Limiting Protection | 8 |
| SECTION IV | INSPECTION | |
| Paragraph | 4-1 General | 9 |
| Paragraph | 4-2 Frequent Inspection | 9 |
| Paragraph | 4-3 Periodic Inspection | 9 |
| Paragraph | 4-4 Load Brake Function Check | 11 |
| Paragraph | 4-5 Wire Rope Inspection | 12 |
| Paragraph | 5-6 Hook Throat Opening | 12 |
| SECTION V | MAINTENANCE AND REPORT | |
| Paragraph | 5-1 General | 13 |
| Paragraph | 5-2 Limit Switch Adjustment | 13 |
| Paragraph | 5-3 Motor Brake Adjustment | 13 |
| Paragraph | 5-4 Wire Rope Replacement | 14 |
| Paragraph | 5-5 Lubrication | 15 |
| SECTION VI | TROUBLESHOOTING | 17 & 18 |
| SECTION VII | WIRING | |
| Paragraph | 7-1 Voltage Conversion | 19 |
| Paragraph | 7-2 thru 7-9 Wiring Diagrams | 20 thru 27 |
| SECTION VIII | ILLUSTRATED PARTS LIST | |
| Paragraph | 8-1 General | 28 |
| Paragraph | 8-2 How To Use The Parts List | 28 |
| Paragraph | 8-3 How To Order Replacement Parts | 28 |

1-1. General Information

This manual provides information for the safe operation and maintenance of Yale LEW-1 Series Hoists. All persons operating or maintaining these hoists should be familiar with the information contained herein. Adherence to the precautions, procedures, and maintenance practices described should ensure long reliable operation. Suggestions for improvements to this manual are solicited.

1-2. Safety Standards

All persons concerned with the installation, operation, inspection and maintenance of these hoists are urged to read American National Standard (ANSI) B30.16. That Standard contains valuable guidelines concerning practices designed to minimize hazards associated with the use of overhead hoisting equipment. ANSI B30.16 also contains detailed procedures for establishing hoist inspection and maintenance programs and can be of significant assistance in maintaining compliance with OSHA regulations.

1-3. Hoist Construction and Features

This hoist has a steel drum and center frame for strength in the load-bearing areas. Strong, lightweight aluminum alloy castings provide a compact, protective enclosure for the mechanical and electrical components.

Heat-treated alloy steel gearing operates in an oil bath to provide the most reliable lubrication and effective heat dissipation. LEW-1 Series Hoists incorporate the following features:

- Overload limiting clutch.
- Completely independent mechanical and electrical brakes.
- Adjustable limit switches.
- Tough, nylon, weatherproof pushbutton stations.
- Steel strain cable inside pushbutton cord.
- Transformer isolated, low-voltage pushbutton controls.
- Quick voltage conversion on dual-voltage units.

1-4. Basic Hoist Data

The basic hoist models covered by this manual are listed in Table 1-1.

SECTION I - INTRODUCTION

Table 1-1. Basic Hoist Data

| Model Number | Rated Load (Lbs) | Lift Speed At Rated Load (Ft. Per Min.) | Motor HP |
|---------------------|------------------|---|----------|
| LEW 1/2-(+) ** 10*2 | 1000 | 10 | 1/2 |
| LEW 1/2-(+) ** 16*2 | 1000 | 16 | 1/2 |
| LEW 1/2-(+) ** 21*2 | 1000 | 21 | 3/4 |
| LEW 1/2-(+) ** 32*2 | 1000 | 32 | 1 |
| LEW 1-(+) ** 10*2 | 2000 | 10 | 3/4 |
| LEW 1-(+) ** 16*2 | 2000 | 16 | 1 |

+ Specify lift required - see catalog and/or price list.

* Specify reeving - S (Single), D (Double-Cross Mounted or P (Double-Parallel Mounted).

** Specify suspension - LG, PT, GT, MT/RT.

1-5. Application Information

This hoist is intended for general industrial use in the lifting and transporting of freely suspended material loads within its rated load. Prior to installation and operation, the user should review his application for abnormal environmental or handling conditions and to observe the applicable recommendations as follows:

- Adverse Environmental Conditions.** Do not use the hoist in areas containing flammable vapors, liquids, gases or any combustible dusts or fibers. Refer to Article 500 of The National Electric Code. Do not use this hoist in highly corrosive, abrasive or wet environments. Do not use this hoist in applications involving extended exposure to ambient temperatures below - 10°F or above 130°F.
- Lifting of Hazardous Loads.** This hoist is not recommended for use in lifting or transporting hazardous loads or materials which could cause widespread damage if dropped. The lifting of loads which could explode or create chemical or radioactive contamination if dropped requires fail-safe redundant supporting devices which are not incorporated into this hoist.
- Lifting of Guided Loads.** This hoist is not recommended for use in the lifting of guided loads, including dumbwaiters and non-riding elevators. Such applications require additional protective devices which are not incorporated into this hoist. Refer to your state and local regulations governing the requirements for elevator and dumbwaiter installations.

1-6. Warranty

Every hoist is thoroughly inspected and tested prior to shipment from the factory. Should any problems develop, return the complete hoist prepaid to your nearest Yale Authorized Warranty Repair Station. If inspection reveals that the problem is caused by defective workmanship or material, repairs will be made without charge and the hoist will be returned, transportation prepaid.

This warranty does not apply where: (1) deterioration is caused by normal wear, abuse, improper or inadequate power supply, eccentric or side loading, overloading, chemical or abrasive actions, improper maintenance or excessive heat; (2) problems resulted from repairs, modifications or alterations made by persons other than factory or Yale Authorized Warranty Repair Station personnel; (3) the hoist has been abused or damaged as a result of an accident; (4) repair parts or accessories other than those supplied by Yale are used on the hoist. Equipment and accessories not of the seller's manufacture are warranted

only to the extent that they are warranted by the manufacturer. EXCEPT AS STATED HEREIN, YALE MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

2-1. Safety Notes

- Inspect the hoist for any evidence of shipping damage or loose parts.
- The supporting structure and load attaching devices should have a load rating at least equal to that of the hoist.
- This hoist is not suitable for use in uncovered outdoor locations or areas containing explosive dust, vapors or gases.
- The installation area must provide safe operating conditions for the operator, including sufficient room for the operator and other personnel to stand clear of the load at all times.

2-2. Trolley Installation

Yale trolleys can be mounted on American Standard I Beams from 6 to 18 inches high. Adjustment for different beam dimensions is accomplished with the proper placement of spaced washers as described below.

- "I"-Beam Adjustment.** Adjustment for "I" beam sizes and tolerances is accomplished by locating the spacer washers as shown in Figures 2-1, 2-2, and 2-3. Tables 2-1, 2-2, and 2-3 provide an approximate guide to washer placement. Be sure to use the proper Table, based on lift and trolley-type of the particular installation.

BEAM MANUFACTURING TOLERANCES ALLOW WIDE VARIATIONS FROM HANDBOOK FLANGE WIDTHS, AND SLIGHT CHANGES TO RECOMMENDED WASHER DISTRIBUTION MAY BE NECESSARY TO SUIT SPECIFIC INSTALLATIONS.

The particular beam on which your hoist is to be installed should be measured and trolley spacer washers adjusted as required to achieve a clearance of 1/2" to 1/8".

Trolleys can be mounted on beam radii as small as 4 feet. Slightly increased spacing may be required when the trolley is mounted on curved beams to maintain freedom of movement.

The load pin nuts for the trolleys require a tightening torque of 100 ft. lbs. Refer to Figures 2-1, 2-2, and 2-3 for nut identification.

- Periodic Inspection.** The trolley should be inspected periodically for evidence of excess wear or overload. Parts should be replaced as required.
- Lubrication.** Trolley wheels are equipped with sealed, lifetime lubricated, precision ball bearings which should not require lubrication for the normal service of the trolley.

2-3. Power Supply Connection

- Disconnect power before making connections.
- Voltage supplied to the hoist should be within plus or minus 10% of the voltage specified for the hoist. Hoists are tagged at the factory with a tag indicating the voltage for which the hoist is wired. Standard single-phase hoists are convertible from 115 to 230 volts. Standard single-speed, 3 phase hoists are convertible from 460 volts to 230 volts. See the wiring section (paragraph 7-1) for voltage conversion instructions.

SECTION I - INTRODUCTION

- c. National Electrical Code (ANSI C1) and local electrical codes should be consulted and proper disconnects, branch circuit protectors, and wiring provided.
 - d. Power cables furnished with the hoist have a green colored ground wire which must be securely connected to the electrical system ground.
 - e. When installing a three-phase hoist, make only temporary connections at the power line. Push the "UP" button and observe the direction of the hook. If it raises, the phasing is correct and permanent connections may be made at the power line. If the load block lowers when the "UP" button is pushed, release the button immediately since the limit switches will not operate to protect the hoist from overtravel. Reverse the red and black wires at the power line connection to correct the hook direction.
2. If brake operation is normal with a light load, repeat the above procedure with approximately one-half rated load, again running the hoist through its full lift stroke for a few cycles. Check again for hook drift.
 3. If brake operation is normal with one-half rated load, attach rated load to the hook and continue the break-in procedure. The hoist shall operate smoothly and the brake should prevent hook drift in excess of one inch as rated load. See Paragraph 5-3 if motor brake adjustment is required.
 4. Set the load on the floor. Disconnect the dead end of the wire rope as described in paragraph 5-4.a.8. Allow the dead end to rotate, in order to remove all twist from the rope. Reconnect the dead end and be sure to replace and tighten the anchor screws.

CAUTION

Do not change connections in the hoist or the pushbutton assembly.

2-4. Vent Plug

This hoist has an oil-bath transmission. For shipping purposes, a non-vented fill plug (39, Figure 8-4) was installed at the factory. A vented plug is located in an envelope tied to one of the hoist end covers and must be installed in place of the non vented shipping plug before operating the hoist.

2-5. Wire Rope Lubrication

It is important that the wire rope is lubricated before the hoist is put into service. Wire rope lubricant is packed with each hoist. For lubrication instructions, see paragraph 5-5a. Additional lubricant is available from your Yale distributor. Specify Part No. 14J49.

2-6. Testing


- a. Before placing the hoist into operation, check for proper limit switch operation. Push the "UP" button and verify that the hook block stops at least 2 inches from the bottom of the hoist. Run the hoist down to its lower limit. At least 2 wraps of wire rope should remain on the drum. If either switch is not correct, adjust according to the procedure outlined in paragraph 5-2.

Note

The upper and lower limit switches are factory set to provide the maximum allowable hook travel. **This travel adjustment should not be increased.** However, the switches may be adjusted to stop the hook sooner at either end of its travel.

- b. Wire rope life can be extended by a short breaking-in period before the hoist is put into service. During this breaking-in period, a small amount of twist may show up in the rope. This twist should be removed as described below. This break-in can be done at the time of hoist testing:
 1. Attach a light load to the hook and run the hoist through its full lift stroke for a few lifting and lowering cycles. Check for hook drift. The hook should not drift more than one inch.

WR-1 Hoists on Coffing Trolleys
Four-Wheel Trolley on 3" Suspension Yoke
 (Applies to hoists with a single trolley)



14016

Figure 2-1


Table 2-1. Trolley I-Beam Adjustment Data

| I-Beam* Size & Weight | Flange Width | Point A Washer Between Susp. Yoke & Sleeve | | Point B Washers Between Sideplate & Nut | | Actual Spacing Suspension Lug to Sleeve | Point C Clearance Wheel to Beam |
|-----------------------------|-----------------|--|------------|---|------------|---|---------------------------------------|
| | | .135 Thick | .075 thick | .135 Thick | .075 thick | | |
| 6" - 12.5# | 3.330 | 0 | 5 | 8 | 8 | .375 | .099 |
| 6" - 17.25# | 3.565 | 2 | 3 | 6 | 10 | .495 | .102 |
| 8" - 18.4# | 4.000 | 3 | 4 | 5 | 9 | .705 | .094 |
| 8" - 23.0# | 4.171 | 2 | 7 | 6 | 6 | .795 | .099 |
| 10" - 25.4# | 4.660 | 1 | 12 | 7 | 1 | 1.035 | .094 |
| 10" - 35.0# | 4.944 | 6 | 5 | 2 | 8 | 1.185 | .102 |
| 12" - 31.8# | 5.000 | 4 | 9 | 4 | 4 | 1.215 | .104 |
| 12" - 35.0# | 5.078 | 7 | 4 | 1 | 9 | 1.245 | .095 |
| 15" - 42.9# | 5.500 | 7 | 7 | 1 | 6 | 1.470 | .109 |
| 15" - 50.0# | 5.640 | 8 | 6 | 0 | 7 | 1.530 | .099 |
| 18" - 54.7# | 6.000 | 6 | 12 | 2 | 1 | 1.170 | .099 |

* American Standard I-Beam

Note: All dimensions are in inches unless otherwise specified.

Four-Wheel Trolley on 3⁵/₈" Suspension Adapter (Applies to hoists with a dual trolley)



14017

Figure 2-2

Table 2-2. Trolley I-Beam Adjustment Data

| I-Beam* Size & Weight | Flange Width | Point A Washer Between Susp. Yoke & Sleeve | | Point B Washers Between Sideplate & Nut | | Actual Spacing Suspension Lug to Sleeve | Point C Clearance Wheel to Beam |
|-----------------------------|-----------------|--|------------|---|------------|---|---------------------------------------|
| | | .135 Thick | .075 thick | .135 Thick | .075 thick | | |
| 6" - 12.5# | 3.330 | 0 | 1 | 7 | 8 | .075 | .111 |
| 6" - 17.25# | 3.565 | 1 | 1 | 6 | 8 | .210 | .129 |
| 8" - 18.4# | 4.000 | 3 | 0 | 4 | 9 | .405 | .106 |
| 8" - 23.0# | 4.171 | 3 | 1 | 4 | 8 | .480 | .096 |
| 10" - 25.4# | 4.660 | 1 | 8 | 6 | 1 | .735 | .106 |
| 10" - 35.0# | 4.944 | 2 | 8 | 5 | 1 | .870 | .099 |
| 12" - 31.8# | 5.000 | 4 | 5 | 3 | 4 | .915 | .116 |
| 12" - 35.0# | 5.078 | 3 | 7 | 4 | 2 | .930 | .092 |
| 15" - 42.9# | 5.500 | 7 | 3 | 0 | 6 | 1.170 | .121 |
| 15" - 50.0# | 5.640 | 4 | 9 | 3 | 0 | 1.215 | .096 |
| 18" - 54.7# | 6.000 | 6 | 8 | 1 | 1 | 1.410 | .111 |

* American Standard I-Beam

Note: All dimensions are in inches unless otherwise specified.

Two-Wheel Trolley on 3⁵/₈" Suspension Adapter (Applies to hoists with dual trolleys)




Figure 2-3

Table 2-3. Trolley I-Beam Adjustment Data

| I-Beam* Size & Weight | Flange Width | Point A Washer Between Susp. Yoke & Sleeve | | Point B Washers Between Sideplate & Nut | | Actual Spacing Suspension Lug to Sleeve | Point C Clearance Wheel to Beam |
|-----------------------------|-----------------|--|------------|---|------------|---|---------------------------------------|
| | | .135 Thick | .075 thick | .135 Thick | .075 thick | | |
| 6" - 12.5# | 3.330 | 3 | 5 | 8 | 5 | .780 | .097 |
| 6" - 17.25# | 3.565 | 5 | 3 | 6 | 7 | .900 | .100 |
| 8" - 18.4# | 4.000 | 5 | 6 | 6 | 4 | 1.125 | .107 |
| 8" - 23.0# | 4.171 | 5 | 7 | 6 | 3 | 1.200 | .097 |
| 10" - 25.4# | 4.660 | 8 | 5 | 3 | 5 | 1.455 | .107 |
| 10" - 35.0# | 4.944 | 9 | 5 | 2 | 5 | 1.590 | .100 |
| 12" - 31.8# | 5.000 | 7 | 9 | 4 | 1 | 1.620 | .102 |
| 12" - 35.0# | 5.078 | 10 | 4 | 1 | 6 | 1.650 | .093 |
| 15" - 42.9# | 5.500 | 11 | 5 | 0 | 5 | 1.860 | .092 |
| 15" - 50.0# | 5.640 | 11 | 6 | 0 | 4 | 1.935 | .097 |
| 18" - 54.7# | 6.000 | 11 | 9 | 0 | 1 | 2.160 | .142 |

* American Standard I-Beam

Note: All dimensions are in inches unless otherwise specified.

SECTION III - OPERATION

3-1. General

This section presents information concerning the proper operation on the Yale Electric Wire Rope Hoist. It is not intended to serve as a handbook on rigging. Rigging, the process of moving heavy loads using mechanical devices, requires special knowledge and equipment. For information on the safe use of slings and similar rigging gear, users are urged to consult a textbook on rigging.

3-2. Safety Notes

- a. Inspect the hoist for any sign of loose, broken, or malfunctioning parts (see Section IV). Any malfunctioning hoist should be tagged as "out of order" and removed from service until the defect is corrected.
- b. Before starting the hoist, the operator should be certain that all personnel are clear.
- c. Do not lift more than the rated load of the hoist.
- d. Do not lift people or loads over people.
- e. Avoid jogging controls or quick reversals of suspended loads.
- f. Do not leave a suspended load unattended.
- g. The operator should have a clear view of the load anytime it is moving and should be sure that the load does not contact any obstructions.
- h. Read ANSI B30.16 Safety Standard for Overhead Hoists.

3-3. Handling The Load

- a. Align hoist directly over load. Avoid side pull, since this can cause the wire rope to jump grooves, or overwrap itself. This condition will quickly damage the wire rope.

- b. The wire rope should not be wrapped around the load. Use proper slings.
- c. Be sure the wire rope is properly seated in the drum groove and in the bottom block sheave.
- d. Bring the hook into engagement with the load and make sure it is well seated before proceeding to lift the load. Be sure that the load is equalized on all supporting ropes.
- e. Lift the load just clear of its supports and stop the hoist to check for proper brake operation.
- f. Avoid letting the hook or load swing excessively while moving a trolley suspended hoist.

3-4. Overload Limiting Protection

This hoist is equipped with a factory-calibrated overload limiting clutch, which permits lifting loads within rated capacity and prevents lifting excessive loads which could damage the hoist. If the load exceeds the lifting capability of the overload clutch, the hoist will not lift the load, but the motor will run as long as the "UP" button is pressed. Repeated attempts to lift an excessive load will overheat the overload clutch and cause permanent damage to the clutch.

CAUTION

The overload limiting clutch is an emergency protection device. It should not routinely be used to measure the maximum load to be lifted.

SECTION IV - INSPECTION

4-1. General

A scheduled inspection routine should be established for this hoist based upon severity of use and environmental conditions. Some inspections should be made frequently (daily to monthly) and others periodically (monthly to yearly). It is suggested that an Inspection and Maintenance Check List and an Inspector's Report similar to those shown in Figures 4-1 and 4-2 be used and filed for reference. All inspections should be made by a designated inspector. Special inspections should be made after any significant repairs or any situation causing suspicion that the hoist may have been damaged. Any hoist which has been removed from service for an extended time should receive an inspection as described under Periodic Inspections. ANSI B30.16, Safety Standard for Overhead Hoists, provides guidelines for hoist operation and inspection.

CAUTION

Any unsafe condition disclosed by any inspection must be corrected before operation of the hoist is resumed.

4-2. Frequent Inspection

- a. Check pushbutton station, brake, and limit switches for proper operation.
- b. Check hooks for deformation, chemical damage, or cracks. Bent hooks or hooks damaged from chemicals, deformation, cracks, or having excessive throat opening (see paragraph 4-6) should be replaced. Visible deformation of any hook may be evidence of hoist abuse and overloading and indicates that a thorough inspection of the complete hoist should be made.
- c. Check that bottom hook swivels freely.
- d. Check for missing, bent or otherwise damaged hook latches.
- e. Check pushbutton and power cord for cuts or other damage.
- f. Check wire rope for wear, twist, distortion or kinks.

4-3. Periodic Inspection

The exact period for the following inspections will depend on the anticipated severity of hoist use. Determination of this period should be based on the user's experience. It is recommended that the user begin with a monthly inspection and extend the periods to quarterly, semiannually, or annually, based on his monthly inspection experience.

- a. Clean hoist of any dirt or foreign material. Inspect bottom block for accumulation of debris.
- b. Perform all frequent inspections listed above.
- c. Check for loose bolts, screws and nuts.
- d. Check housings, load block, and other parts for wear, corrosion, cracks or distortion. Check for abnormal openings between housing sections.
- e. Check motor brake for worn discs, oil contamination or excessive clearance (see paragraph 5-3).
- f. Check mechanical load brake function (paragraph 4-4).
- g. Inspect the entire length of wire rope for deficiencies. See WIRE ROPE INSPECTION, paragraph 4-5.
- h. Inspect hooks and suspension parts for cracks, distortion or extreme wear.
- i. Inspect hooks for cracks using magnetic particle, dye penetrant or other crack detecting methods.
- j. Check limit switch set points and reset if necessary (see paragraph 5-2).
- k. Inspect all wiring for defective insulation, and check to be sure all electrical connections are tight. Check motor reversing contactor or relay for burned contacts.
- l. Inspect for oil leaks. Check oil level.
- m. Inspect for missing or illegible capacity or warning labels.
- n. Inspect the supporting structure for continued ability to support the hoist rated load.

INSPECTION & MAINTENANCE CHECK LIST ELECTRIC POWERED OVERHEAD WIRE ROPE HOIST

TYPE OF HOIST _____ CAPACITY (TONS) _____
LOCATION _____ ORIGINAL INSTALLATION DATE _____
MANUFACTURER _____ MANUFACTURER'S SERIAL NUMBER _____

| Item | Frequency of Inspection | | | Possible Deficiencies | OK | Action Required |
|--|-------------------------|---------|----------|--|----|-----------------|
| | Frequent | | Periodic | | | |
| | Daily | Monthly | 1-12 Mo. | | | |
| Operating Controls | • | • | • | Any deficiency causing improper operation | | |
| Limit Switches | • | • | • | Any deficiency causing improper operation Pitting or deterioration | | |
| Disc (Motor) Brake | • | • | • | Slippage or excessive wear Glazing, contamination of excessive wear | | |
| Load Brake (Mechanical) | | | • | Failure to support load with disc brake open (see Figure 4-8) | | |
| Hooks | • | • | • | Excessive throat opening, bent or twisted more than 10 degrees, damaged hook latch, wear, chemical damage, worn hook bearing Cracks (use dye penetrant, magnetic particle or other suitable detection method) | | |
| Suspension Lug | | | • | Cracks, excessive wear or other damage which might impair the strength of the lug Cracks (use dye penetrant, magnetic particle or other suitable detection method) | | |
| Wire Rope | • | • | • | Inadequate lubrication, wear, twist, distortion, improper dead-ending, deposits of foreign substance Deterioration or wear resulting in appreciable loss of original strength | | |
| Suspension Lug Connections | | | • | Cracks, bending, stripped threads, damaged suspension studs | | |
| Pins, Bearings, Bushings, Shafts, Couplings, Gears | | | • | Excessive wear, corrosion, cracks, distortion | | |
| Nuts, Bolts, Rivets | | | • | Looseness, stripped and damaged threads, corrosion | | |
| Sheave, Drum | | | • | Distortion, cracks and excessive wear Build up of foreign substances | | |
| Housing, Load Block | | | • | Cracks, distortion, excessive wear, Internal build up of foreign substances | | |
| Wiring and Terminals | | | • | Fraying, defective insulation | | |
| Contact Block, Magnetic Hoist Control Switch, Other Electrical Apparatus | | | • | Loose connections, burned or pitted contacts | | |
| Supporting Structure and Trolley (if used) | | | • | Damage or wear which restricts ability to support imposed loads | | |
| Nameplates, Decals Warning Labels | | | • | Missing, damaged or illegible | | |
| Transmission Lubricant | | | • | Low Level, Requires Changing | | |
| Note: Refer to Maintenance and Inspection Sections of the Hoist Maintenance Manual for further details. | | | | | | |

FREQUENCY OF INSPECTION:

Frequent - Indicates items requiring inspection daily to monthly. Daily inspections may be performed by the operator if properly designated.

Periodic - Indicates items requiring inspection monthly to yearly. Inspections to be performed by or under the direction of a properly designated person. The exact period of inspection will depend on frequency and type of usage. Determination of this period will be based on the user's experience. It is recommended that the user begin with a monthly inspection and extend the periods to quarterly, semiannually or annually based on his monthly experience.

Figure 4-1. Recommended Inspection and Maintenance Check List

| INSPECTOR'S REPORT | | | |
|-----------------------|--|-------------|------|
| Item | Remarks (List Deficiencies and Recommended Action) | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| Inspector's Signature | Date Inspected | Approved By | Date |

Figure 4-2 Recommended Inspector's Report

4-3. Load Brake Function Check

To check the functioning of the mechanical load brake, proceed as follows:

- Attach a light load to the hoist and lift it several inches.
- Disconnect Hoist From Power Supply** and remove short end brake cover (see Figure 8-1, Index No. 1).
- Referring to Figure 4-3 and Figure 8-9, place screwdrivers No. 1 and No. 2 behind the plate and armature assembly and prepare to pry against the transmission cover.

Note

Do not allow either screwdriver to contact brake disc (see Figure 8-9, Index No. 7).

- d. Carefully pry open motor brake (close solenoid gap) and observe action of load. If the load accelerates, the mechanical load brake is malfunctioning and must be repaired.




Figure 4-3 Load Brake Function Check List

4-5. Wire Rope Inspection

- a. Make a thorough inspection of the wire rope at least once each month and keep a written, dated and signed report of rope condition on file. Any deterioration, resulting in appreciable loss of original strength, such as described below, shall be carefully noted and determination made as to whether further use of the rope would constitute a safety hazard. See Figure 4-4 for identification of wire rope components.
 - 1) Reduction of rope diameter below nominal due to loss of core support, internal or external corrosion or wear of outside wires.
 - 2) A number of broken outside wires and the degree or distribution or concentration of such broken wires.
 - 3) Worn outside wires.
 - 4) Sections of rope which are normally hidden during inspection or maintenance procedures, such as parts passing over sheaves, should be given close inspection as these are points most subject to deterioration.
 - 5) Corroded or broken wires at end connections.
 - 6) Corroded, cracked, bent, worn or improperly applied end connections.
 - 7) Kinking, crushing, cutting or unstranding.
- b. No precise rules can be given for determination of exact time for replacement of wire rope, since many variable factors are involved. Safety in this respect depends largely upon the use of good judgment in evaluating remaining strength in the used rope after allowance for deterioration disclosed

by inspection. Safety of rope operation depends upon this remaining strength. Conditions such as the following should be sufficient reason for questioning rope safety and consideration of replacement.

- 1) Twelve randomly distributed broken wires in one rope lay length or four broken wires in one strand in one rope lay length. One lay is the length, parallel to the longitudinal axis, in which a strand makes one complete turn about the axis of the rope. See Figure 4-4.
- 2) Two wires broken adjacent at the end fittings.
- 3) Wear of one-third of the original diameter of outside individual wires.
- 4) Kinking, crushing, birdcaging or any other damage resulting in distortion of the rope structure.
- 5) Evidence of any heat damage from any cause.
- 6) Reductions from nominal 1/4 inch diameter to 15/64 inch.

⚠ CAUTION

Use only wire rope assemblies supplied by our company since replacement rope assemblies must be of the same size, grade and construction rope and have the same swagged end fittings as the original rope assembly.

4-6. Hook Throat Opening

Check throat opening as indicated in Figure 4-5. Replace hook if measurement exceeds the allowable.




Figure 4-4 Basic Components of Wire Rope




Figure 4-5 Hook Throat Opening

SECTION V - MAINTENANCE AND REPAIR

5-1. General

This section provides instructions for the most common routine maintenance and adjustments. Major repairs are not within the scope of this manual and should be referred to qualified service facilities.

SAFETY NOTE

Always remove load and disconnect hoist from power supply before removing end covers or making repairs.

5-2. Limit Switch Adjustment

Limit switches are provided to protect the hoist against damage resulting from over travel. For easy identification the upper (No. 2, Figure 5-1) and lower (No. 3, Figure 5-1) limit switch adjusting nuts are colored brass and zinc respectively. Each limit switch nut has ten slots for adjustment, and the increment of adjustment is such that one slot is equivalent to approximately 3/4" of hook travel. Care should be exercised when adjusting either limit of travel.

a. Adjusting Upper Limit (Brass Nut).

- 1) Carefully raise the load block to a point where its top is 2" or more from the hoist housing.
- 2) DISCONNECT POWER from the hoist and remove the short end cover.
- 3) With a screwdriver, pry the spring guide plate (No. 1, Figure 5-1) out of the slots in the colored limit switch nuts (Nos. 2 and 3).




Figure 5-1 Limit Switch Adjustment

- 4) Turn the slotted brass nut (No. 2) toward its limit switch until the switch clicks.
- 5) Release the spring guide plate and be sure it snaps back into the slots in both nuts. Do not disturb the other slotted nut if it has been previously set.
- 6) Replace the short end cover and reconnect power to the hoist.
- 7) Carefully raise the load block to its upper limit and observe to see if it stops automatically at the desired point. Do not allow the load block to run into the hoist drum. The stopping point should be at least 2" below the hoist drum.

b. Adjusting Lower Limit (Zinc Nut)

- 1) Carefully lower the load block to a point where at least 2 wraps of wire rope remain on the drum.
- 2) DISCONNECT POWER from the hoist and remove the short end cover.
- 3) Adjust the zinc limit switch nut in the same manner described above for the brass nut.
- 4) Replace the short end cover and reconnect power to the hoist.
- 5) Carefully lower the load block to its lower limit and observe if it stops automatically at the desired level. At least 2 wraps of wire rope should remain on the drum.

NOTE

If upper and lower limits are not operating satisfactorily, repeat adjustment.

5-3. Motor Brake Adjustment

When properly adjusted, the multiple disc motor brake should release promptly, operate without noticeable chatter, and stop the load with no more than one inch of drift. If the hoist hesitates to lift the load promptly when the pushbutton is depressed, the brake should be adjusted per the following procedure.




Figure 5-2 Motor Brake Adjustment

- a. Remove any load and DISCONNECT POWER from hoist.
- b. Remove the short end cover.
- c. Referring to Figure 5-2, check the gap between armature (A) and frame (B). The correct gap is .015".
- d. Adjust the gap by turning the three lock nuts (F) and check with a feeler gauge to be sure the gap is the same on both ends of the solenoid.

CAUTION

Be sure the bottom of the armature does not touch the splined adapter (H). As wear occurs, the original clearance will be reduced. When this clearance is gone, **the brake discs must be replaced.**


- e. Replace short end cover and reconnect power. If the brake still chatters or is hesitant to release, refer to Section V4, Troubleshooting.

5-4. Wire Rope Replacement

For hoists reeved Two Part Single, see paragraph 5-4a. For hoists reeved Two Part Double see paragraph 5-4b.

a. Hoists Reeved Two Part Single:

Refer to Figure 5-3 for parts identification and proper rope reeving.




**Figure 5-3. Two Part Single Reeving:
Standard Headroom Models**

- 1) Push "DOWN" button and run old rope out until stopped by lower limit switch.
- 2) Disassemble the load block by removing the screws (9, Figure 8-9A) and one spring pin (3, Figure 8-9A). Clean and inspect the block, hook, sheave, bearings, and pin for wear, damage, etc. Replace parts as necessary. Do not reassemble the load block at this point.
- 3) DISCONNECT POWER from the hoist and remove the short end cover.
- 4) With a screwdriver, push the spring guide plate (1, Figure 5-1) out of the slots in the limit switch nuts. Turn the zinc slotted nut (3) back to about the center of the threaded screw. DO NOT DISCONNECT THE WIRES FROM THE LIMIT SWITCHES.
- 5) With the end cover off, connect hoist to power supply. Be sure the green wire is grounded.
- 6) Carefully jog the "DOWN" button until all the old rope is run off and the drum socket opening is accessible.
- 7) DISCONNECT POWER from the hoist.
- 8) Disconnect old rope dead end eye by removing one dead end anchor screw (A, Figure 5-3) and loosening the other screw (B) approximately three turns. Lift the dead end eye up and slide the anchor pin back by grasping the head of screw (B).
- 9) Slide the sleeve fitting out of the drum socket. Remove and discard the old rope.


- 10) Place paper on floor to protect the new wire rope from dirt and grit. Stretch the new rope out on the paper with the sleeve fitting end toward the hoist. Relieve any twist in the new rope.
- 11) Insert the new rope's sleeve fitting into the drum socket, making sure the fitting is properly seated.
- 12) Push the "UP" button until about half of the new rope is wound onto the drum. Apply slight tension to the rope with a gloved hand to wind rope evenly on the drum.
- 13) Attach the dead end by placing the new rope's eye fitting over the anchor pin, while making sure there are no twists in the rope. Be sure to replace and tighten both anchor pin screws.
- 14) Reassemble the load block onto the new wire rope. See Figure 8-9A for aid in reassembly. Refer to Figure 5-3 to make sure that the rope is reeved correctly.
- 15) Adjust the limit switches per paragraph 5-2.
- 16) Lubricate the wire rope per paragraph 5-5a. Test the hoist and break-in the wire rope per paragraph 2-6b.

b. Hoists Reeved Two Part Double:

Refer to Figures 5-4 or 5-5 for parts identification and proper rope reeving.




**Figure 5-4. Two Part Single Reeving:
True Vertical Lift Models**



**Figure 5-5. Two Part Single Reeving:
Low Headroom Models**

- (1) Push "DOWN" button and run old rope out until stopped by lower limit switch.
- (2) Disassemble the load block by removing the spring pins (12, Figure 8-9B) and the slotted nuts (9, Figure 8-9B). The block covers (11, Figure 8-9B) will still be captured by the rope. Clean and inspect the hook, sheaves, bearings, and yoke for wear, damage, etc. Replace parts as necessary. Do not reassemble the load block yet.
- (3) DISCONNECT POWER from the hoist and remove the short end cover.
- (4) With a screwdriver, push the spring guide plate (1, Figure 5-1) out of the slots in the limit switch nuts. Turn the zinc slotted nut (3) back to about the center of the threaded screw. DO NOT DISCONNECT THE WIRES FROM THE LIMIT SWITCHES.
- (5) With the end cover off, connect hoist to power supply. Be sure the green wire is grounded.
- (6) Carefully jog the "DOWN" button until all the old rope is run off and the drum socket openings are accessible.
- (7) DISCONNECT POWER from the hoist.
- (8) Remove the equalizer sheave (A, Figure 5-4 or 5-5) by removing one retaining ring (B) and the sheave pin (C). Clean and inspect these parts.
- (9) Slide the sleeve fittings out of the drum sockets and out of the block covers. Remove and discard the old rope.
- (10) Place paper on floor to protect the new wire rope from dirt and grit. Stretch the new rope out in one length and relieve any twist. The double the rope by bringing the two sleeve fittings together.
- (11) Pass each sleeve fitting through the rope openings in the block covers only. The block should remain disassembled at this point.
- (12) Insert each sleeve fitting into the drum sockets, making sure the fittings are properly seated.

- (13) Push the "UP" button until a few wraps of rope are wound onto the drum. Apply slight tension to the ropes with gloved hands to wind the rope evenly on the drum.
- (14) Place the looped end over the equalizer sheave and return the sheave to its frame. Reinstall the sheave pin and retaining ring.
- (15) At this point, only the block covers will be hanging from the two loops of rope.



**Figure 5-6. Assembly of Load Block
Two Part Double Reeved**

- (16) Refer to Figure 5-6 for assembly of load block. Pull a loop of rope to the inside of the block cover (A), and place a sheave (B) in this loop. Angle the top of the sheave into the cover, while keeping the rope seated in the sheave groove. The sheave will now drop to the inside wall of the cover. Place the sheave and cover, as one unit, over the yoke (C), and hand tighten the slotted nut. Repeat for the other side. Tighten both slotted nuts and install the spring pins. Refer to Figure 5-4 or 5-5 to make sure that the rope is reeved correctly.
- (17) Adjust the limit switched per paragraph 5-2.
- (18) Lubricate the wire rope for paragraph 5-5a. Test the hoist and break-in the wire rope per paragraph 2-6b.

5-5. Lubrication

Proper lubrication is necessary for long, trouble-free hoist operation. Refer to the following and to Table 5-1, Recommended Lubrication Schedule, for lubrication points, type of lubricant and frequency of lubrication.

- a. **Wire Rope:** Lubrication of the wire rope is important. The action within the rope as it moves over the drum or around the sheave is for the strands to slide one against the other. Lubrication will reduce this friction and prevent the entrance of moisture which can cause corrosion. Frequent light applications of lubricant are better than infrequent heavy applications. For best results, use Yale Wire Rope Lubricant (Part No. 14J49), or other wire rope lubricant. As alternative, use SAE 30 motor oil.
- b. **Gearing:** The gear case of the hoist is filled at assembly with 46 oz. of a gear oil containing special friction-reducing additives.

⚠ WARNING

The use of gear oils other than that recommended in Table 5-1 can cause brake chatter or can render the load brake incapable of holding a load. A 46 oz. container of this oil is available from Yale•Lift-Tech. (Part No. 14J1).

- a. **To check the oil level**, remove the 1/8" pipe plug from the side of the hoist. With the hoist hanging level, transmission oil should be even with the edge of the tapped plug hole.
- b. The length of time between necessary oil changes will depend on the severity of use the hoist receives. In general, the oil should be changed every 12 months of normal operation, or every 200 hours of actual hoist on-time. Very heavy use or operation in high ambient temperatures (over 105°F) will require that oil be changed more often. An indication of the need for oil replacement is load brake noise. If an erratic tapping sound is made when lowering a load, the oil should be changed.
- c. **Limit Switch Shaft:** To prevent rust, the threaded limit switch shaft should be given a light coat of grease or sprayed with a general purpose lubricant.
- d. **Hook Bearing:** Apply a few drops of SAE 30 oil around the edge of the bearing.
- e. **Sheave Bearings:** At periodic inspections (see Figure 4-1), and when the wire rope is replaced, wash out the old grease with solvent and pack with new grease.
- f. **Trolley Gear Box:** At periodic inspections (see Figure 4-1) check grease level by removing end cap (22, Figure 8-11). The gear box should be approximately half full of grease. In general, the trolley gear box lubricant does not require changing.
- g. **Trolley Wheel Gears:** Apply a light coat of grease to the pinion and both gears.

Table 5-1. Recommended Lubrication Schedule* Model LEW-1 Electric Wire Rope Hoist

| Figure And Index No. | Component | Type of Lubricant | Type of Service and Frequency of Lubrication | | |
|---|------------------------|---|---|---------|------------|
| | | | Heavy | Normal | Infrequent |
| Figure 8-5C, No. 26 Figure 8-5B, No. 44 Figure 8-5A, No. 17 | Wire Rope | Coffing Wire Rope Lubricant (Kit No. 14J49 contains 8 fl. oz) or SAE 30 Gear or Motor Oil | Daily | Weekly | Monthly |
| Figure 8-4 | Hoist Gearing | Coffing No. H-7813 transmission oil (Kit No. 14J1 contains quantity of oil sufficient for one oil change) | At periodic inspection (see Figure 4-1, paragraph 5-5b) | | |
| Figure 8-6, No. 9 | Limit Switch Shaft | "WD-40" or general purpose spray lubricant | Monthly | Yearly | Yearly |
| Figure 8-9B, No. 5 Figure 8-9A, No. 11 | Load Hook Bearing | SAE 30 Gear or Motor Oil | Weekly | Monthly | Yearly |
| Figure 8-9B, No. 3 Figure 8-9A, No. 7 | Sheave Bearings | NLGI #2 multipurpose lithium-base grease (Coffing No. H-7610) | At periodic inspection (see Figure 4-1) | | |
| Figure 8-11 | Trolley Gear Box | NLGI #2EP lithium-base grease. (Coffing No. H-7610) | At periodic inspection (see Figure 4-1) | | |
| Figure 8-10B, No. 23 Figure 8-10A, No. 17 | Gears Trolley Wheel | NLGI #2 multipurpose lithium-base grease (Coffing No. H-7610) | Weekly | Monthly | Yearly |

Note: All bearings except hook and sheave bearings are pre-lubricated and sealed.

* This lubrication schedule is based on a hoist operating in normal environmental conditions. Hoists operating in adverse atmospheres containing excessive heat, corrosive fumes or vapors, abrasive dust, etc., should be lubricated more frequently.

SECTION VI - TROUBLESHOOTING

6-1. General

Use the following table as an aid to troubleshoot your hoist. If you do not have an experienced machinist-electrician to do your repair work, we recommend that you send your hoist to an approved service center for repairs.

| TROUBLE | REMEDY |
|---------|--------|
|---------|--------|

Hook Fails to Stop at End of Travel

| | |
|--|--|
| <ol style="list-style-type: none"> 1. Limit switches not operating. 2. Limit switch nuts not moving on shaft. 3. Magnetic reversing switch malfunction. | <ol style="list-style-type: none"> 1. Check adjustment. See paragraph 5-2. Check connections against wiring diagram. Tighten loose connections or replace. 2. Check for stripped threads or bent nut guide. 3. Remove electrical cover and check reversing switch. 3. Remove electrical cover and check reversing switch. |
|--|--|

Hoist Does Not Respond to Pushbutton

| | |
|--|--|
| <ol style="list-style-type: none"> 1. Power failure in supply lines. 2. Wrong voltage or frequency. 3. Improper connections in hoist or pushbutton station. 4. Motor brake does not release. 5. Faulty magnetic hoist control switch. | <ol style="list-style-type: none"> 1. Check circuit breakers, switches and connections in power supply lines. 2. Check voltage and frequency of power supply against the rating on the nameplate of the hoist. 3. Check all connections at line connectors and on terminal block. Check terminal block on dual-voltage hoists for proper voltage connections. 4. Check connections to the solenoid coil. Check for open or short circuit. Check for proper adjustment. See paragraph 5-3. 5. Check coils for open or short circuit. Check all connections in control circuit. Check for burned contacts. Replace as needed. |
|--|--|

Hook Does Not Stop Promptly

| | |
|---|---|
| <ol style="list-style-type: none"> 1. Hoist Overloaded 2. Brake not holding | <ol style="list-style-type: none"> 1. Reduce load to within rated capacity of hoist. 2. Check motor brake adjustment (see paragraph 5-3) and load brake (Figure 4-4). |
|---|---|

Hook Moves in Wrong Direction

| | |
|--|--|
| <ol style="list-style-type: none"> 1. Three-phase reversal. 2. Improper connections. | <ol style="list-style-type: none"> 1. Reverse any two wires (except the green ground wire) at the power source (see paragraph 2-3). 2. Check all connections against Wiring Diagram. |
|--|--|

Hoist Hesitates to Lift When Energized

| | |
|--|---|
| <ol style="list-style-type: none"> 1. Hoist overloaded. 2. Motor brake requires adjustment. 3. Worn overload limiting clutch. 4. Low voltage. 5. Faulty SINPAC starting switch or start capacitor (single phase hoists only). | <ol style="list-style-type: none"> 1. Check circuit breakers, switches and connections in power supply. Reduce load within rated capacity of hoist. 2. Check motor brake adjustment. See Figure 5-3. 3. Replace clutch. 4. Check voltage at hoist power cord with hoist starting. Voltage should be no less than 90% of voltage specified on hoist. 5. Replace faulty component. |
|--|---|

Hook Raises But Will Not Lower (Motor not running)

| | |
|---|--|
| <ol style="list-style-type: none"> 1. "Down" circuit open. 2. Broken conductor in pushbutton cable. 3. Faulty magnetic hoist control switch. | <ol style="list-style-type: none"> 1. Check circuit for loose connections. Check "Down" limit switch for malfunction. 2. Check each conductor in the cable. If one is broken, replace entire cable. 3. Check coils for open or short circuit. Check all connections in control circuit. Check for burned contacts. Replace as needed. |
|---|--|

| TROUBLE | REMEDY |
|---------|--------|
|---------|--------|

Hook Raises But Will Not Lower When Motor is Operating.

Consult Factory Or Authorized Duff-Norton Warranty Repair Station.

Hook Lowers But Will Not Raise

| | |
|--|---|
| <ol style="list-style-type: none"> 1. Hoist overloaded. 2. Low voltage. 3. "UP" circuit open. 4. Broken conductor in pushbutton cable. 5. Faulty magnetic hoist control switch. 6. Faulty capacitor (single-phase hoists only). 7. Worn overload limiting clutch. | <ol style="list-style-type: none"> 1. Reduce load to within rated capacity. 2. Determine cause of low voltage and bring up to at least 90% of the voltage specified on hoist. Line voltage should be measured while holding or lifting load. 3. Check circuit for loose connections. Check "UP" limit switch for malfunction. 4. Check each conductor in the cable. If one is broken, replace entire cable. 5. Check coils for open or short circuit. Check all connections in control circuit. Check for burned contacts. Replace as needed. 6. Check starting capacitor in motor. Replace if necessary. 7. Replace clutch. |
|--|---|

Lack of Proper Lifting Speed

| | |
|---|--|
| <ol style="list-style-type: none"> 1. Hoist Overloaded 2. Motor brake is dragging. 3. Low voltage. 4. Overload limiting clutch intermittently slipping. | <ol style="list-style-type: none"> 1. Reduce load to within rated capacity of hoist. 2. Check for proper brake adjustment or other defects. See paragraph 5-3. 3. Bring up voltage to plus or minus 10% of voltage specified on hoist. Line voltage should be measured while hoist is lifting load. 4. Replace clutch. |
|---|--|

Load Brake "Noise" (Erratic tapping sounds or squeals)

| | |
|---|--|
| <ol style="list-style-type: none"> 1. Need transmission oil change or improper lubricant has been used. 2. Load brake malfunctioning. | <ol style="list-style-type: none"> 1. Change transmission oil. See Table 5-1. Note: Hoist Warranty is void if unapproved oil is used. 2. Check load brake operation. See paragraph 4-4. |
|---|--|

Motor Brake Noise or Chatter (While starting hoist)

| | |
|---|---|
| <ol style="list-style-type: none"> 1. Brake needs adjustment. 2. Low voltage. | <ol style="list-style-type: none"> 1. Adjust as per paragraph 5-3. 2. Check voltage at hoist power cord with hoist starting. Voltage should be no less than 90% of the voltage specified. 115 volt hoists are particularly subject to voltage drop problems due to their high current draw. Conversion to 230 volt operation is suggested in extreme cases. |
|---|---|

Motor Brake "Buzz" (Anytime hoist is running)

| | |
|--|--|
| <ol style="list-style-type: none"> 1. Brake needs adjustment. 2. Broken shading coil on brake frame. | <ol style="list-style-type: none"> 1. Adjust as per paragraph 5-3. 2. Replace shading coil or complete brake frame assembly. |
|--|--|

SECTION VII - WIRING

SAFETY NOTES

Disconnect power from hoist before removing end covers.

7-1. Voltage Conversion

Standard single phase units are convertible from 115 to 230 volts and standard single speed three phase units are convertible from 460 to 230 volts. Conversion to the alternate voltage can be accomplished with the following procedure.

- Be sure power is disconnected from hoist. Remove long end cover.
- Single Phase Hoists (With SINPAC' switch):** Transfer leads 2. H2, H3, T2, S1, and T3 per the appropriate terminal block schematic.
- Three Phase Hoists:** Transfer leads T4, T5, T6, T7, T8, T9, H2, H3, S1, and S2 per the appropriate terminal block schematic.

⚠ CAUTION

Do not move any wires or make any changes to the wiring except at the terminal block.

- After converting voltage, check for proper phasing of three phase units and check for proper limit switch operation.

7-2. Wiring Diagrams

The wiring diagrams for standard hoist models are reproduced on the following pages. In addition, every hoist should have a wiring diagram located inside the long end cover.






Figure 7-1. Wiring Diagram
 115/230V, 1 Phase, Single Speed Hoist
 with SINPAC Switch



14029


Figure 7-2. Wiring Diagram
230/460V, 3 Phase, Single Speed Hoist




14030

Figure 7-3. Wiring Diagram
208V or 575V, 3 Phase, Single Speed Hoist

| XFMR CHART |
|-----------------|
| H1-COM (BLACK) |
| H4-208V (RED) |
| H4-575V (GRAY) |
| X1-COM (BLUE) |
| X2-24V (YELLOW) |
| X2-115V (PINK) |




**Figure 7-4. Wiring Diagram
208V, 230V, 460V or 575V, 3 Phase, Two Speed Hoist**



14032

Figure 7-5. Wiring Diagram
115/230V, 1 Phase, Single Speed Hoist & Single Speed Trolley



14033

Figure 7-6. Wiring Diagram
208V, 230/460V or 575V, 3 Phase, Single Speed Hoist & Single Speed Trolley






Figure 7-7. Wiring Diagram
208V, 230V, 460V or 575V, 3 Phase, Two Speed Hoist & Single Speed Trolley



14035

Figure 7-8. Wiring Diagram
208V, 230V, 460V or 575V, 3 Phase,
Single Speed Hoist & Two Speed Trolley



**Figure 7-9. Wiring Diagram
208V, 230V, 460V or 575V, 3 Phase,
Two Speed Hoist & Two Speed Trolley**

SECTION VIII - ILLUSTRATED PARTS LIST

8-1. General

The following exploded drawings provide a complete list of parts used in the standard LEW-1 hoist models (shown in Table 1-1, page 3). Since several different models of hoists are covered by this manual, differences may be noted between the appearance of your hoist part and the reference illustration. If this is the case, the parts list will show several different part numbers with sufficient information to allow the selection of the correct part number.

8-2. How To Use The Parts List

The parts list consists of three columns as follows:

- 1) Index Number
 - 2) Part Name, and additional descriptions which are essential for choosing the correct part number when more than one is listed.
 - 3) Part Number
- b. How to determine proper part number.
- 1) Locate the index number in the corresponding figure of the parts list.
 - 2) If only one part number is listed for the index number, that part number should be ordered.
 - 3) If more than one part number is listed, the information under "part name" will determine the correct part number.

EXAMPLE

| Index No. | Part Name | Part No. |
|-----------|---|--------------------------|
| 5 | Transformer: (1PH) Pri. 115/230V, Sec. 24V 50/60 Hz Pri. 115/230V, Sec. 115V 50/60 Hz | JL-821-212 JL-821-211 |


8-3. How To Order Replacement Parts

When ordering parts or requesting information concerning your LEW-1 hoist, always include the hoist model number and serial number. Both numbers are permanently stamped on the bottom of the center frame, on the rectangular tube member.


When ordering motor parts, please provide complete motor nameplate data, including motor "ref." number or model number.

Note

Repair parts are available only from Yale distributors or authorized repair facilities. It is recommended that repair part orders be directed to the authorized repair facility near you.



14004



14005

Figure 8-1. Basic Hoist

| Index No. | Part Name | Part No. | Index No. | Part Name | Part No. |
|-----------|---------------------------------|-----------------|-----------|-----------------------------|----------|
| 1 | Brake Cover | 36J1 | 14 | Gasket, Transmission | 560J5 |
| 2 | Electrical Cover | 36J2 | 15 | Decal | 676J2-B |
| 3 | Gasket Cover | 560J4 | 16* | Decal, Power Requirements: | |
| 4 | Motor Adapter: | | | 115/230 Volt, 1 Phase | 679J1 |
| | LEW-1/2-15LG10S2, D2 & P2 | 39J3-1 | | 230/460 Volt, 3 Phase | 679J2 |
| | LEW-1/2-15LG16S2, D2 & P2 | 39J3-1 | | 230 Volt, 3 Phase | 679J3 |
| | LEW-1/2-15LG21S2, D2 & P2 | 39J3 | | 460 Volt, 3 Phase | 679J4 |
| | LEW-1/2-15LG32S2, D2 & P2 | 39J3 | | 575 Volt, 3 Phase | 679J5 |
| | LEW-1-15LG10S2, D2 & P2 | 39J3-1 | | 208 Volt, 3 Phase | 679J36 |
| | LEW-1-15LG10S2, D2 & P2 | 39J3 | 21 | Suspension Assembly: | |
| | (Single Spd) | | | 15 ft. Lift | 33JG14-1 |
| | LEW-1-15LG16S2, D2 & P2 | 39J3 | | 25 ft. Lift | 33JG15-1 |
| | (Two Speed & 1 Phase) | | | 35 ft. Lift | 33JG26-4 |
| 5 | Transmission Cover | 34J16 | | 50 ft. Lift | 33JG26-2 |
| 6 | Transmission Housing | 35J6 | | 65 ft. Lift | 33JG26-3 |
| 7 | Power Cables: | | 22 | Cover: | |
| | 1 Phase | 951KG1-15 | | 15 ft. Lift | 270J1-1 |
| | 3 Phase | 953KG1-15 | | 25 ft. Lift | 270J1-2 |
| 8 | Wiring Harness: | | | Lifts Greater Than 25 ft. | NA |
| | 15 ft. Lift, Single Speed Hoist | 940J5 | 23 | Cover: | |
| | 15 ft. Lift, Two Speed Hoist | 940J5-1 | | 15 ft. Lift | 270J2-1 |
| | 25 ft. Lift, Single Speed Hoist | 940J6 | | 25 ft. Lift | 270J2-2 |
| | 25 ft. Lift, Two Speed Hoist | 940J6-1 | | Lifts Greater Than 25 ft. | NA |
| | Lifts Greater Than 25 Ft. | Consult Factory | 24 | Screw, Covers | H-2970 |
| | | H-2923-P | 25 | Suspension Lug: | |
| 9 | Screw, End Covers | | | 15 ft. Lift | 50J31-1 |
| 10 | Decal, Capacity: | | | 25, 35, 50 & 65 ft. Lift | 50J48 |
| | 1/2 Ton | 675J2-B | 26 | Fill Plug, Vented | H-6258 |
| | 1 Ton | 675J3-B | 27 | Level Plug | S-25-13 |
| 11 | Flat Washer | H-4002-P | 28 | Cord Grip | H-7641 |
| 12 | Decal, Yale | YJL677 | 29 | Label (Lug Mount Unit Only) | 687K9 |
| 13 | Screw | H-2981-P | | | |

* Not illustrated




Figure 8-2A. Hoist Motor Parts (3 Phase)

| Index No. | Part Name | Part No. |
|-----------|---------------------------|----------|
| 1 | Motor, Complete (1/2 HP): | |
| | LEW1/2-15**10S2, D2 & P2 | |
| | LEW 1/2-15**16S2, D2 & P2 | |
| | Single Speed - 230/460V | 8637202 |
| | Single Speed - 575V | 8637205 |
| | Single Speed - 208V | 8637208 |
| | Two Speed - 230V | 8737202 |
| | Two Speed - 460V | 873J205 |
| | Two Speed - 575V | 8737208 |
| | Two Speed - 208V | 8737209 |
| | Motor, Complete (1 HP): | |
| | LEW1/2-15**32S2, D2 & P2 | |
| | LEW 1-15**16S2, D2 & P2 | |
| | Single Speed - 230/460V | 863J104 |
| | Single Speed - 575V | 863J108 |
| | Single Speed - 208V | 863J109 |
| | Two Speed - 230V | 873J104 |
| | Two Speed - 460V | 873J108 |
| | Two Speed - 575V | 873J112 |
| | Two Speed - 208V | 873J115 |

| Index No. | Part Name | Part No. |
|-----------|--|----------|
| | Motor, Complete (3/4 HP): | |
| | LEW 1/2-15**21S2, D2 & P2 | |
| | LEW 1-15**10S2, D2 & P2 | |
| | Single Speed 230/460V | 863J203 |
| | Single Speed 575V | 8637206 |
| | Single Speed 208V | 863J209 |
| | Two Speed 230V | 873J103 |
| | Two Speed 460V | 873J107 |
| | Two Speed 575V | 873J111 |
| | Two Speed 208V | 873J116 |
| 2 | Thru Bolt Contact Factory with Length Required | |
| 3 | End Shield - Contact Factory | |
| 4 | Stator - Not Available Separately | |
| 5 | Bearing | 500K3 |
| 6 | Rotor and Shaft Assembly Contact Factory with Complete Motor Nameplate Data for Availability | |
| 7 | Lock Washer | H-4082-P |




Figure 8-2B. Hoist Motor Parts (1 Phase)

Parts List for Single Phase Hoist Motor (SINPAC® Switch)

| Index No. | Part Name | Part No. |
|-----------|--|-------------------------------|
| 1 | Motor, Complete: 1/2 HP, 115/230 Volt 1 HP, 115/230 Volt 1/4 HP, 115/230 Volt | 861J222 861J124 861J123 |
| 2 | End Shield - Contact Factory | 500K3 |
| 7 | Bearing | |
| 9 | Rotor & Shaft - Contact Factory with complete nameplate data for availability | |

| Index No. | Part Name | Part No. |
|-----------|---|----------|
| 10 | Stator - Not available separately. | H-4082-P |
| 11 | Thru Bolt - Contact Factory with Length Required | |
| 12 | Lockwasher | |

14008





Figure 8-3A. Controller Area Single Phase Hoist (Only)

| Index No. | Part Name | Part No. |
|-----------|--------------------------------|-------------|
| 1 | Insulator | JF-759-3 |
| 2 | Reversing Contactor 24V Coils | JF-829-1 |
| | Reversing Contactor 115V Coils | JF-829 |
| 3 | Coil (24V) | JF-37916-25 |
| | Coil (115V) | JF-37916-32 |
| | Screw | H-2742-P |
| 5 | Transformer: | |
| | Pri.: 115/230V, Sec.: 24V | JL-821-212 |
| | Pri.: 115/230V, Sec.: 115V | JL-821-211 |
| 6 | Lockwasher | H-4158 |
| 7 | Screw | H-2751 |

| Index No. | Part Name | Part No. |
|-----------|---|----------|
| 8 | Screw | H-2752 |
| 9 | Terminal Block | 909K6 |
| 10 | Capacitor, 216-259 mfd. (1-13/16 Dia.) | JL-810-3 |
| | Capacitor, 400-480 mfd. (1-13/16 Dia.) | JL-810-4 |
| 11 | SINEPAC® Switch | 839J2 |
| 12 | Panel Plate | 257J1B |
| 13 | Screw | H-2981-P |
| 14 | Cable Tie | H-9006 |
| 15 | Bushing | H-7956 |




14009

Figure 8-3B. Controller Area Three Phase Hoist (Only)
Single or Two Speed Models

| Index No. | Part Name | Part No. |
|-----------|--------------------------------|-------------|
| 1 | Insulator | JF-759-3 |
| 2 | Reversing Contactor 24V Coils | JF-829-1 |
| 3 | Reversing Contactor 115V Coils | JF-829 |
| 4 | Coil (24V) | JF-37916-25 |
| 5 | Coil (115V) | JF-37916-32 |
| 6 | Screw | H-2742-P |
| 7 | Transformer: (Single Speed) | |
| | Pri.: 208V, Sec.: 24V | JL-821-272 |
| | Pri.: 208V, Sec.: 115V | JL-821-271 |
| | Pri.: 230/460V, Sec.: 24V | JL-821-232 |
| | Pri.: 230/460V, Sec.: 115V | JL-821-231 |
| | Pri.: 575V, Sec.: 115V | JL-821-252 |
| | Pri.: 575V, Sec.: 115V | JL-821-251 |
| | Transformer: (Two Speed) | JL-821-272 |
| | Pri.: 208V, Sec.: 24V | |
| | Pri.: 208V, Sec.: 115V | JL-821-271 |
| | Pri.: 230V, Sec.: 24V | JL-821-232 |
| | Pri.: 230V, Sec.: 115V | JL-821-231 |

| Index No. | Part Name | Part No. |
|-----------|------------------------------------|------------|
| 5 (cont.) | Transformer: (Two Speed) | |
| | Pri.: 460V, Sec.: 24V | JL-821-232 |
| | Pri.: 460V, Sec.: 115V | JL-821-231 |
| | Pri.: 575V, Sec.: 115V | JL-821-252 |
| | Pri.: 575V, Sec.: 115V | JL-821-251 |
| 6 | Lockwasher | H-4158 |
| 7 | Screw | H-2751 |
| 8 | Screw | H-2752 |
| 9 | Terminal Block (Single Speed Only) | 909K9 |
| 10 | Two Speed Models Only | |
| | Speed Relay (24V Coil) | 820J3 |
| | Speed Relay (115V Coil) | 820J4 |
| 11 | Bushing | H-7956 |
| 12 | Panel Plate | 257J1B |
| 13 | Screw | H-2981-P |



**Figure 8-3C. Controller Area
Single Speed Hoist with Single Speed Trolley
(Single or Three Phase)**

| Index No. | Part Name | Part No. |
|-----------|--------------------------------|-------------|
| 1 | Panel Plate | 257J1B |
| 2 | Reversing Contactor 24V Coils | JF-829-1 |
| | Reversing Contactor 115V Coils | JF-829 |
| 2A | Coil (24V) | JF-37916-25 |
| | Coil (115V) | JF-37916-32 |
| 3 | Transformer: | |
| | Pri.: 115/230V, Sec.: 24V | JL-821-212 |
| | Pri.: 115/230V, Sec.: 115V | JL-821-211 |
| | Pri.: 208V, Sec.: 24V | JL-821-272 |
| | Pri.: 208V, Sec.: 115V | JL-821-271 |
| | Pri.: 230/460V, Sec.: 24V | JL-821-232 |
| | Pri.: 230/460V, Sec.: 115V | JL-821-231 |
| | Pri.: 575V, Sec.: 115V | JL-821-252 |
| | Pri.: 575V, Sec.: 115V | JL-821-251 |

| Index No. | Part Name | Part No. |
|-----------|---|----------------------|
| 4 | Screw | H-2742-P |
| 5 | Lockwasher | H-4158 |
| 6 | Single Phase Only Terminal Block | 909K4 |
| 7 | Screw | H-2981-P |
| 8 | Single Phase Only (13/16" Dia.) Hoist Capacitor, 216-259 mfd. Hoist Capacitor, 400-480 mfd. | JL-810-3 JL-810-4 |
| 9 | Insulator | JF-759-3 |
| 10 | Screw | H-2752 |
| 11* | Splice Connector | H-5757 |
| 12 | Bushing | H-7956 |
| 13 | Single Phase Only Hoist SINEPAC® Switch | 839J2 |
| 14 | Cable Tie | H-9006 |

Note: See Figure 8-12B for Trolley Capacitor & Sinepac® Switch.





Figure 8-4. Hoist Transmission

14011

Figure 8-4. Hoist Transmission

| Index No. | Part Name | Part No. | Index No. | Part Name | Part No. |
|-----------|------------------------------|----------|-----------|-------------------------------|----------|
| 1 | Transmission Cover | 34J16 | 24 | Intermediate Pinion: | |
| 2 | Seal | 561K2 | | LEW1/2-15**16S2, D2 & P2 | 402J2 |
| 3 | Seal | MA-562 | | LEW1-15**16S2, D2 & P2 | 402J2 |
| 4 | Output Pinion | 404J1 | | LEW1/2-15**10S2, D2 & P2 | 402J1 |
| 5 | Output Gear Assembly | 407JG26 | | LEW1-15**10S2, D2 & P2 | 402J1 |
| 6 | Brake Disc | 580J8 | | LEW1/2-15**21S2, D2 & P2 | 402J3 |
| 7 | Pressure Plate | 576 | | LEW1/2-15**32S2, D2 & P2 | 402J3 |
| 8 | Nut | 130J3 | 25 | Retaining Ring: | |
| 9 | Ratchet and Bushing Assembly | 7JG15-2 | | LEW1/2-15**16S2, D2 & P2 | H5549 |
| 10 | Screw | H-2255 | | LEW1-15**16S2, D2 & P2 | H5549 |
| 11 | Lock Washer | H-4133 | | LEW1/2-15**10S2, D2 & P2 | H5553 |
| 12 | Dowel Pin (Housing) | H-5382 | | LEW1-15**10S2, D2 & P2 | H5553 |
| 13 | Screw (Housing) | H-2978-P | | LEW1/2-15**21S2, D2 & P2 | H5530 |
| 14 | Retaining Ring | H-5503 | | LEW1/2-15**32S2, D2 & P2 | H5530 |
| 15 | Fill Plug, Vented | H-6258 | 26* | Transmission Replacement | |
| 16 | Level Plug | S-25-13 | | Oil Kit | 14J1 |
| 17 | Gasket | 560J5 | 27 | Retaining Ring | H-5566 |
| 18 | Drain Plug | H-6268 | 28 | Output Shaft | 132J23 |
| 19 | Transmission Housing | 35J6 | 29 | Bearing | 500K29 |
| 20 | Bearing | 500K7 | 30 | Retaining Ring | H-5539 |
| 21 | Input Pinion: | | 31 | Dowel Pin (Pawl) | H-5493 |
| | LEW1/2-15 16S2, D2 & P2 | 400J1 | 32 | Bearing Adapter | 32J2 |
| | LEW1-15** 16S2, D2 & P2 | 400J1 | 33 | Bearing | 500K3 |
| | LEW1/2-15**10S2, D2 & P2 | 400J9 | 34 | Retaining Ring | H-5536 |
| | LEW1-15** 10S2, D2 & P2 | 400J9 | 35 | Screw | H-2694-P |
| | LEW1/2-15**21S2, D2 & P2 | 400J2 | 36 | Dowel Pin | H-5383 |
| | LEW1/2-15**32S2, D2 & P2 | 400J3 | 37 | Washer | H-4082-P |
| 22 | Input Gear: | | 38* | Seal Kit | 14J2 |
| | LEW1/2-15 16S2, D2 & P2 | 401J5 | | (Includes three 561 K2 seals, | S-25-4 |
| | LEW1-15**16S2, D2 & P2 | 401J5 | | one MA-562 seal and one | |
| | LEW1/2-15**10S2, D2 & P2 | 401J9 | | 560J5 gasket) | |
| | LEW1-15**10S2, D2 & P2 | 401J9 | 39 | Shipping Plug (Non-Vented) | |
| | LEW1/2-15**21S2, D2 & P2 | 400J11 | 41 | Pawl Assembly | 25JG4-2 |
| | LEW1/2-15**32S2, D2 & P2 | 401J3 | | | |
| 23 | Load Equalizer Assembly: | | | | |
| | LEW1/2-15**10S2, D2 & P2 | 591JG20 | | | |
| | LEW1/2-15**16S2, D2 & P2 | 591JG4 | | | |
| | LEW1/2-15**21S2, D2 & P2 | 591JG5 | | | |
| | LEW1/2-15**32S2, D2 & P2 | 591JG5 | | | |
| | LEW1-15**10S2, D2 & P2 | 591JG6 | | | |
| | LEW1-15**16S2, D2 & P2 | 591JG7 | | | |

* Not illustrated



14012

Figure 8-5A. Drum Area, Standard Headroom Models
2 Part Single, Parallel Mount

| Index No. | Part Name | Part No. |
|-----------|-----------------------------|----------|
| 1 | Motor Adapter: | |
| | 1/2 HP | 39J3-1 |
| | 1 HP | 39J3 |
| | 3/4 HP Single Speed 3 Phase | 39J3-1 |
| | 3/4 HP Two Speed 3 Phase | 39J3 |
| | 3/4 HP Single Phase | 39J3 |
| 2 | Transmission Housing | 35JG6 |
| 3 | Gasket | 560J12-1 |
| 4 | Gasket | 560J12-2 |
| 5 | Bearing | 500K5 |
| 6 | Drum: | |
| | 15 ft. Lift | 16JG13-1 |
| | 25 ft. Lift | 16JG13-2 |
| | 35 ft. Lift | 16JG13-9 |
| | 50 ft. Lift | 16JG13-6 |
| | 65 ft. Lift | 16JG13-8 |
| 7 | Motor Coupling: | |
| | 15 ft. Lift | 107JG7-1 |
| | 25 ft. Lift | 107JG7-2 |
| | 35 ft. Lift | 107JG7-9 |
| | 50 ft. Lift | 107JG7-6 |
| | 65 ft. Lift | 107JG7-8 |
| 8 | Suspension Assembly: | |
| | 15 ft. Lift | 33JG14-1 |
| | 25 ft. Lift | 33JG15-1 |
| | 35 ft. Lift | 33JG26-4 |
| | 50 ft. Lift | 33JG26-2 |
| | 65 ft. Lift | 33JG26-3 |

| Index No. | Part Name | Part No. |
|-----------|------------------------------------|-----------|
| 9 | Driv-Lok Pin | H-5230-5 |
| 10 | Screw, Button Head | H-2999-22 |
| 11 | Screw, Hex Head | S44-21 |
| 12 | Lock Washer | H-4066-P |
| 13 | Spring Pin | S-50-43 |
| 14 | Screw, Hex Head | S-44-41 |
| 15 | Lock Washer | H-4157 |
| 16 | Anchor Pin | 18J13 |
| 17 | Wire Rope Assembly: | |
| | 15 ft. Lift | 19J101 |
| | 25 ft. Lift | 19J102 |
| | 35 ft. Lift | 19J110 |
| | 50 ft. Lift | 19J107 |
| | 65 ft. Lift | 19J109 |
| 18 | Suspension Lug: | |
| | 15 ft. Lift | 50J31-1 |
| | 25, 35, 50 & 65 ft. Lift | 50J48 |
| 19 | Clevis Pin | 103J10 |
| 20 | Yoke - (Used on 15 ft. Lift Only) | 190111 |
| 21 | Suspension Adaptor | |
| | (Used on 25, 35, 50 & 65 ft. Lift) | 50J33 |
| 22 | Washer | H-4012-P |
| 23 | Slotted Hex Nut | H-3928-P |
| 24 | Driv-Lok Pin | H-5190 |

**Figure 8-5. Drum Area, Standard Headroom Models
2 Part Single, Parallel Mount**





Figure 8-5B. Drum Area, Low Headroom Models - 2 Part Double, Cross Mount

14015

| Index No. | Part Name | Part No. |
|-----------|-----------------------------|----------|
| 1 | Motor Adapter: | |
| | 1/2 HP | 39J3-6 |
| | 1 HP | 39J3-2 |
| | 3/4 HP Single Speed 3 Phase | 39J3-6 |
| | 3/4 HP Two Speed 3 Phase | 39J3-2 |
| | 3/4 HP Single Phase | 39J3-2 |
| 2 | Transmission Housing | 35JG6 |
| 3 | Gasket | 560J12-1 |
| 4 | Gasket | 560J12-2 |
| 5 | Bearing | 500K5 |
| 6 | Drum Assembly: | |
| | 15 ft. Lift | 16JG13-3 |
| | 30 ft. Lift | 16JG13-7 |
| 7 | Drive Coupling: | |
| | 15 ft. Lift | 107JG7-3 |
| | 30 ft. Lift | 107JG7-7 |
| 8 | Suspension Adaptor | 50J33 |
| 9 | Washer | H-4012-P |
| 10 | King Bolt | 7009J-2 |
| 11 | King Bolt | 700J9-1 |
| 12 | Pin H-5190 | |
| 13 | Screw | S-44-21 |
| 14 | Screw | S-44-23 |
| 15 | Screw | S-44-68 |
| 16 | Washer | H-4066P |
| 17 | Bolt H-2356 | |
| 18 | Nut S12-27 | |
| 19 | Washer | H-4083P |
| 20 | Pin H-5230-5 | |
| 21 | Tie Rod: | |
| | 15 ft. Lift | 931J1-3 |
| | 30 ft. Lift | 931J1-4 |
| 22 | Tie Rod Spacer: | |
| | 15 ft. Lift | 200J28-3 |
| | 30 ft. Lift | 200J28-4 |

| Index No. | Part Name | Part No. |
|-----------|---|------------|
| 23 | Tube Assembly: | |
| | 15 ft. Lift | 200JG33-1A |
| | 30 ft. Lift | 200JG33-2A |
| 24 | Coupling Guard: | |
| | 15 ft. Lift | 200J31-1 |
| | 30 ft. Lift | 200J31-2 |
| 25 | Suspension Plate | 296J8 |
| 26 | Load Pin | 103K14 |
| 27 | Nut H-3928P | |
| 28 | Pillow Block | 503J6 |
| 29 | Side Frame | 48J8 |
| 30 | Side Frame | 48J9 |
| 31 | Nut H-3945 | |
| 32 | Washer (.075 Thick) | H-4210 |
| 33 | Washer (.135 Thick) | H-4209 |
| 34 | Retaining Ring | H-5526 |
| 35 | Bushing | SK-6415-6W |
| 36 | Equalizer Sheave Assembly (Includes Index No. 37-40) | 113JG2 |
| 37 | Sheave Pin | 122J20 |
| 38 | Retaining Ring | H-5527 |
| 39 | Bushing | MA-532 |
| 40 | Sheave | 28J16 |
| 41 | Tube Assembly: | |
| | 15 ft. Lift | 200JG32-1A |
| | 30 ft. Lift | 200JG32-2A |
| 42 | Screw | S-44-169 |
| 43 | Counterweight | 52J6 |
| 44 | Wire Rope Assembly: | |
| | 15 ft. Lift | 19J303 |
| | 30 ft. Lift | 19J305 |


Figure 8-5B. Drum Area, Low Headroom Models - 2 Part Double, Cross Mount



14053

**Figure 8-5C. Drum Area, True Vertical Lift Models
2 Part Double, Parallel Mount**

| Index No. | Part Name | Part No. | Index No. | Part Name | Part No. |
|-----------|--|--|-----------|---|----------------------|
| 1 | Motor Adaptor: 1/2 HP Single Speed 3 Phase 1 HP Single Speed 3 Phase 3/4 Single Speed 3 Phase 3/4 Two Speed 3 Phase 3/4 HP Single Phase | 39J3-1 39J3 39J3-1 39J3 39J3 | 12 | Screw | S-44-21 |
| 2 | Transmission Housing | 35JG6 | 13 | Lock Washer | H-4066-P |
| 3 | Gasket | 560J12-1 | 14 | Screw | S-49-19 |
| 4 | Gasket | 560J12-2 | 15 | Pin H-5210 | |
| 5 | Bearing | 500K5 | 16 | Pin H-5230-5 | |
| 6 | Drum Assembly: 15 ft. Lift 30 ft. Lift | 16JG13-3 16JG13-7 | 17 | Suspension Assembly: 15 ft. Lift 30 ft. Lift | 33JG25-1 33JG25-2 |
| 7 | Drive Coupling: 15 ft. Lift 30 ft. Lift | 1071G7-3 107JG7-7 | 18 | Pillow Block | 503J8 |
| 8 | Suspension Lug | 50J48 | 19 | Retaining Ring | H-5526 |
| 9 | Clevis Pin | 103J10 | 20 | Bushing | SK-6415-96 |
| 10 | Support Plate | 296J9 | 21 | Equalizer Sheave Assembly (Includes Index No. 22-25) | 113JG2 |
| 11 | Screw | H2999-22 | 22 | Sheave Pin | 122J20 |
| | | | 23 | Retaining Ring | H-5527 |
| | | | 24 | Bushing | MA-532 |
| | | | 25 | Sheave | 28J16 |
| | | | 26 | Wire Rope Assembly: 15 ft. Lift 30 ft. Lift | 19J303 19J305 |




14013

Figure 8-6A. Limit Switch Parts (All Lifts Except 65 Ft.)

| Index No. | Part Name | Part No. |
|-----------|---|----------|
| 1 | Limit Switch & Shaft Assembly (Consists of Index Nos. 4 thru 12) | 918JG7 |
| 4 | Limit Switch Bracket Assembly (Includes Index No. 5) | JF-900-3 |
| 5 | Limit Switch Bushing | JF-531-4 |
| 6 | Microswitch, Limit | 815J1 |
| 7 | Screw | H-1402-P |

| Index No. | Part Name | Part No. |
|-----------|--------------------------|------------|
| 8 | Nut | H-3944 |
| 9 | Limit Switch Shaft | JF-117-3 |
| 10 | Limit Switch Nut (Brass) | SK6000-63W |
| 11 | Limit Switch Nut (Zinc) | SK6000-63Z |
| 12 | Retaining Ring | H-5520 |
| 13 | Spring | JF-343-3 |
| 14 | Screw | H-2694-P |




14014

Figure 8-6B. Long Lift Limit Switch Parts (Used on 65 Ft. Lift Only)

| Index No. | Part Name | Part No. |
|-----------|---|------------|
| 1 | Long Lift Limit Switch Assembly (all items except No.19) | 944JG6WR |
| 2 | Mounting Plate | 129J1 |
| 3 | Thrust Washer | 255K16 |
| 4 | Spring | P8-287 |
| 5 | Zinc Nut | SK6000-63Z |
| 6 | Brass Nut | SK6000-63W |
| 7 | Shaft and Gear Assembly | 117JG2 |
| 8 | Bushing | JF-531-4 |
| 9 | End Plate | 258J8 |
| 10 | Lock Washer | H-4158 |

| Index No. | Part Name | Part No. |
|-----------|--------------------------|----------|
| 11 | Screw | H-2741-P |
| 12 | Switch | 815J1 |
| 13 | Locknut | H-3944 |
| 14 | Drive Pinion | 427J1 |
| 15 | Frame and Guide Assembly | 258JG7 |
| 16 | Screw | H-1402-P |
| 17 | Screw | 854823 |
| 18 | Retaining Ring | H-5520 |
| 19 | Mounting Screw | H-2981-P |
| 20 | Flat Head Screw | H-1210 |
| 21 | Post | 110J14 |




14037

Figure 8-7. Motor Brake Parts

| Index No. | Part Name | Part No. | Index No. | Part Name | Part No. |
|-----------|---|--|-----------|----------------------------------|----------|
| 1 | Disc Brake Assembly: LEW-½-15**10S2, D2 & P2 (½ HP) LEW-½-15**16S2, D2 & P2 (½ HP) Single Speed 115-230V 230/460V 575V 208V Two Speed 230V 460V 575V 208V Other LEW Models (¾ & 1 HP) Single Speed 115/230V 230/460V 575V 208V Two Speed 230V 460V 575V 208V | 854JG6 854JG7 854JG9 854JG10 854JG7 854JG8 854JG9 854JG10 854JG1 854JG2 854JG4 854JG5 854JG2 854JG3 854JG4 854JG5 | 3 | Plate & Armature Assembly | 858JG1 |
| | | | 4 | Plate & Stud Assembly | 859JG1 |
| | | | 5 | Brake Plate | 291J1 |
| | | | 6 | Spring | 344J6 |
| | | | 7 | Brake Disc | 581J1A |
| | | | 8 | Retainer | JF-710 |
| | | | 9 | Locking Nut | H-3978 |
| | | | 10 | Coil: | |
| | | | | 115V (For Brake 854JG6, 854JG1) | JF-853-1 |
| | | | | 230V (For Brake 854JG7, 854JG2) | JF-853-2 |
| | | | | 460V (For Brake 854JG8, 854JG3) | JF-853-3 |
| | | | | 575V (For Brake 854JG9, 854JG4) | JF-853-4 |
| | | | | 208V (For Brake 854JG10, 854JG5) | JF-853-5 |
| | | | 11 | Spacer (1/2 HP Models Only) | 141J2 |
| | | | 12 | Screw | H-2976-P |
| | | | 13 | Brake Adapter | 142J1 |
| | | | 14 | Retaining Ring | H-5501 |
| | | | 15 | Transmission Cover | 34J16 |
| | | | | (Reference - Figure 8-1) | |
| | | | 16** | Shading Coil Element | 860J1 |
| | | | 17* | Adhesive (1 oz. Tube) | H-7812 |
| | | | 18 | Decal, Load Equalizer | 676J1 |
| | | | 19 | Lock Washer | H-4134 |
| | | | 20 | Bearing Adapter | 32J2 |
| | | | | (Reference - See Figure 8-4) | |
| 2 | Plate & Frame Assembly | 857JG1 | | | |

* Not illustrated

** Replacement requires use of adhesive



14038

Figure 8-8A. Pushbutton (Single Speed Hoists)

| Index No. | Part Name | Part No. | Index No. | Part Name | Part No. |
|-----------|--|---|-----------|-----------------------|----------|
| 1 | Pushbutton and Cable Assembly: (Consists of Index Nos. 2 thru 25) PB Drop Length: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop Length | PB-299-11 B PB-299-21 B PBS-299-26B PB-299-31B PBS-299-46B PBS-299-61B PBS-299-*B JF-761 | 6 | Cover | PB-298 |
| 2 | Rubber Grommet | | 7 | Pushbutton | PB-284-2 |
| 3 | Pushbutton Cable Assembly: PB Drop Length: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop Length | PB-299-11 PB-299-21 PBS-299-26 PB-299-31 PBS-299-46 PBS-299-61 PBS-299-* | 8 | Interlock | PB-285 |
| 4 | Pushbutton Assembly: (Consist of Index Nos. 5 thru 25) | 534K97-B | 9 | Boot | PB-286 |
| 5 | Enclosure | PB-282-4 | 10 | Spring, Compression | PB-287 |
| | | | 11 | Spring, Conical | PB-288 |
| | | | 12 | Contact Plate | PB-289 |
| | | | 13 | Contact Plate, Common | PB-290 |
| | | | 14 | Washer, Contact | PB-291 |
| | | | 15 | Screw | PB-301 |
| | | | 16 | Washer, Boot | PB-293 |
| | | | 17 | Grommet | PB-294-1 |
| | | | 18 | Cap, Enclosure | PB-295 |
| | | | 19 | "O" Ring | X-6477-1 |
| | | | 20 | Rubber Seal | H-7851 |
| | | | 21 | Screw | H-2991 |
| | | | 22 | Screw | H-2992 |
| | | | 23 | Screw | H-2993 |
| | | | 24 | Warning Tab | PB-296 |
| | | | 25 | Lock Washer | H-4160 |

* Equal to Pushbutton Drop





Figure 8-8B. Pushbutton (Two Speed Hoists)

| Index No. | Part Name | Part No. |
|-----------|--|--|
| 1 | Pushbutton and Cable Assembly: (Consists of Index Nos. 2 thru 31) PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | 534JG4-11 534JG4-21 534JG4-26 534JG4-31 534JG4-46 534JG4-61 534JG4-* |
| 2 | Rubber Grommet | JF-761 |
| 3 | Pushbutton Cable Assembly: PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | PB-300-11 PB-300-21 PBS-300-26 PB-300-31 PBS-300-46 PBS-300-61 PBS-300-* |
| 4 | Pushbutton Assembly: (Consist of Index Nos. 5 thru 31) | 534JG4 |
| 5 | Enclosure | PB-282-4 |
| 6 | Cover | PB-298 |

| Index No. | Part Name | Part No. |
|-----------|-----------------------|-----------|
| 7 | Pushbutton | PB-284-22 |
| 8 | Interlock | PB-285-1 |
| 9 | Boot | PB-286 |
| 10 | Spring, Compression | PB-287 |
| 11 | Spring, Conical | PB-288 |
| 12 | Contact Plate | PB-289 |
| 13 | Contact Plate, Common | PB-290 |
| 14 | Washer, Contact | PB-291 |
| 15 | Screw | H-1852-P |
| 16 | Washer, Boot | PB-293 |
| 17 | Grommet | PB-294-1 |
| 18 | Cap, Enclosure | PB-295 |
| 19 | "O" Ring | X-6477-1 |
| 20 | Rubber Seal | H-7851 |
| 21 | Screw (Enclosure) | H-2925 |
| 22 | Screw (Cap) | H-2992 |
| 23 | Screw (Plates) | H-2993 |
| 24 | Warning Tab | PB-296 |
| 25 | Lock Washer | H-4160 |
| 26 | 2-Speed Adapter | PB-308 |
| 27 | Insulating Bushing | 755J1 |
| 28 | Spring, Lower | 344J5 |
| 29 | Contact Button | 201J1 |
| 30 | Bushing | 200J16 |
| 31 | Jumper Wire | JF-940-42 |

* Equal to Pushbutton Drop

Figure 8-8B. Pushbutton (Two Speed Hoists)



14040

Figure 8-8C. Pushbutton (Single Speed Hoist - Single Speed Trolley)

| Index No. | Part Name | Part No. |
|-----------|--|---|
| 1 | Pushbutton and Cable Assembly: (Consists of Index Nos. 2 thru 27) PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | PB-300-11A PB-300-21A PBS-300-26A PB-300-31A PBS-300-46A PBS-300-61A PBS-300-*A JF-761 |
| 2 | Rubber Grommet | |
| 3 | Pushbutton Cable Assembly: PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | PB-300-11 PB-300-21 PBS-300-26 PB-300-31 PBS-300-46 PBS-300-61 PBS-300-* |
| 4 | Pushbutton Assembly: (Consist of Index Nos. 5 thru 27) | 534K98 |
| 5 | Enclosure | PB-282-4 |
| 6 | Cover | PB-283 |

| Index No. | Part Name | Part No. |
|-----------|-----------------------|-----------|
| 7 | Pushbutton (Hoist) | PB-284-2 |
| 8 | Interlock | PB-285 |
| 9 | Boot | PB-286 |
| 10 | Spring, Compression | PB-287 |
| 11 | Spring, Conical | PB-288 |
| 12 | Contact Plate, Common | PB-290 |
| 13 | Contact Plate | PB-289 |
| 14 | Washer, Contact | PB-291 |
| 15 | Screw | PB-301 |
| 16 | Washer, Boot | PB-293 |
| 17 | Grommet | PB-294-2 |
| 18 | Cap, Enclosure | PB-295 |
| 19 | "O" Ring | X-6477-1 |
| 20 | Seal | H-7851 |
| 21 | Screw | H-2991 |
| 22 | Screw | H-2992 |
| 23 | Screw | H-2993 |
| 24 | Warning Tab | PB-296 |
| 25 | Lock Washer | H-4160 |
| 26 | Jumper (Common) | JF-940-42 |
| 27 | Pushbutton (Trolley) | PB-284-1 |

* Equal to Pushbutton Drop

Figure 8-8C. Pushbutton (Single Speed Hoist - Single Speed Trolley)




Figure 8-8D. Pushbutton
(Two Speed Hoist, Single Speed Trolley;
Single Speed Hoist, Two Speed Trolley)

14041

**Figure 8-8D. Pushbutton
(Two Speed Hoist, Single Speed Trolley;
Single Speed Hoist, Two Speed Trolley)**

| Index No. | Part Name | Part No. |
|-----------|---|---|
| 1 | Pushbutton and Cable Assembly: (Consists of Index Nos. 2 thru 34) Two Speed Hoist, Single Speed Trolley PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop Single Speed Hoist, Two Speed Trolley PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | 534JG5-11 534JG5-21 534JG5-26 534JG5-31 534JG5-46 534JG5-61 534JG5-* |
| 2 | Rubber Grommet | JF-761-1 |
| 3 | Pushbutton Cable Assembly: PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | PB-309-11 PBS-309-21 PBS-309-26 PB-309-31 PBS-309-46 PBS-309-61 PBS-309-* |
| 4 | Pushbutton Assembly: (Consist of Index Nos. 5 thru 34) Two Speed Hoist, Single Speed Trolley Single Speed Hoist, Two Speed Trolley | 534JG5 534JG6 |

| Index No. | Part Name | Part No. |
|-----------|-----------------------|-----------|
| 5 | Enclosure | PB-282-4 |
| 6 | Cover | PB-283 |
| 7 | Pushbutton (Hoist) | PB-284-22 |
| 8 | Interlock (Black) | PB-285-1 |
| 9 | Boot | PB-286 |
| 10 | Spring, Compression | PB-287 |
| 11 | Spring, Conical | PB-288 |
| 12 | Contact Plate, Common | PB-290 |
| 13 | Contact Plate | PB-289 |
| 14 | Washer, Contact | PB-291 |
| 15 | Screw | H-1852-P |
| 16 | Washer, Boot | PB-293 |
| 17 | Grommet | PB-294-2 |
| 18 | Cap, Enclosure | PB-295 |
| 19 | "O" Ring | X-6477-1 |
| 20 | Seal | H-7851 |
| 21 | Screw | H-2925 |
| 22 | Screw | H-2992 |
| 23 | Screw | H-2993 |
| 24 | Warning Tab | PB-296 |
| 25 | Lock Washer | H-4160 |
| 26 | Jumper | 940J111 |
| 27 | Pushbutton (Trolley) | PB-284-21 |
| 28 | Spacer | 755J2 |
| 29 | Spring, Lower | 344J5 |
| 30 | Insulating Bushing | 755J1 |
| 31 | Lower Contact | 201J1 |
| 32 | Bushing | 200J16 |
| 33 | Two-Speed Adapter | PB-308 |
| 34 | Interlock (Red) | PB-285 |

* Equal to Pushbutton Drop





Figure 8-8E. Pushbutton (Two Speed Hoist - Two Speed Trolley)

| Index No. | Part Name | Part No. |
|-----------|--|---|
| 1 | Pushbutton and Cable Assembly: (Consists of Index Nos. 2 thru 33) PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | 534JG7-11 534JG7-21 534JG7-26 534JG7-31 534JG7-46 534JG7-61 534JG7-* |
| 2 | Rubber Grommet | JF-761-1 |
| 3 | Pushbutton Cable Assembly: PB Drop In Feet: 11 Ft. 21 Ft. 26 Ft. 31 Ft. 46 Ft. 61 Ft. Special PB Drop | PB-309-11 PB-309-21 PBS-309-26 PBS-309-31 PBS-309-46 PBS-309-61 PBS-309-* |
| 4 | Pushbutton Assembly: (Consist of Index Nos. 5 thru 33) | 534JG7 |
| 5 | Enclosure | PB-282-4 |
| 6 | Cover | PB-283 |
| 7 | Pushbutton (Hoist) | PB-284-22 |

| Index No. | Part Name | Part No. |
|-----------|---------------------------|-----------|
| 8 | Interlock (Black) | PB-285-1 |
| 9 | Boot | PB-286 |
| 10 | Spring, Compression | PB-287 |
| 11 | Spring, Conical | PB-288 |
| 12 | Contact Plate, Common | PB-290 |
| 13 | Contact Plate | PB-289 |
| 14 | Washer, Contact | PB-291 |
| 15 | Screw | H-1852-P |
| 16 | Washer, Boot | PB-293 |
| 17 | Grommet | PB-294-2 |
| 18 | Cap, Enclosure | PB-295 |
| 19 | "O" Ring | X-6477-1 |
| 20 | Seal | H-7851 |
| 21 | Screw | H-2925 |
| 22 | Screw | H-2992 |
| 23 | Screw | H-2993 |
| 24 | Warning Tab | PB-296 |
| 25 | Lock Washer | H-4160 |
| 26 | Jumper | 940J111 |
| 27 | Pushbutton (Trolley) | PB-284-21 |
| 28 | Jumper (Two-Speed Common) | JF-940-42 |
| 29 | Insulating Bushing | 755J1 |
| 30 | Spring, Lower | 344J5 |
| 31 | Lower Contact | 201J1 |
| 32 | Bushing | 200J16 |
| 33 | Two-Speed Adapter | PB-308 |

* Equal to Pushbutton Drop

Figure 8-8E. Pushbutton (Two Speed Hoist - Two Speed Trolley)




14043

Figure 8-9A. Bottom Block, Standard Headroom Models

| Index No. | Part Name | Part No. |
|-----------|---|-----------------|
| 1 | Bottom Block Assembly, Complete (Consists of Index Nos. 2 thru 11) | 30KG28 100K2 |
| 2 | Bottom Block Shaft | |
| 3 | Spring Pin | H-5235 |
| 4 | Side Frame | 30K1 |
| 5 | Sheave Assembly (Includes Bearing) | 28KG1 |
| 6 | Sheave | 28K1 |
| 7 | Bearing | 521K1 |

| Index No. | Part Name | Part No. |
|-----------|----------------------------|----------|
| 8 | Thrust Washer | CB-255 |
| 9 | Allen head Screw | S-49-19 |
| 10 | Lock Washer | H-4139 |
| 11 | Hook Assembly with Latch | 3JG20S |
| 12 | Latch Kit | H-7540 |
| 13 | Capacity Plate: 1/2 Ton | 675K26 |
| | 1 Ton | 675K28 |
| 14 | Drive Rivet | H-2861-P |




14044

Figure 8-9B. Bottom Block, Low Headroom & True Vertical Lift Models

| Index No. | Part Name | Part No. |
|-----------|---|----------|
| 1 | Bottom Block Assembly, Complete (Consists of Index Nos. 2 thru 12) | 914JG27 |
| 2 | Sheave | 28K1 |
| 3 | Bushing | 530K14 |
| 4 | Yoke | 122J19 |
| 5 | Bearing | JF-510 |
| 6 | Shank Extension | 124J11 |
| 7 | Hook & Latch Assembly | 3J20S |
| 8 | Driv-Lok Pin (3/16 x 1-1/4) | H-5219 |

| Index No. | Part Name | Part No. |
|-----------|----------------------------|----------|
| 9 | Slotted Nut | H-3986-P |
| 10 | Driv-Lok Pin (3/16 x 7/8) | H-5159 |
| 11 | Cover | 30J24 |
| 12 | Spring Pin | H-5260 |
| 13 | Latch Kit | H-7540 |
| 14 | Capacity Plate: 1/2 Ton | 675K26 |
| | 1 Ton | 675K28 |
| 15 | Drive Rivet | H-2861-P |



14045

Figure 8-10A. Motorized Trolley
(Single Speed Hoist, Single Speed Trolley)

| Index No. | Part Name | Part No. |
|-----------|----------------------------------|-----------------|
| 1 | Pin, Load | 103K1 |
| 2 | Washer (1/8 thick) | H-4211 |
| 3 | Washer (10 gal.) | H-4209 |
| 4 | Washer (14 gal.) | H-4210 |
| 5 | Pinion | 420K1 |
| 6 | Ring, Retaining | H-5501 |
| 7 * | Cable Assembly, Tie 15 ft. Lift: | |
| | 3-Phase, All HP | 955JG33 |
| | Single Phase, 1/2 HP | 955JG31 |
| | Single Phase, 3/4 & 1 HP | 955JG35 |
| | 25 ft. Lift: | 955JG34 |
| | 3-Phase, All HP | |
| | Single Phase, 1/2 HP | 955JG32 |
| | Single Phase, 3/4; 1 HP | 955JG36 |
| 8 * | Lifts Greater Than 25 ft. | Consult Factory |
| | Cap, Splice | H-7519 |

| Index No. | Part Name | Part No. |
|-----------|-----------------------|----------|
| 9* | Insulator, Splice Cap | H-7520 |
| 10 | Nut, Elastic Stop | H-3945 |
| 11 | Wheel: | |
| | Plain | 45K10 |
| | Drive | 45K1 |
| 12 | Axle102K1 | |
| 13 | Spacer | 200K1 |
| 14 | Bearing | 500K4 |
| 15 | Ring, Retaining | H-5528 |
| 16 | Washer (1/8 thick) | H-4211 |
| 17 | Gear | 420K2 |
| 18 | Pin, Dowel | H-5531 |
| 19 | Screw, Machine | H-2165 |
| 20* | Decal Coffing | 677J7 |
| 22 | Side Plate Weldment | 5KG4 |

* Not Shown





Figure 8-11. Trolley Transmission

| Index No. | Part Name | Part No. |
|-----------|-----------------|-----------|
| 1 | Retaining Ring | SK2658-6W |
| 2 | Retaining Ring | H-5549 |
| 3 | Bearing | JF-504-2 |
| 4 | Worm: | |
| | 35 FPM | 485K21 |
| | 75 FPM | 485K22 |
| 5 | Bearing | 500K3 |
| 6 | Gear Housing | 39K22 |
| 7 | Plug | S-25-13 |
| 9 | Screw | H-2215 |
| 10 | Adapter Housing | 38K60A |
| 11 | Gasket | 560K2 |
| 13 | Gasket | 560K3 |

| Index No. | Part Name | Part No. |
|-----------|----------------|----------|
| 14 | Splice Plate | 295K1 |
| 15 | Screw | H-1009-P |
| 16 | Shaft | 100K12 |
| 17 | Woodruff Key | S-23-15 |
| 18 | Retaining Ring | H-5527 |
| 19 | Worm Gear: | |
| | 35 FPM | 487K4 |
| | 75 FPM | 487K3 |
| 20 | Shim Washer | 202K1 |
| 21 | "O" Ring | H-5069 |
| 22 | End Cap | 32K3 |
| 23 | Lockwasher | H-4084P |
| 24 | Bearing | 500K7 |




**Figure 8-12A. Trolley Motor Parts
(3 Phase, Single and Two Speeds)**

| Index No. | Part Name | Part No. |
|-----------|---------------------------|-----------|
| 1 | Motor Complete: | JL-863-1M |
| | Single Speed | |
| | 208, 230/460V, 3-PH, | |
| | 60 Hz, 1/4 HP | |
| | 575V, 3-PH, 60Hz, 1/4 HP | JL-863-5M |
| | Two Speed | JL-873-1M |
| | 208, 230V, 3-PH, | |
| | 60Hz, 1/4 HP | |
| | 460V, 3-PH, 60 Hz, 1/4 HP | JL-873-5M |
| | 575V, 3-PH, 60 Hz, 1/4 HP | JL-873-9M |

| Index No. | Part Name | Part No. |
|-----------|-----------------------------------|----------|
| 2 | Stator (Not Available Separately) | |
| 3 | Rotor & Shaft | |
| 4 | End Shield | |
| 5 | Bearing | |
| 6 | Ring, Retaining | |
| 7 | Screw, Motor Mount | |
| 8 | Lock Washer | |

* For individual motor parts, contact your Yale Lift-Tech Distributor and supply complete motor nameplate data.



14048

**Figure 8-12B. Trolley Motor Parts
(1 Phase, Single Speed)**

| Index No. | Part Name | Part No. |
|-----------|---|------------|
| 31 | Motor, Complete: 1/2 HP, 115/230V, 60 Hz | JL-861-12 |
| 31 | Motor, Complete: HP, 115/230V, 60 Hz | JL-861-11M |
| 32 | Stator- (Not Available Separately) | — |
| 33 | Rotor & Shaft Assembly: 1/2 HP, 115/230V, 60 Hz 1/4 HP, 115/230V, 60 Hz | * |
| 34 | End Shield | * |
| 35 | Bearing | 500K3 |
| | Capacitor: | |
| 38 | 1/2 HP | * |
| 38 | 1/2 HP | * |

| Index No. | Part Name | Part No. |
|-----------|-----------------|----------|
| 39 | Capacitor Cover | * |
| 40 | Screw | * |
| 42 | Rear Bearing | 732012 |
| 43 | Nut Flange | * |
| 44 | Screw | * |
| 45 | Lock Washer | H-4062-P |
| 46 | Screw | * |
| 48 | Shim Washer | * |
| 49 | SINPAC® Switch | 839J2 |
| 50 | Cover | * |
| 51 | Screw | * |

* Contact factory with complete electric motor nameplate data.




Figure 8-13A. Trolley Controls
(Single Speed or Two Speed Trolleys)

| Index No. | Part Name | Part No. |
|-----------|-----------------------------|-------------|
| 1 | Screw | H-2742-P |
| 2 | Contactor (24V Coils) | JF-829-1 |
| | Contactor (115V Coils) | JF-829 |
| 2A | Coil (24V) | JF-37916-25 |
| | Coil (115V) | JF-37916-32 |
| 3 | Insulator | JF-759-3 |
| 4 | Lockwasher | H-4158 |
| 5 | Transformer: (Single Speed) | |
| | Pri.: 230/460V, Sec.: 24V | JL-821-432 |
| | Pri.: 230/460V, Sec.: 115V | JL-821-431 |
| | Pri.: 575V, Sec.: 115V | JL-821-452 |
| | Pri.: 575V, Sec.: 115V | JL-821-451 |
| | Pri.: 208V, Sec.: 24V | JL-821-472 |
| | Pri.: 208V, Sec.: 115V | JL-821-471 |

| Index No. | Part Name | Part No. |
|-----------|-------------------------------|------------|
| 5 (cont.) | Transformer: (Two Speed) | |
| | Pri.: 230 or 460V, Sec.: 24V | JL-821-432 |
| | Pri.: 230 or 460V, Sec.: 115V | JL-821-431 |
| | Pri.: 575V, Sec.: 115V | JL-821-452 |
| | Pri.: 575V, Sec.: 115V | JL-821-451 |
| | Pri.: 208V, Sec.: 24V | JL-821-472 |
| | Pri.: 208V, Sec.: 115V | JL-821-471 |
| 6 | Screw | H-2752 |
| 7 | Speed Relay (Two Speed) | |
| | Speed Relay (24V Coil) | 820J3 |
| | Speed Relay (115V Coil) | 820J4 |
| 8 | Speed Relay (24V Coil) | 257K615 |
| 9 | Control Box | 260K100-1 |




Figure 8-14. Two-Wheel Trolley

| Index No. | Part Name | Part No. |
|-----------|---|----------|
| 1 | Side Plate | 5K56 |
| 2 | Load Pin | 103K1 |
| 3 | Washer (1/8 thick) | H-4211 |
| 4 | Washer (10 ga.) | H-4209 |
| 5 | Washer (14 ga.) | H-4210 |
| 6 | Nut | H-3945 |
| 7 | Suspension Box (Ref. See Figure 8-5) | 50J33 |
| 8 | Axle | 102K1 |
| 9 | Spacer | 200K1 |
| 10 | Retaining Ring | H-5528 |
| 11 | Bearing | 500K4 |
| 12 | Wheel | 45K10 |




Figure 8-15. Geared Trolley

| Index No. | Part Name | Part No. |
|-----------|-----------------------------|----------|
| 1 | Ring, Retaining | H-5501 |
| 2 | Pinion | 420K1 |
| 3 | Spacer Bearing | 525K2 |
| 4 | Gear Shaft | 100K14 |
| 5 | Sleeve & Adapter Assembly | 51KG1 |
| 6 | Spacer Bearing | 525K1 |
| 7 | Hand-Chain Wheel | 33K23 |
| 8 | Hand-Chain (Specify Length) | 53A |
| 9 | Retaining Ring | H-5527 |
| 10 | Sleeve Bushing | 530K6 |




Figure 8-16. Current Collector Group

| Index No. | Part Name | Part No. |
|-----------|---|----------|
| 1 | Swivel Collector Assembly: Insul-8 Type | 804K1 |
| 2 | Brace Plate | 802K12 |
| 3 | Plate, Mounting | 802K1 |
| 4 | Arm, Mounting (20" long) | 803KG8 |
| 5 | Shackle, Mounting | 806K1 |
| 6 | Lock Washer | H-3561-P |
| 7 | Nut H-3561 | |
| 8 | Collector Arm Kit Includes Index No's 2 thru 7 | CCK2 |

[illegible]

Note: When ordering parts always furnish Model and Catalog Number of Hoist and lift of hoist on which the parts are to be used.

Parts for your hoist are available from your local authorized **Yale** repair station.
For the location of your nearest repair station, write:

IN USA

Yale•Lift-Tech

P.O. Box 769

Muskegon, MI 49443-0769

Phone: **800 742-9269**

Fax: **800 742-9270**



⚠ WARNING

To prevent personal injury, do not use the equipment shown in this manual to lift, support or otherwise transport people, or to suspend unattended loads over people.

WARRANTY

WARRANTY AND LIMITATION OF REMEDY AND LIABILITY

A. Seller warrants that its products and parts, when shipped, and its work (including installation, construction and start-up), when performed, will meet applicable specifications, will be of good quality and will be free from defects in material and workmanship. All claims for defective products or parts under this warranty must be made in writing immediately upon discovery and in any event, within one (1) year from shipment of the applicable item unless Seller specifically assumes installation, construction or start-up responsibility. All claims for defective products or parts when Seller specifically assumes installation, construction or start-up responsibility and all claims for defective work must be made in writing immediately upon discovery and in any event, within one (1) year from completion of the applicable work by Seller, provided; however, all claims for defective products and parts made in writing no later than eighteen (18) months after shipment. Defective items must be held for Seller's inspection and returned to the original f.o.b. point upon request. THE FOREGOING IS EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES WHATSOEVER, EXPRESS, IMPLIED AND STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS.

B. Upon Buyer's submission of a claim as provided above and its substantiation, Seller shall at its option either (i) repair or replace its product, part or work at either the original f.o.b. point of delivery or at Seller's authorized service station nearest Buyer or (ii) refund an equitable portion of the purchase price.

C. This warranty is contingent upon Buyer's proper maintenance and care of Seller's products, and does not extend to normal wear and tear. Seller reserves the right to void warranty in event of Buyer's use of inappropriate materials in the course of repair or maintenance, or if Seller's products have been dismantled prior to submission to Seller for warranty inspection.

D. The foregoing is Seller's only obligation and Buyer's exclusive remedy for breach of warranty and is Buyer's exclusive remedy hereunder by way of breach of contract, tort, strict liability or otherwise. In no event shall Buyer be entitled to or Seller liable for incidental or consequential damages. Any action for breach of this agreement must be commenced within one (1) year after the cause of action has accrued.