


**RT SERIES
TROLLEYS**

**PARTS AND INSTRUCTION
MANUAL**

Yale



JULY 1984

MECHANICAL INSTALLATION

Trolley To Beam

Place the nuts on one end of the suspension bolts. Arrange the sideplates, and spacers on the bolts according to Fig. 1 and Table 1 for the proper beam size. Assemble the Trolley on beam by sliding one sideplate out far enough to allow the wheel to clear the beam flange. Draw the side sideplates together, assemble the additional spacers and nuts. Tighten nuts to 175 ft/lbs. torque.

TABLE 1

I-BEAM		NO. OF SPACERS			
SIZE	FLANGE	A	B	C	D
6" x 12.5	3 3/8	9	3	4	8
6" x 17.2	3 5/8	8	4	4	8
7" x 15.3	3 5/8	8	4	4	8
7" x 20.0	3 7/8	7	5	5	7
8" x 18.4	4	7	5	6	6
8" x 23.0	4 1/8	6	6	6	6
10" x 25.4	4 5/8	5	7	8	4
10" x 35.0	5	4	8	9	3
12" x 31.8	5	4	8	9	3
12" x 35.0	5 1/8	3	9	9	3
12" x 40.8	5 1/4	3	9	10	2
12" x 50.0	5 1/2	2	10	10	2
15" x 42.9	5 1/2	2	10	10	2
15" x 50.0	5 5/8	2	10	11	1
18" x 54.7	6	0	12	12	0

WARNING: Deviation from washer adjustment recommendations could cause the trolley to fall from the beam. The trolley should be inspected periodically to assure its continued safe operation. The number of spacers indicated is nominally correct. However, due to variations in structural steel, it may be necessary to vary the number used.

THE DISTANCE BETWEEN TRACK WHEEL FLANGES SHOULD BE 1/8" TO 3/16" GREATER THAN THE WIDTH OF THE BEAM FLANGE FOR STRAIGHT RUNWAYS, AND 3/16" TO 1/4" GREATER FOR RUNWAYS THAT INCLUDE SHARP CURVES.

When used on monorail with curves lightly lubricate edges of beam at curve section with grease.




FIG. 1

ELECTRICAL INSTALLATION

Be sure all power is disconnected before starting any electrical work.

POWER CORD TO HOIST

A short length of power cord is installed in the trolley control box (Fig. 1). Remove 4 inches of the outer jacket and strip each wire 3/8 inches. Insert the cord into the power cord entrance on the hoist. Connect the green wire to the ground lug and the line wires to the "L" terminals.

CAUTION:

Before connecting power to the trolley, be sure the power supply corresponds to the ratings of the trolley and of the hoist. If necessary, reconnect the trolley motor and transformer of dual voltage units according to the wiring diagram, using the terminals and jumpers provided in the field wiring kit.

A three phase motor can rotate in either direction depending on its connection to the power line. If the direction of hook travel of a three phase hoist does not match the push button markings, interchange any two of the line wires at the terminal strip. **DO NOT** rewire the push button.


PENDANT LENGTH CHANGE

If it is necessary to lengthen the pendant, the cord and strain relief cable must be replaced. The necessary parts can be obtained from your Yale dealer or service center. Use the old cord as a guide for cutting and installing the new cord. Be sure to observe the correct color code of the wires. The pendant cord must be slightly longer than the strain relief cable to prevent strain on the electrical wires and connections.

The pendant can be shortened simply by loosening the clamp on the strain relief cable at the control box, and shortening the strain relief cable. The pendant cord need not be shortened unless the extra slack in the cord causes interference with moving parts. If it is necessary to shorten the cord, be sure to observe the correct color code when reconnecting the wires.

DUAL CONTROL STATION ASSEMBLY

If desired, the two button control stations furnished with the Trolley and Hoist can be joined into a single rigid unit, as shown in Fig. 2, using the bracket furnished with the Trolley.



**PUSH BUTTON
FIGURE 2**

To install the bracket, loosen the clamping nut on cord fitting on hoist push button station. Unscrew the fitting from the station and slide it up the cord a few inches. Locate the bracket so that it will be locked in place by the suspension bracket. Replace the fitting in the station and tighten it on the cord.

FOR TROLLEYS FURNISHED WITH 4 BUTTON STATIONS:

Cut the hoist push button cord 42 inches from the bottom of the hoist. Remove and discard the strain relief rope. Remove 4 inches of the outer jacket and strip each wire 3/8 inches. Install the cord in the trolley control box as shown in Figure 3. Connect the green wire to the ground lug, the red wire to terminal (15), the blue wire to terminal (H6) and the black wire to terminal (L). For two speed hoist only, connect the orange wire to terminal (28) and the blue wire to terminal (29).




FIG. 3

OPERATING AND SAFETY PROCEDURES

Immediately after installation, operate trolley according to the operating and safety procedures as follows, with a capacity load over the entire length of runway or monorail system to be sure that all adjustments and operations are satisfactory.

Rail stops must be installed for all trolleys operating on open end beams. These stops must be positioned to exert impact force on the trolley side frames only.

When preparing to lift a load, be sure that the attachments to the hook are firmly seated in hook saddle. Avoid off center loading of any kind, especially loading on the point of hook.

When lifting, raise the load only enough to clear the floor or support and check to be sure that the attachments to hook and load are firmly seated. Continue lift only after you are assured the load is free of all obstructions.

When applying a load, it should be directly under the trolley. Avoid off center loading of any kind.

Take up a slack load chain carefully and start load easily to avoid shock and jerking of hoist load chain. If there is any evidence of overloading, immediately lower the load and remove the excess load.

Do not allow the load to swing or twist while hoisting.

Anticipate the stopping point and allow trolley to coast to a smooth stop. Reversing or "plugging" to stop trolley causes overheating of motor and swaying of load.

Do not load trolley beyond the rated capacity. Overload can cause immediate failure of some load carrying part or create a defect causing future failure at less than rated capacity.

Do not use this or any other overhead materials handling equipment for lifting or transporting persons.

Stand clear of all loads and avoid moving a load over the heads of other personnel. Warn personnel of your intention to move a load in their area.

Do not leave the load suspended in the air unattended.

Do not wrap the load chain around the load and hook onto itself as a choker chain.

Permit only qualified personnel to operate unit.

MAINTENANCE

To maintain continuous and satisfactory operation, a regular periodic inspection procedure must be initiated so that worn or damaged parts can be replaced before they become unsafe. The frequency of inspection must be determined by the individual application.

The following list gives an inspection procedure for normal usage under normal conditions. When the unit is subjected to heavy usage or dusty, gritty, moist or other adverse atmospheric conditions, shorter time periods must be assigned. Inspection must be made of all parts for unusual wear, corrosion or damage in addition to those specifically mentioned in the schedule below.

It is suggested that the unit be inspected monthly for wear damage and corrosion effects to all parts with particular attention to the following:

All fasteners including track wheel axle nuts, and suspension bolt nuts.

Contactors and control station for burnt or pitted contacts and loose or corroded terminals.

Cables and leads for broken wires, loose or corroded terminals, also damaged insulation.

Terminal board for loose or corroded connections.

Track wheels for wear of tread and flange and for bearing wear indicated by excessive looseness of wheel on axle.

Trackwheel gear and pinion for wear.

Collector or power supply system for damage, wear, corrosion and proper operation.

Once a month lubricate trackwheel gear and pinion with Texaco Novatex No. 2 or an equivalent heavy cup grease or graphite grease.


Motor gear box oil must be changed after first 100 hours of operation, then every six months or 2500 hours of normal service, whichever comes first. Use 1/2 pint of Omala Oil Grade 37 (product of Shell Oil Co.) for each oil change.

All other trolley parts are lubricated for life at the factory.

REPAIR PARTS

RT Series 1/2 Through 2 Ton*

Trolley Assembly



* Trolley Capacity indicated by Diameter of Double End Stud (Item 13).

When Replacement Parts Are Needed, Order Only Yale® Factory Engineered Parts

RT 1/2 Through 2 Ton (6-15 INCH I-BEAM)

Trolley Assembly

ITEM NBR	AMERICAN STD. 6-15" I-BEAM	PATENTED TRACK	DESCRIPTION	QTY.
	6465932-00	6467752-00	TROLLEY ASSEMBLY (Incl. Items 1 thru 14)	1
1	0150158-00	0150158-00	NUT	4
2	6461873-01	6461873-01	SIDE PLATE, PLAIN	1
3	5003539-07	5003539-07	BEARING	8
4	6412103-00	0650863-00	WHEEL, PLAIN	2
5	6400469-04	6400469-04	RETAINING RING	4
6	0250576-00	0650864-00	AXLE, WHEEL	4
7	6412113-00	5011583-00	WHEEL, GEARED	2
8	6461873-02	6461873-02	SIDE PLATE, GEARED	1
9	0149374-00	0149374-00	HEX NUT	4
10	0150268-00	0150268-00	LOCKWASHER	4
11	0114200-00	0114200-00	ADJUSTMENT WASHERS	48/20
12	6445021-05	0114207-00	WASHER	4
13	0101020-00	0101017-00	DOUBLE END STUD (5/8 IN.)	2
14	0161158-00	0161158-00	WASHER	16/24
22	SEE TABLE 6467002-00	SEE TABLE	GEAR CASE RT MTG KIT (Incl. Items 23, 24, 25 & 26)	1
23	6462883-00	6462883-00	PINION	1
24	6462973-01	6462973-01	GROOVE PIN	1
25	0554856-00	0554856-00	BOLT	2
26	0150266-00	0150266-00	LOCK WASHER	2
39			MOTOR ASSEMBLY	1
40	0103739-00	0103739-00	LOCK NUT	1
41	6401569-10	6401569-10	WATER TIGHT CONNECTOR	1
42	6431261-81	6431261-81	POWER CORD	7 Ft.
43	6401569-18	6401569-18	WATER TIGHT CONNECTOR	1
44	0103740-00	0103740-00	LOCKNUT	1

*When Ordering Motors Give Complete Data On Motor Nameplate.


GEAR TABLE

TRAVEL SPEED (FT/MIN)	GEAR CASE	RATIO
15	6462923-30	30:1
30	6462923-15	15:1
45	6462923-10	10:1
90	6462923-05	5:1

REPAIR PARTS

RT Series 3 Ton^{*}

Trolley Assembly



★ Trolley Capacity Indicated by Diameter of Double End Stud (Item 13).

When Replacement Parts Are Needed, Order Only Yale® Factory Engineered Parts

RT 3 TON (8-24 INCH I-BEAM)

Trolley Assembly

ITEM NBR	AMERICAN STD. 8-25" I-BEAM	PATENTED TRK. 3 1/4 & 4 1/16 FLG.	DESCRIPTION	QTY.
	6467762-00	6467772-00	TROLLEY ASSEMBLY (Incl. Items 2 thru 16)	1
1	0213606-00	0149716-00	NUT	4
2	6465003-01	6465003-01	SIDE PLATE, PLAIN	1
3	0664037-00	0664037-00	BEARING ASSEMBLY	8
4	6412133-00	6465981-00	WHEEL, PLAIN	2
5	5024531-00	5024531-00	SHIM	4
6	0664038-00	0664038-00	AXLE, WHEEL	4
7	6412143-00	6465991-00	WHEEL, GEARED	2
8	6465003-02	6465003-02	SIDE PLATE, GEARED	1
9	0149716-00	0149716-00	HEX NUT	4
10	0150297-00	0150297-00	LOCKWASHER	4
11	0114197-00	0114197-00	ADJUSTMENT WASHERS	24/4
12	0664039-00	5005201-00	WHEEL SPACER	4
13	6449073-00	0101053-00	DOUBLE END STUD (1 IN.)	2
14	6447913-06	6447913-06	BEARING SPACER	8/8
16	0629893-00	5000239-23	SPACER	4
22	SEE TABLE 646700200	SEE TABLE	GEAR CASE RT MGT. KIT (Incl. Items 23, 24, 25 & 26)	1
23	6462883-00	6462883-00	PINION	1
24	6462973-01	6462973-01	GROOVE PIN	1
25	0554856-00	0554856-00	BOLT	2
26	0150266-00	0150266-00	LOCK WASHER	2
39	.	.	MOTOR	1
43	0103739-00	0103739-00	LOCKNUT	1
44	6401569-10	6401569-10	WATERTIGHT CONNECTOR	1
45	6431261-81	6431261-81	POWER CORD	7 ft.
46	6401569-18	6401569-18	WATERTIGHT CONNECTOR	1
47	0103740-00	0103740-00	LOCKNUT	1

*When Ordering Motors Give Complete Data On Motor Nameplate.


GEAR TABLE

TRAVEL SPEED (FT/MIN)	GEAR CASE	RATIO
15	6462923-30	30:1
30	6462923-15	15:1
45	6462923-10	10:1
90	6462923-05	5:1

REPAIR PARTS

MOTORIZED TROLLEY DRIVE (RT)

TROLLEY MOTOR 648943100 (Splined Shaft for RT Trolley)



When Replacement Parts Are Needed, Order Only Yale[®] Factory Engineered Parts

FEBRUARY 1985

TT SERIES

Yale Hoisting Equipment

AIR MOTOR AND ADAPTER ASM.

TT Series (Air Powered)

ITEM	PART NO. 1/2 PIPE	DESCRIPTION	QTY.
1	6453748-00	SCREW	6
2	6421178-00	END CAP	1
3	6453758-00	SCREW	6
4	6421188-00	GASKET	1
5	6421088-00	BEARING	1
6	6421028-00	END PLATE	1
7	6421138-00	GASKET	2
8	6421128-00	DOWEL PIN	4
9	6421068-00	PUSH PIN	2
10	6421058-00	VANE SPRING	4
11	6421048-00	VANE	4
12	NOT AVAILABLE	ROTOR ASSEMBLY	1
13	6421008-00	BODY	1
14	6453768-00	OILER ASSEMBLY	2
15	6421078-00	BEARING	1
16	6453778-00	SCREW	6
17	6421198-00	"O" RING	1
18	6421118-00	SEAL	1
19	6421168-00	END CAP	1
20	6421228-00	REPAIR KIT (INCL. ITEMS 4, 5, 7, 9, 10, 11, 15, 17 & 18) .	1
21	6414140-00	MOTOR ADAPTER ASM. (INCL. ITEMS 22 through 27) .	1
22	6405083-00	MOTOR ADAPTER (NOT SHOWN)	1
23	0655796-00	SCREW (NOT SHOWN)	4
24	0515197-00	RETAINING RING (NOT SHOWN)	1
25	0325737-00	BEARING (NOT SHOWN)	1
26	0150290-00	LOCKWASHER (NOT SHOWN)	4
27	0150288-00	WASHER (NOT SHOWN)	4

When Replacement Parts Are Needed, Order Only Yale® Factory Engineered Parts

FEBRUARY 1985


TT SERIES

Yale® Hoisting Equipment

REPAIR PARTS

MOTORIZED TROLLEY DRIVE (RT)

Trolley Assembly 6: Tread Diameter



Yale® Hoisting Equipment

REPAIR PARTS

MOTORIZED TROLLEY DRIVE (RT)

Trolley Assembly 6: Tread Diameter



ITEM	DESCRIPTION	PART NO.
1	HOUSING	649106601
2	BEARING BALL	649106602
3	CONE LM-11949 ROLLER BEARING	649106603
4	CUP LM-11910 ROLLER BEARING	649106604
5	TEMPER LOAD RING	649106605
6	TRUARC SPACER #5900-66	649106607
7	SPIROLOX RETAINING RINGS RST 66	649106608
8	RETAINING RING N5000-156	649106609
9	HIGH SPEED CAP CLOSED	649106610
10	GASKET HIGH SPEED CAP	649106611
11	GASKET SLOW SPEED COVER	649106612
12	KEY 3/16 SQ. X 1	649106613
13	PLUG VENT 1/8 X .375	649106614
14	PLUG STL. 1/8 X .375	649106615
15	VENT SHIELD (NOT SHOWN)	649106616
16	SLOW SPEED COVER & FLANGE	649106617
17	SLOW SPEED SHAFT	649106618
18	SLOW SPEED PLUG, COVER & HOUSING	649106619
19	SOC. HD SCREW 5/16-18 X 7/8	649106620
20	LOCKWASHER HI COLLAR 5/16	649106621
21	HEX HD CAP SCREW 1/4-20 X 5/8	649106622
22	SLOW SPEED SPACER	649106606
23	OIL SEAL C/R 11124	649106623
24	OIL SEAL C/R 7443	649106624
25	MOTOR ADAPTER	649106625
26	HEX HD CAP SCREW 1/4-20 X 1 1/8	649106626
27	WORM SHAFT 56C	SEE TABLE
28	GEAR	SEE TABLE
29	LOCKWASHER	649106629
30	HEX HD CAP SCREW 3/8-16 X 7/8	649106630

RATIO	ITEM 27, WORM SHAFT YALE NO.	ITEM 28, GEAR YALE NO.
5	649106650	649106660
10	649106651	649106661
15	649106652	649106662
20	649106653	649106663
30	649106654	649106664
40	649106655	649106665
50	649106656	649106666
60	649106657	649106667

When replacement parts are needed, order only Yale® Factory Engineered Parts.



WIRING DIAGRAMS

THREE PHASE




FORWARD

REVERSE



DUAL VOLTAGE MOTOR CONNECTIONS				DUAL VOLTAGE TRANSF. CONNECTIONS			
LOW VOLTAGE		HIGH VOLTAGE		LOW VOLTAGE		HIGH VOLTAGE	
TA	TB	TC		TA	TB	TC	
T1	T2	T3		T1	T2	T3	
T7	T8	T9		T7	T8	T9	
01	02	03		01	02	03	
T4	T5	T6		T4	T5	T6	
							

WIRING DIAGRAMS

SINGLE PHASE





TROLLEY MOTOR CONNECTIONS											
LOW VOLTAGE						HIGH VOLTAGE					
TROLLEY CONTACTOR TERMINAL						TROLLEY CONTACTOR TERMINAL					
10	7	1	4	5		10	7	1	4	5	
TA	TB	TC				TA	TB	TC			
T1	T4					T1	T4				
B1	B2					B1	B2				
T3	T2	T5	J10	J11		T2	T3	T5	B2	J10	J11




WIRING DIAGRAM



THREE PHASE



DUAL VOLTAGE MOTOR CONNECTIONS			DUAL VOLTAGE TRANSF. CONNECTIONS		
LOW VOLTAGE			HIGH VOLTAGE		
TA	TB	TC	TA	TB	TC
T1	T2	T3	T1	T2	T3
T7	T8	T9	T7	T8	T9
51	T8	B2	21	T8	B2
T40	T50	T60	T40	T50	T60



WIRING DIAGRAM SINGLE PHASE




TROLLEY MOTOR CONNECTIONS	
LOW VOLTAGE	HIGH VOLTAGE
<p>TROLLEY</p> <p>CONTACTOR TERMINAL</p> <p>10 7 1 4 5</p> <p>TA TB TC</p> <p>T1 T4</p> <p>B1 B2</p> <p>T3 T2 T5 J10 J11</p>	<p>TROLLEY</p> <p>CONTACTOR TERMINAL</p> <p>10 7 1 4 5</p> <p>TA TB</p> <p>T1 T4</p> <p>B1 B2</p> <p>T2 T3 T5 B2 J10 J11</p>

UP
DOWN

FORWARD
REVERSE

TRANSFORMER CONNECTIONS	
LOW VOLTAGE	HIGH VOLTAGE
<p>OH1 OH2 OH3 OH4</p> <p>1 2 3 4</p>	<p>OH1 OH2 OH3 OH4</p> <p>1 2 3 4</p>



POWERED HOIST INSPECTION CHECK LIST

SEE PREVENTIVE MAINTENANCE SECTION OF INSTRUCTION MANUAL FOR DETAILS.

CHECK ONLY COMPONENTS APPLICABLE FOR SPECIFIC EQUIPMENT AND INSPECTION TYPE.

MODEL _____

HOIST S/N _____

HOOKS	YES	NO	CABLE	YES	NO	CHAINS	YES	NO
HARDWARE LOOSE	<input type="checkbox"/>	0	BROKEN WIRES AT ENDS	<input type="checkbox"/>	0	BINDING	<input type="checkbox"/>	0
CRACKS	<input type="checkbox"/>	0	BROKEN WIRES EXCESSIVE	<input type="checkbox"/>	0	CRACKED	<input type="checkbox"/>	0
EXCESSIVE WEAR	<input type="checkbox"/>	0	EXCESSIVE WEAR	<input type="checkbox"/>	0	TWISTED	<input type="checkbox"/>	0
BENT	<input type="checkbox"/>	0	KINKED OR DISTORTED	<input type="checkbox"/>	0	DISTORTED	<input type="checkbox"/>	0
SPREADING	<input type="checkbox"/>	0	CORROSION	<input type="checkbox"/>	0	CORRODED	<input type="checkbox"/>	0
FREELY ROTATE	<input type="checkbox"/>	<input type="checkbox"/>	HEAT DAMAGED	<input type="checkbox"/>	0	EXCESSIVE WEAR	<input type="checkbox"/>	0
LATCH DAMAGED	<input type="checkbox"/>	0				WORN CHAIN GUIDES	<input type="checkbox"/>	0
						POCKET WHEELS WORN	<input type="checkbox"/>	0
BRAKES	YES	NO	WIRING	YES	NO	DRUM & SHEAVES	YES	NO
MOTOR BRAKE WORN OR NOT OPERATING	<input type="checkbox"/>	0	LOOSE CONNECTIONS	<input type="checkbox"/>	0	WORN EXCESSIVELY	<input type="checkbox"/>	0
EXCESSIVE LOADBRAKE DRIFT OR BLACKLASH	<input type="checkbox"/>	0	FRAYED	<input type="checkbox"/>	0	CRACKED OR SCORED	<input type="checkbox"/>	0
EXCESSIVE DISC WEAR	<input type="checkbox"/>	0	DAMAGED	<input type="checkbox"/>	0			
			PROPER GROUNDING	0	<input type="checkbox"/>			
LIMIT SWITCHES	YES	NO	LOAD LIMITING DEVICE	YES	NO	COLLECTORS	YES	NO
OPERATING PROPERLY	0	<input type="checkbox"/>	OPERATING PROPERLY	0	<input type="checkbox"/>	BINDING	<input type="checkbox"/>	0
						EXCESSIVE WEAR	<input type="checkbox"/>	0
ING	YES	NO	OPERATION CONTROLS	YES	NO	LUBRICATION	YES	NO
DISTORTED	<input type="checkbox"/>	0	CONTACTOR PITTING	<input type="checkbox"/>	0	ALL POINTS LUBRICATED AS GIVEN IN LUB CHART	0	<input type="checkbox"/>
CRACKS	<input type="checkbox"/>	0	OPERATING PROPERLY	0	<input type="checkbox"/>	OIL DARK OR LOW	<input type="checkbox"/>	0
LOOSE HARDWARE	<input type="checkbox"/>	0	DAMAGED PUSH BUTTON HOUSING	<input type="checkbox"/>	0	OIL LEAKS	<input type="checkbox"/>	0
BEARING NOISE	<input type="checkbox"/>	0						
SUPPORTING STRUCTURE	YES	NO	AIR SYSTEM	YES	NO	WARNING LABELS	YES	NO
CONTINUED ABILITY TO SUPPORT IMPOSED LOADS	0	<input type="checkbox"/>	LEAKING	<input type="checkbox"/>	0	MISSING	<input type="checkbox"/>	0
WORN OR DISTORTED TROLLEY PARTS	<input type="checkbox"/>	0	LOOSE CONNECTIONS	<input type="checkbox"/>	0	ILLEGIBLE	<input type="checkbox"/>	0
			BROKEN CONTROL PENDANT	<input type="checkbox"/>	0			

NOTE IF ANY () IS CHECKED DO NOT OPERATE THE HOIST UNTIL REPAIRS HAVE BEEN MADE.

REMARKS AND REPAIRS MADE _____

SIGNATURE _____ DATE _____ CLOCK NUMBER _____

POWERED HOIST INSPECTION CHECK LIST

SEE PREVENTIVE MAINTENANCE SECTION OF INSTRUCTION MANUAL FOR DETAILS.

CHECK ONLY COMPONENTS APPLICABLE FOR SPECIFIC EQUIPMENT AND INSPECTION TYPE.

HOIST MODEL _____

HOIST S/N _____

HOOKS			CABLE			CHAINS		
	YES	NO		YES	NO		YES	NO
HARDWARE LOOSE	<input type="checkbox"/>	<input type="checkbox"/>	BROKEN WIRES AT ENDS	<input type="checkbox"/>	<input type="checkbox"/>	BINDING	<input type="checkbox"/>	<input type="checkbox"/>
CRACKS	<input type="checkbox"/>	<input type="checkbox"/>	BROKEN WIRES EXCESSIVE	<input type="checkbox"/>	<input type="checkbox"/>	CRACKED	<input type="checkbox"/>	<input type="checkbox"/>
EXCESSIVE WEAR	<input type="checkbox"/>	<input type="checkbox"/>	EXCESSIVE WEAR	<input type="checkbox"/>	<input type="checkbox"/>	TWISTED	<input type="checkbox"/>	<input type="checkbox"/>
BENT	<input type="checkbox"/>	<input type="checkbox"/>	KINKED OR DISTORTED	<input type="checkbox"/>	<input type="checkbox"/>	DISTORTED	<input type="checkbox"/>	<input type="checkbox"/>
SPREADING	<input type="checkbox"/>	<input type="checkbox"/>	CORROSION	<input type="checkbox"/>	<input type="checkbox"/>	CORRODED	<input type="checkbox"/>	<input type="checkbox"/>
FREELY ROTATE	<input type="checkbox"/>	<input type="checkbox"/>	HEAT DAMAGED	<input type="checkbox"/>	<input type="checkbox"/>	EXCESSIVE WEAR	<input type="checkbox"/>	<input type="checkbox"/>
LATCH DAMAGED	<input type="checkbox"/>	<input type="checkbox"/>				WORN CHAIN GUIDES	<input type="checkbox"/>	<input type="checkbox"/>
						POCKET WHEELS WORN	<input type="checkbox"/>	<input type="checkbox"/>
BRAKES			WIRING			DRUM & SHEAVES		
	YES	NO		YES	NO		YES	NO
MOTOR BRAKE WORN OR NOT OPERATING	<input type="checkbox"/>	<input type="checkbox"/>	LOOSE CONNECTIONS	<input type="checkbox"/>	<input type="checkbox"/>	WORN EXCESSIVELY	<input type="checkbox"/>	<input type="checkbox"/>
EXCESSIVE LOADBRAKE DRIFT OR BLACKLASH	<input type="checkbox"/>	<input type="checkbox"/>	FRAYED	<input type="checkbox"/>	<input type="checkbox"/>	CRACKED OR SCORED	<input type="checkbox"/>	<input type="checkbox"/>
EXCESSIVE DISC WEAR	<input type="checkbox"/>	<input type="checkbox"/>	DAMAGED	<input type="checkbox"/>	<input type="checkbox"/>			
			PROPER GROUNDING	<input type="checkbox"/>	<input type="checkbox"/>			
LIMIT SWITCHES			LOAD LIMITING DEVICE			COLLECTORS		
	YES	NO		YES	NO		YES	NO
OPERATING PROPERLY	<input type="checkbox"/>	<input type="checkbox"/>	OPERATING PROPERLY	<input type="checkbox"/>	<input type="checkbox"/>	BINDING	<input type="checkbox"/>	<input type="checkbox"/>
						EXCESSIVE WEAR	<input type="checkbox"/>	<input type="checkbox"/>
HOUSING			OPERATION CONTROLS			LUBRICATION		
	YES	NO		YES	NO		YES	NO
DISTORTED	<input type="checkbox"/>	<input type="checkbox"/>	CONTACTOR PITTING	<input type="checkbox"/>	<input type="checkbox"/>	ALL POINTS LUBRICATED AS GIVEN IN LUB CHART	<input type="checkbox"/>	<input type="checkbox"/>
CRACKS	<input type="checkbox"/>	<input type="checkbox"/>	OPERATING PROPERLY	<input type="checkbox"/>	<input type="checkbox"/>	OIL DARK OR LOW	<input type="checkbox"/>	<input type="checkbox"/>
LOOSE HARDWARE	<input type="checkbox"/>	<input type="checkbox"/>	DAMAGED PUSH BUTTON	<input type="checkbox"/>	<input type="checkbox"/>	OIL LEAKS	<input type="checkbox"/>	<input type="checkbox"/>
BEARING NOISE	<input type="checkbox"/>	<input type="checkbox"/>	HOUSING	<input type="checkbox"/>	<input type="checkbox"/>			
SUPPORTING STRUCTURE			AIR SYSTEM			WARNING LABELS		
	YES	NO		YES	NO		YES	NO
CONTINUED ABILITY TO SUPPORT IMPOSED LOADS	<input type="checkbox"/>	<input type="checkbox"/>	LEAKING	<input type="checkbox"/>	<input type="checkbox"/>	MISSING	<input type="checkbox"/>	<input type="checkbox"/>
WORN OR DISTORTED TROLLEY PARTS	<input type="checkbox"/>	<input type="checkbox"/>	LOOSE CONNECTIONS	<input type="checkbox"/>	<input type="checkbox"/>	ILLEGIBLE	<input type="checkbox"/>	<input type="checkbox"/>
			BROKEN CONTROL PENDANT	<input type="checkbox"/>	<input type="checkbox"/>			

NOTE IF ANY () IS CHECKED DO NOT OPERATE THE HOIST UNTIL REPAIRS HAVE BEEN MADE.

REMARKS AND REPAIRS MADE _____

SIGNATURE _____ DATE _____ CLOCK NUMBER _____

DATE 3/79 FORM 165-905-101



(800) 713-0101 • www.gohispeed.com

Yale®

HOISTS

Warranty

Every hoist is thoroughly inspected and tested prior to shipment from the factory. Should any problems develop, return the complete hoist prepaid to your nearest Yale Authorized Warranty Repair Station.

This warranty does not apply where: (1) deterioration is caused by normal wear, abuse, improper or inadequate power supply, eccentric or side loading, overloading, chemical or abrasive actions, improper maintenance or excessive heat; (2) problems resulted from repairs, modifications or alterations made by persons other than factory or Duff-Norton personnel;

(3) the hoist has been abused or damaged as a result of an accident; (4) repair parts or accessories other than those supplied by Duff-Norton are used on the hoist. Equipment and accessories not of the seller's manufacture are warranted only to the extent that they are warranted by the manufacturer. **EXCEPT AS STATED HEREIN, DUFF-NORTON MAKES NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.**

Improvements:

Yale is constantly striving to improve its product. Changes in design and improvements will be made whenever the manufacturer believes the efficiency of the product will be improved without incurring any obligation to incorporate such improvements in any products which have been shipped or are in service.

Important Notice:

Use of chain, wire rope or replacement parts other than as supplied as original equipment on Yale hoists may lead to dangerous operation. Accordingly, Yale cannot be responsible in such cases and our warranty should be voided.

For more information write Yale Hoists, Forrest City, Arkansas 72335.



Yale® Hoists
Highway 1 North
P.O. Box 1000
Forrest City, Arkansas 72335
Customer Service Phone (800) 999-6318
Fax (800) 766-0223

Copyright 1991
Yale Hoists

3448
Printed in U.S.A.