





DANGER:

UNLESS HOOK RAISES WHEN "UP" BUTTON IS PRESSED SEVERE HOIST DAMAGE AND A DROPPED LOAD MAY RESULT.



CORRECT IMPROPER HOOK DIRECTION BY
INTERHANGING MOTOR LEADS ORANGE (5)
AND RED (8)
DO NOT CHANGE PUSHBUTTON WIRING.

WARNING

THIS EQUIPMENT MUST BE EFFECTIVELY GROUNDING ACCORDING TO APPLICABLE CODES.

AVERTISSEMENT

CET EQUIPMENT DOIT ETRE MIS A'LA TERRE
EN ACCORDANCE AVEC LES NORMES EN
VIGUEUR.



NO.	CHANGE	DATE	ITL.	ELEMENTARY DIAGRAM WITH TRANSFORMER
				1 PHASE RECONNECTABLE, STEARNS REVERSING SWITCH
				D.C. SOLENOID BRAKE
				BUDGIT ELECTRIC HOIST
				SC. -----
				DA. 2/7/90
				DR. BES
				CK.
				 YALE LIFT-TECH division of Columbus McKinnon Corporation Muskegon, Michigan 49443
				SHEET 4 OF MORE SHEETS
				330174