




DANGER:

UNLESS HOOK RAISES WHEN "UP" BUTTON IS PRESSED SEVERE HOIST DAMAGE AND A DROPPED LOAD MAY RESULT.
CORRECT IMPROPER HOOK DIRECTION BY INTERCHANGING INPUT POWER L1 AND L3.
DO NOT CHANGE PUSHBUTTON WIRING.

WARNING

THIS EQUIPMENT MUST BE EFFECTIVELY
GROUNDED ACCORDING TO APPLICABLE
CODES.

AVERTISSEMENT

CET EQUIPEMENT DOIT ETRE MIS A LA TERRE EN ACCORDANCE AVEC LES NORMES EN VIGUEUR.

NO.	CHANGE	DATE	ITL.	WIRING DIAGRAM
				3 PHASE 2-SPEED
				D.C. SOLENOID BRAKE
				BUDGIT ELECTRIC HOIST
				SC. -----
				DA. 4/17/90
				DR. RITTER
				CK.
				 YALE • LIFT-TECH division of Columbus McKinnon Corporation Muskegon, Michigan 49443
				SHEET 4 OF MORE SHEETS
				330565