




DANGER:

UNLESS HOOK RAISES WHEN "UP" BUTTON IS PRESSED SEVERE HOIST DAMAGE AND A DROPPED LOAD MAY RESULT.

CORRECT IMPROPER HOOK DIRECTION BY
INTERCHANGING INPUT POWER L1 AND L3
DO NOT CHANGE PUSHBUTTON WIRING.

WARNING

THIS EQUIPMENT MUST BE EFFECTIVELY
GROUNDED ACCORDING TO APPLICABLE
CODES.

AVERTISSEMENT

CET EQUIPMENT DOIT ETRE MIS A'LA TERRE
EN ACCORDANCE AVEC LES NORMES EN
VIGUEUR.

NO.	CHANGE	DATE	ITL.	WIRING DIAGRAM		208 OR 575 VOLT	
				3 PHASE 1-SPEED SINGLE VOLTAGE			
				A.C. SOLENOID BRAKE			
				BUDGIT ELECTRIC HOIST			
				SC. -----	 YALE • LIFT-TECH division of Columbus McKinnon Corporation Muskegon, Michigan 49443		
				DA. 8/17/06			
				DR. RITTER			SHEET 3 OF 4 SHEETS
				CK.			333213