

LR Motor Shop Repairs

Job Number 101000

Prepared for Reynolds Metals company

1333 highway 270 Malvern AR 72104

Table of Contents

AC Recondition As Found - Shop

AC Recondition - Rev. 2: CE1020287-702 89-05001

1.0



Hi-Speed Industrial Service 7030 Ryburn Dr Millington, Tn 38053 901-873-5300

> FolderID: 101000 FormID: 16060866

AC Recondition As Found

Reynolds Metals company

1333 highway 270 Malvern, AR 72104

AC Recondition - Rev. 2

Location: Shop

Serial Number: CE1020287-702 89-05001

Description: 100HP US MOTORS 1800RPM

405TS

Hi-Speed Job Number:	101000
Manufacturer:	US Motors/Nidec
Serial Number:	CE1020287-702 89-05001
HP/kW:	100 (HP)
RPM:	1780 (RPM)
Frame:	405TS
Voltage:	460
Current:	118
Phase:	Three
Hz:	60 (Hz)
Service Factor:	1.15
Enclosure:	TEFC
J-box Included:	Complete
Bearing RTDs:	No
Stator RTDs:	No
Repair Stage:	Final
Heaters:	No
Winding Type :	Random Wound
Bearing Type:	Rolling Element

Priorities Found: **3 - High**





6 - Good

Overall Condition

- Report Date
- Nameplate Picture



Photos of all six sides of the machine.















	4.	Describe the Overall Condition of the Equipment as Received		
	5.	Distance from the end of the shaft to the Coupling/Sheave		
In	itial	Mechanical/Electrical		
	6.	Does Shaft Turn Freely?	(Yes) Yes	
	7.	Does Shaft Have Visible Damage?	(No) No	
	8.	Assembled Shaft Runout	0.0015 Inches	
	9.	Assembled Shaft End Play		
	10.	Air Gap Variation <10%		
	11.	Lead Condition	(P) Pass	




12. Lead Length	10 Inches
13. Frame Condition	pass







15.	Broken or Missing Components			
Initial	Initial Electrical Inspection			
16.	Insulation Resistance/Megger		18174 Mego	hms
17.	Winding Resistance			
	1-2	1-3	2-3	
	0.0505	0.0505	0.0504	
18.	Perform Surge Test		(P) I	Pass



19. Number of Stator Slots 72 Megohms

20. Stator Condition wash and bake





Mechanical Inspection

21. Drive End Bearing Brand Nachi



22. Drive End Bearing Number-	6214
23. Drive End Bearing Qty.	1
24. Drive End Bearing Type	(Ball) Ball Bearing
25. Drive End Lubrication Type	(Grease) Grease Lubricated
26. Drive End Bearing Insulation or Grounding Device?	na
27. Drive End Wavy Washer/Snap-Ring Other Retention Device?	na



29.	Opposite Drive End Bearing Brand	Nachi
30.	Opposite Drive End Bearing Number-	6214



31. Opposite Drive End Bearing Qty.	1
32. Opposite Drive End Bearing Type	(Ball) Ball Bearing
33. Opposite Drive End Lubrication Type	(Grease) Grease Lubricated
34. Opposite Drive End Bearing Insulation or Grounding Device?	na
35. Opposite Drive End Wavy Washer/Snap-Ring Other Retention Device?	na
36. Opposite Drive End Bearing Condition	Frosted



37. Drive End Seal

Rotor Inspection

39. Rotor Type/Material

(Squirrel Aluminum) Squirrel Cage Aluminum Die Cast



40. Growler Test	(Pass) Pass
41. Number of Rotor Bars	
42. Rotor Condition	wash
43. List the Parts needed for the Repair Below	
2 6214 Bearing	
44. Signature of Technician that Disassembled Motor	RW



Mechanical Fits- Rotor			
45.	Shaft Runout		
46.	Rotor Runout		
	Drive End Bearing Fit	Rotor Body	Opposite Drive End Bearing
47.	Coupling Fit Closest to Bearing Housi	ng	
	0 Degrees	90 Degrees	120 Degrees
48.	Coupling Fit Closest to the end of the	Shaft	
	0 Degrees	60 Degrees	120 Degrees
49.	Drive End Bearing Shaft Fit		
	0 Degrees	60 Degrees	120 Degrees
	2.7559	2.7559	2.7559

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.



51.	51. Opposite Drive End Bearing Shaft Fit			
	0 Degrees	60 Degrees	120 Degrees	
	2.7563	2.7563	2.7563	
5 2.	Opposite Drive End Bearing Shaft Fit	Condition		(P) Pass



53. Shaft Air Seal Fits		
Drive End Air Seal	Opposite Drive End Air Seal	
Mechanical Fits- Bearing Housings		
54. Drive End - Endbell Bearing Fit		
0 Degrees	60 Degrees	120 Degrees
4.9217	4.9217	4.9217



56.	Opposite Drive End - Endbell Bearing Fit			
	0 Degrees	60 Degrees	120 Degrees	
57.	7. Opposite Drive End - Endbell Bearing Fit Condition			(F) Fail
-	Resleeve paint and Grooved			()



58.	Bearing Cap Condition			
	Drive End Bearing Cap	Opposite Drive End Bearing Cap		
	pass	pass		
59.	End Bell Air Seal Fits			
	Drive End Air Seal	Opposite Drive End Air Seal		
60.	List Machine Work Needed Below			
	Ode end bell housing fit bad.fan cover l	bolts broke in end bell		
61.	Technician	F	RW	
		2 1		
Dynar	Dynamic Balance Report			

Rotor Weight Balance Grade 63. Initial Balance Readings Drive End Opposite Drive End 64. Final Balance Readings Drive End Opposite Drive End 65. Technician Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Sport Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Roto Cause of Failure 74. Failure locations 75. Roto cause of Failure 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 83. Shaft Repair Sign-off	62.	Rotor Weight and Balance Grade					
Drive End Opposite Drive End 64. Final Balance Readings Drive End Opposite Drive End 65. Technician Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician ROO Cause of Failure 74. Failure locations 75. Root cause of Failure 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Prive End Bearing Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair Drive End Bear Fis Post Repair Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees		Rotor Weight	Balance Grade				
Drive End Opposite Drive End 64. Final Balance Readings Drive End Opposite Drive End 65. Technician Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Bering Shaft Fit Post Repair							
Drive End Opposite Drive End 65. Technician Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Surge Test 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 78. Shaft Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees	63.		Occasio Director				
Drive End Opposite Drive End 65. Technician Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Polarization Index 71. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees		Drive End	Opposite Drive End				
Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair Prive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees	64.	4. Final Balance Readings					
Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Polarization Index 71. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees		Drive End	Opposite Drive End				
Rewind 66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Polarization Index 71. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees							
66. Core Test Results - Watts loss per Pound Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 68. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 78. Shaft Runout Post Repair 79. Post Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal							
Pre-Burnout Post Burnout 67. Core Hot Spot Test Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Burge Test 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits-Rootor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal							
67. Core Hot Spot Test Pre-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Polarization Index 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 90 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	66.	•					
Pre-Burnout Post-Burnout 68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 78. Shaft Runout Post Repair 79. Tree and Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees		FIE-Bulliout	POST BUILIOUT				
68. Post Rewind Electrical Test- Insulation Resistance 69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees	67.	Core Hot Spot Test					
69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees		Pre-Burnout	Post-Burnout				
69. Post Rewind Polarization Index 70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 77. Rotor Runout Post Repair 77. Rotor Runout Post Repair 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees							
70. Post Rewind Winding Resistance 1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees			n Resistance				
1-2 1-3 2-3 71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Prive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees							
71. Post Rewind Surge Test 72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees	70.	•	4.2	2.2			
72. Post Rewind Hi-Pot 73. Technician Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees		1-2	1-3	2-3			
Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	71.	Post Rewind Surge Test					
Root Cause of Failure 74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	72.	Post Rewind Hi-Pot					
74. Failure locations 75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	73.	Technician					
75. Root cause of failure Mechanical Fits- Rotor - Post Repair 76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	Root	Cause of Failure					
Mechanical Fits- Rotor - Post Repair76. Shaft Runout Post Repair77. Rotor Runout Post RepairDrive End Bearing FitRotor BodyOpposite Drive End Bearing78. Coupling Fit Closest to Bearing Housing Post Repair0 Degrees120 Degrees79. Coupling Fit Closest to the end of the Shaft Post Repair0 Degrees120 Degrees80. Drive End Bearing Shaft Fit Post Repair0 Degrees120 Degrees81. Opposite Drive End Bearing Shaft Fit Post Repair0 Degrees120 Degrees82. Shaft Air Seal Fits Post RepairOpposite Drive End Air SealOpposite Drive End Air Seal							
76. Shaft Runout Post Repair 77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal							
77. Rotor Runout Post Repair Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal		·					
Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal		·					
78. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	77.	·	Potor Pody	Opposite Drive End Pooring			
0 Degrees 90 Degrees 120 Degrees 79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal		Drive End Bearing Fit	Rotor Body	Opposite Drive End Bearing			
79. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	78.	Coupling Fit Closest to Bearing Housi	ng Post Repair				
0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal		0 Degrees	90 Degrees	120 Degrees			
0 Degrees 60 Degrees 120 Degrees 80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal							
80. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	79.	· · ·	·	100 5			
0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal		0 Degrees	60 Degrees	120 Degrees			
0 Degrees 60 Degrees 120 Degrees 81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	80.	Drive End Bearing Shaft Fit Post Repa	air				
81. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal		· ·		120 Degrees			
0 Degrees 60 Degrees 120 Degrees 82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal				G			
82. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal	81.						
Drive End Air Seal Opposite Drive End Air Seal		0 Degrees	60 Degrees	120 Degrees			
Drive End Air Seal Opposite Drive End Air Seal	82	Shaft Air Seal Fits Post Repair					
	02.	·	Opposite Drive End Air Seal				
83. Shaft Repair Sign-off		2o Ena Ali Oodi	Spposite Silva Elia vili dodi				
	83.	Shaft Repair Sign-off					

Mechani	cal Fits- Bearing Housings - Po	ost Repair			
84. Dr	4. Drive End - Endbell Bearing Fit Post Repair				
0	Degrees	60 Degrees	120 Degrees		
	pposite Drive End - Endbell Bearing	·			
0	Degrees	60 Degrees	120 Degrees		
86. Be	earing Cap Condition Post Repair				
	rive End Bearing Cap	Opposite Drive End Bearing Cap			
Ο.	into Liia Boainig Gap	opposite 2.110 2.110 2001111g cup			
87. Er	nd Bell Air Seal Fits Post Repair				
Dr	rive End Air Seal	Opposite Drive End Air Seal			
	nd Bell Repair Sign-off				
Assembl					
	notograph All Major Components pric	or to assembly			
	nal Insulation Resistance Test				
	ssembled Shaft Endplay				
	ssembled Shaft Runout				
	est Run Voltage	N. 16	V 6		
Vo	olts	Volts	Volts		
94. Te	est Run Amperage				
	mps	Amps	Amps		
	<u>'</u>	·	·		
95. Dr	rive End Vibration Readings - Inches	Per Second			
Н	orizontal	Vertical	Axial		
20.0					
	pposite Drive End Vibration Readings				
Ho	orizontal	Vertical	Axial		
97. Ar	mbient Temperature - Fahrenheit				
	rive End Bearing Temps - Fahrenheit				
	Minutes	10 Minutes	15 Minutes		
99. Op	Opposite Drive End Bearing Temps - Fahrenheit				
5	Minutes	10 Minutes	15 Minutes		
465 -	0.01 1.11 0.11 1.11 1.11				
	QC Check All Parts for Cleanliness Prior to Assembly				
	Document Final Condition with Pictures after paint				
102. Fir	22. Final Pics and QC Review				

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.



STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. APPLICABILITY. The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. SCOPE OF GOODS AND/OR SERVICES. The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only bee effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. <u>DELIVERY OF GOODS AND/OR SERVICES.</u> Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- **DELIVERY SITE AND TIME FOR PERFORMANCE.** Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have sixty (60) days to cure the alleged discrepancy and/or nonconformance. If Hi-Speed fails to cure in this time period, Buyer shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed. Buyer shall notify Hi-Speed and arrange for the return of the goods as required. Should such non-conforming services be rejected Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. <u>LIMITATION OF DAMAGES.</u> HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY.</u> The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. **GOVERNING LAW AND JURISDICTION.** Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. ABANDONED EQUIPMENT. Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER.</u> No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. <u>ASSIGNMENT.</u> The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. NO INDIVIDUAL LIABILITY. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.