

EVERY DAY SINCE 1946

LR Motor Shop Repairs

Job Number 103366

Prepared for Remington (10243)

2592 AR Hwy 15 N Lonoke AR 72086

Table of Contents

AC Inspection as Found - MOTOR SHOP LR



Hi-Speed Industrial Service 7030 Ryburn Dr Millington, Tn 38053 901-873-5300

> FolderID: 103366 FormID: 21293236

AC Inspection as Found

Remington (10243) 2592 AR Hwy 15 N Lonoke, AR 72086

AC Inspection	- Rev. 2	Hi-Speed Job Number:	99908
Location:	MOTOR SHOP LR	Manufacturer:	Other
Serial Number:	P07020114	Product Number:	PVF-F 270
	W RENI CIRILLO 1800RPM	Serial Number:	P07020114
SHAKER		HP/kW:	2.6 (kW)
		RPM:	1500 (RPM)
		Voltage:	230 / 460
		Current:	12/7
		Phase:	Three
		Hz:	60 (Hz)
		J-box Included:	None
		Coupling/Sheave:	None
		Date Received:	06/10/2022
		Bearing RTDs:	No
		Stator RTDs:	No
		Repair Stage:	Final
		Rewind:	Yes
		Shaft Machined Fit Repairs Required:	Yes
		Bearing Housing Machined Fit Repairs Required:	No
		Heaters:	No
		Winding Type :	Random Wound
		Bearing Type:	Rolling Element
Priorities Found: 🔵	5 - High 🛛 🔵 5 - Good		

Overall Condition

1. Report Date

08/20/2024

2. Nameplate Picture





3. Photos of all six sides of the machine.

































	4.	Describe the Overall Condition of the Equipment as Received Ok			
	5.	Report Date [COPY]	08/20/2024		
In	Initial Mechanical/Electrical				
	6.	Does Shaft Turn Freely?	(Y) Yes		
	7.	Does the shaft require T.I.R in Lathe to identify additional repairs?	(No) No		
	8.	Does Shaft Have Visible Damage?	(No) No		
	9.	Assembled Shaft Runout	0 Inches		
	10.	Assembled Shaft End Play	0 inches		

11. Air Gap Variation <10% none			
12.	Lead Condition		(F) Fail
13.	Lead Length		12 Inches
14.	Does it have Lugs?, If so what is the	Stud Size?	(No) No
15.	Lead Numbers		1-6
16.	Frame Condition		ok
17.	Fan Condition		(N) NA
18.	18. Broken or Missing Components		missing cord and grommet
Initial	Electrical Inspection		
19.	Insulation Resistance/Megger		0 Megohms
20.	Winding Resistance		
	1-2	1-3	2-3
	0	0	0
21.	Perform Surge Test		(F) Fail
22.	Number of Stator Slots		36
23.	Stator Condition		rewind
24.	Stator Thermistors/Ohms		none
25.	Stator Overloads/Ohms		none
Mechanical Inspection			

26. Drive End Bearing Brand





27. Drive End Bearing Number-	NJ317 C4
28. Drive End Bearing Qty.	1
29. Drive End Bearing Type	(Roller) Roller Bearing
30. Drive End Lubrication Type	(Grease) Grease Lubricated
31. Drive End Bearing Insulation or Grounding Device?	none
32. Drive End Wavy Washer/Snap-Ring Other Retention Device?	none
33. Drive End Bearing Condition	normal wear
34. Opposite Drive End Bearing Brand	SKF
35. Opposite Drive End Bearing Number-	NJ317 C4
36. Opposite Drive End Bearing Qty.	1
37. Opposite Drive End Bearing Type	(Roller) Roller Bearing
38. Opposite Drive End Lubrication Type	(Grease) Grease Lubricated
39. Opposite Drive End Bearing Insulation or Grounding Device?	none
40. Opposite Drive End Wavy Washer/Snap-Ring Other Retention Device?	none

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

SKF

41.	Opposite Drive End Bearing Condition	n	normal wear
42.	Drive End Seal		2- 120*160*12
43.	Opposite Drive End Seal		2- 85*120*12
Rotor	Inspection		
44.	Rotor Type/Material		(Squirrel Aluminum) Squirrel Cage Aluminum Die Cast
45.	Growler Test		(Pass) Pass
46.	Number of Rotor Bars		28
47.	Rotor Condition		good
48.	List the Parts needed for the Repair E	Below	
	2 - NJ317 C4, 2- 120*160*12, 2- 85*120*1	12	
49.	Signature of Technician that Disasse	mbled Motor	David Maclin
L	122		
	anical Fits- Rotor		
	Shaft Runout		0 inches
51.	Rotor Runout		
	Drive End Bearing Fit	Rotor Body	Opposite Drive End Bearing
	0	0	0
52.	Coupling Fit Closest to Bearing Hous	-	
	0 Degrees	90 Degrees	120 Degrees
	0	0	0
53.	Coupling Fit Closest to the end of the		
	0 Degrees	60 Degrees	120 Degrees
	0	0	0
54.	Drive End Bearing Shaft Fit	-	-
	0 Degrees	60 Degrees	120 Degrees
	3.3465	3.3463	3.346
	Drive End Bearing Shaft Fit Condition		(F) Fail
56.	Opposite Drive End Bearing Shaft Fit		
	0 Degrees	60 Degrees	120 Degrees
-7	3.3455	3.3458	3.3457
57.	Opposite Drive End Bearing Shaft Fit	Condition	(F) Fail
58.	Shaft Air Seal Fits	Opposite Drive Fact Air Court	
	Drive End Air Seal	Opposite Drive End Air Seal	
Most	ok	ok	
	anical Fits- Bearing Housings		
59.	Drive End - Endbell Bearing Fit		
	0 Degrees	60 Degrees	120 Degrees
00	7.087	7.087	7.087
60.	Drive End - Endbell Bearing Fit Cond		(P) Pass
61.	Opposite Drive End - Endbell Bearing		
	0 Degrees	60 Degrees	120 Degrees
00	7.0871	7.0872	7.0871
62.	Opposite Drive End - Endbell Bearing	I FIT CONDITION	(P) Pass

63	Bearing Cap Condition	
00.	Drive End Bearing Cap	Opposite Drive End Bearing Cap
	ok	ok
64	End Bell Air Seal Fits	UK
011	Drive End Air Seal	Opposite Drive End Air Seal
	ok	ok
65.	List Machine Work Needed Below	UK
00.	Weld and machine BOTH shaft fits	
66.	Technician	David Maclin
	//	
/		
	Cause of Failure	
67.	Failure locations	
	Cord, bearing fits	
68.	Root cause of failure	
	Cord failure at takeout	
-	nic Balance Report	
69.	Rotor Weight and Balance Grade	
	Rotor Weight	Balance Grade
70.	Initial Balance Readings	
	Drive End	Opposite Drive End
71.	Final Balance Readings	
	Drive End	Opposite Drive End
72.	Technician	
Rewin	nd	
73.	Core Test Results - Watts loss per Pe	ound
	Pre-Burnout	Post Burnout
74.	Core Hot Spot Test	
	Pre-Burnout	Post-Burnout
75		
	Post Rewind Electrical Test- Insulation	on Resistance
	Post Rewind Polarization Index	
//.	Post Rewind Winding Resistance	
	1-2	1-3 2-3
78	Post Rewind Surge Test	
	Post Rewind Hi-Pot	
	Technician	
	anical Fits- Rotor - Post Repair	
	Shaft Runout Post Repair	

82. Rotor Runout Post Repair Opposite Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 83. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 84. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 Degrees 60 Degrees 120 Degrees 88. Shaft Repair Sign-off Assembly Assembly Basembly Basembly 90. Photograph All Major Components prior to Assembly 90 Photograph All Major Components prior to Assembly 90 91. Final Insulation Resistance Test 92 Assembly 93 Assembly 93. Assembled Shaft Runout 94 Test Run Amperage Amps Amps Amps Amps Amps Amps Amps 94. Test Run Amperage Volts Volts Volts 90 95. Drive End Vibration Readings - Inches Per	00	Deter Duneut Deet Deneir			
83. Coupling Fit Closest to Bearing Housing Post Repair 0 Degrees 90 Degrees 120 Degrees 84. Coupling Fit Closest to the end of the Shaft Post Repair 0 0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 0 Degrees 0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 0 Degrees 90 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 0 Degrees 98. Och Check All Parts for Cleanliness Prior to Assembly 9 99. Och Check All Parts for Cleanniness Prior to Assembly 9 90. Photograph All Major Components prior to assembly 9 91. Final Insulation Residence Test 9 92. Assembled Shaft Endplay 9 93. Assembled Shaft Runout 9 94. Test Run Voltage Volts Volts Volts Volts Volts Volts Volts 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second	82.	·			
0 Degrees 90 Degrees 120 Degrees 84. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 87. Shaft Air Seal Fits Post Repair 0 Deprees 60 Degrees 88. Shaft Repair Sign-off Assembly 90 89. OC Check All Parts for Cleanliness Prior to Assembly 90 90. Photograph All Major Components prior to Assembly 90 91. Final Insulation Resistance Test 92 92. Assembled Shaft Endplay 33 93. Assembled Shaft Endplay 93 94. Test Run Voltage Volts Volts Volts Volts Volts 95. Test Run Amperage Amps Amps Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Driv		Drive End Bearing Fit	Rotor Body	Opposite Drive End Bearing	
0 Degrees 90 Degrees 120 Degrees 84. Coupling Fit Closest to the end of the Shaft Post Repair 0 Degrees 60 Degrees 0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 87. Shaft Air Seal Fits Post Repair 0 Deprees 60 Degrees 88. Shaft Repair Sign-off Assembly 90 89. OC Check All Parts for Cleanliness Prior to Assembly 90 90. Photograph All Major Components prior to Assembly 90 91. Final Insulation Resistance Test 92 92. Assembled Shaft Endplay 33 93. Assembled Shaft Endplay 93 94. Test Run Voltage Volts Volts Volts Volts Volts 95. Test Run Amperage Amps Amps Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Driv					
84. Coupling Fit Closest to the end of the Shaft Post Repair 0 0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 0 Degrees 60 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 0 Degrees 60 Degrees 87. Shaft Air Seal Fits Post Repair 0 Degrees 60 Degrees 120 Degrees 88. Shaft Repair Sign-off Assembly Assembly Assembly Assembly 89. OC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Reasitance Test 92. Assembled Shaft Endplay 91. Final Insulation Reasitance Test 92. Assembled Shaft Runout 94. Test Run Voltage Volts Volts Volts 92. Test Run Amperage Amps Amps Amps Amps 93. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 93. Oposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 94. Test Run Amperage Amps Amps Amps Amps 95. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial	83.		÷ ·		
0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 Doposite Drive End Air Seal 120 Degrees 88. Shaft Repair Sign-off Assembly 120 Degrees 99. QC Check All Parts for Cleanliness Prior to Assembly 90 91 91. Final Insulation Resistance Test 120 120 92. Assembled Shaft Endplay 120 120 93. Assembled Shaft Runout 140 140 94. Test Run Voltage Volts Volts Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 14. Torst Run Voltage - Inches Per Second 101 100 197. Opposite Drive End Vibration Readings - Inches Per Second Axial 198. Ambient Temperature - Fahrenheit 15 15 199. Drive End Bearing Temps - Fahrenheit 15 15 100. Opposite Drives End Bearing Temps - Fahrenheit 15 15 101. Document Final Condition with Pictures after paint 15 101		0 Degrees	90 Degrees	120 Degrees	
0 Degrees 60 Degrees 120 Degrees 85. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 Doposite Drive End Air Seal 120 Degrees 88. Shaft Repair Sign-off Assembly 120 Degrees 99. QC Check All Parts for Cleanliness Prior to Assembly 90 91 91. Final Insulation Resistance Test 120 120 92. Assembled Shaft Endplay 120 120 93. Assembled Shaft Runout 140 140 94. Test Run Voltage Volts Volts Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 14. Torst Run Voltage - Inches Per Second 101 100 197. Opposite Drive End Vibration Readings - Inches Per Second Axial 198. Ambient Temperature - Fahrenheit 15 15 199. Drive End Bearing Temps - Fahrenheit 15 15 100. Opposite Drives End Bearing Temps - Fahrenheit 15 15 101. Document Final Condition with Pictures after paint 15 101					
85. Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly Image: State Stat	84.				
0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 Drive End Air Seal Opposite Drive End Air Seal 0 88. Shaft Repair Sign-off 0 0 Assembly 0 0 0 90. QC Check All Parts for Cleanliness Prior to Assembly 0 91. Final Insulation Resistance Test 0 92. Assembled Shaft Endplay 0 93. Assembled Shaft Endplay 0 94. Test Run Voltage Volts Volts Volts Volts Volts Volts 95. Test Run Amperage Armps Amps Armps Armps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal 98. Arbiert Temperature - Fahrenheit 9 99. Drive End Vibration Readings - Inches Per Second Horizontal 98. Arbiert Temperature - Fahrenheit 15 99. Drive End Bearing Temps - Fahrenheit 5 <t< th=""><th></th><th>0 Degrees</th><th>60 Degrees</th><th>120 Degrees</th></t<>		0 Degrees	60 Degrees	120 Degrees	
0 Degrees 60 Degrees 120 Degrees 86. Opposite Drive End Bearing Shaft Fit Post Repair 0 0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair 0 Drive End Air Seal Opposite Drive End Air Seal 0 88. Shaft Repair Sign-off 0 0 Assembly 0 0 0 90. QC Check All Parts for Cleanliness Prior to Assembly 0 91. Final Insulation Resistance Test 0 92. Assembled Shaft Endplay 0 93. Assembled Shaft Endplay 0 94. Test Run Voltage Volts Volts Volts Volts Volts Volts 95. Test Run Amperage Armps Amps Armps Armps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal 98. Arbiert Temperature - Fahrenheit 9 99. Drive End Vibration Readings - Inches Per Second Horizontal 98. Arbiert Temperature - Fahrenheit 15 99. Drive End Bearing Temps - Fahrenheit 5 <t< th=""><th></th><th></th><th></th><th></th></t<>					
86. Opposite Drive End Bearing Shaft Fit Post Repair 0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to Assembly 91. Final Insulation Resistance Test 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts Volts Volts Volts Volts 95. Test Run Amperage Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit 9. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 91. Tost Find Bearing Temps - Fahrenheit 5 Minutes 15 Minutes 100. Opposite Drive End Bearing Temp	85.	· ·			
0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to Assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps Horizontal Vertical Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial		0 Degrees	60 Degrees	120 Degrees	
0 Degrees 60 Degrees 120 Degrees 87. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to Assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps Horizontal Vertical Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial					
87. Shaft Air Seal Fits Post Repair Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Endplay 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 90. Opposite Drive End Bearing Temps - Fahrenheit 91. Test Run test 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint	86.		·	-	
Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Endplay 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Axial 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 91. Axial		0 Degrees	60 Degrees	120 Degrees	
Drive End Air Seal Opposite Drive End Air Seal 88. Shaft Repair Sign-off Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Endplay 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Axial 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 91. Axial	07				
88. Shaft Repair Sign-off Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Endplay 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 90. Drive End Bearing Temps - Fahrenheit 91. Opposite Drive End Bearing Temps - Fahrenheit 92. Opposite Drive End Bearing Temps - Fahrenheit 93. Minutes 15 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 93. Orive End Bearing Temps - Fahrenheit 94. Drive End Bearing Temps - Fahrenheit 95. Minutes 10 Minutes 101. Document Final Condition with Pictures after paint </th <th>87.</th> <th>· ·</th> <th></th> <th></th>	87.	· ·			
Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes		Drive End Air Seal	Opposite Drive End Air Seal		
Assembly 89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes					
89. QC Check All Parts for Cleanliness Prior to Assembly 90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint					
90. Photograph All Major Components prior to assembly 91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts 95. Test Run Amperage Amps Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 91. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 92. Ambient Temperature - Fahrenheit 93. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint		•			
91. Final Insulation Resistance Test 92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 91. Opposite Drive End Bearing Temps - Fahrenheit 92. Ambient Temperature - Fahrenheit 93. Ambient Temperature - Fahrenheit 94. Drive End Bearing Temps - Fahrenheit 95. Trest End Bearing Temps - Fahrenheit 96. Drive End Bearing Temps - Fahrenheit 97. Opposite Drive End Bearing Temps - Fahrenheit 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 910. Opposite Drive End Bearing Temps - Fahrenheit 910. Opposite Drive End Bearing Temps - Fahrenheit 911. Document Final Condition with Pictures after paint	89.		,		
92. Assembled Shaft Endplay 93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 91. Opposite Drive End Bearing Temps - Fahrenheit 92. Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 100. Opposite Drive End Bearing Temps - Fahrenheit 101. Document Final Condition with Pictures after paint	90.	Photograph All Major Components pr	or to assembly		
93. Assembled Shaft Runout 94. Test Run Voltage Volts Volts 95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint	91.	Final Insulation Resistance Test			
94. Test Run Voltage Volts Volts 95. Test Run Amperage Amps Amps Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Axial 98. Ambient Temperature - Fahrenheit Axial 99. Drive End Bearing Temps - Fahrenheit 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes	92.	Assembled Shaft Endplay			
Volts Volts 95. Test Run Amperage	93.	Assembled Shaft Runout			
95. Test Run Amperage Amps Amps 96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint	94.	Test Run Voltage			
Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Axial 98. Ambient Temperature - Fahrenheit Axial 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 15 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes		Volts	Volts	Volts	
Amps Amps Amps 96. Drive End Vibration Readings - Inches Per Second Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Axial 98. Ambient Temperature - Fahrenheit Axial 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 15 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes					
96. Drive End Vibration Readings - Inches Per Second Horizontal Vertical 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 15 Minutes 101. Document Final Condition with Pictures after paint	95.	Test Run Amperage			
Horizontal Vertical Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit Axial 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 15 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes		Amps	Amps	Amps	
Horizontal Vertical Axial 97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit Axial 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 15 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes					
97. Opposite Drive End Vibration Readings - Inches Per Second Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint	96.	Drive End Vibration Readings - Inche	s Per Second		
Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit - 99. Drive End Bearing Temps - Fahrenheit - 5 Minutes 10 Minutes 15 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit - - 5 Minutes 10 Minutes 15 Minutes 101. Document Final Condition with Pictures after paint - -		Horizontal	Vertical	Axial	
Horizontal Vertical Axial 98. Ambient Temperature - Fahrenheit					
98. Ambient Temperature - Fahrenheit 99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 15 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 15 Minutes 101. Document Final Condition with Pictures after paint	97.		-		
99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint		Horizontal	Vertical	Axial	
99. Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint					
5 Minutes 10 Minutes 15 Minutes 100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 5 Minutes 10 Minutes 15 Minutes 101. Document Final Condition with Pictures after paint 10 Minutes 10 Minutes	98.	•			
100. Opposite Drive End Bearing Temps - Fahrenheit 5 Minutes 10 Minutes 101. Document Final Condition with Pictures after paint	99.	 Drive End Bearing Temps - Fahrenheit 			
5 Minutes 10 Minutes 15 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes		5 Minutes	10 Minutes	15 Minutes	
5 Minutes 10 Minutes 15 Minutes 101. Document Final Condition with Pictures after paint 15 Minutes					
101. Document Final Condition with Pictures after paint	100.				
		5 Minutes	10 Minutes	15 Minutes	
102. Final Pics and QC Review			es after paint		
	102.	Final Pics and QC Review			



STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. <u>APPLICABILITY.</u> The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. <u>SCOPE OF GOODS AND/OR SERVICES.</u> The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only be effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. DELIVERY OF GOODS AND/OR SERVICES. Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- 6. DELIVERY SITE AND TIME FOR PERFORMANCE. Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice to Hi-Speed of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

TermsAndConditions

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. LIMITATION OF DAMAGES. HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY</u>. The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. <u>GOVERNING LAW AND JURISDICTION.</u> Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. <u>ABANDONED EQUIPMENT.</u> Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER</u>. No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. <u>ASSIGNMENT.</u> The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. <u>NO INDIVIDUAL LIABILITY</u>. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.