

LR Motor Shop Repairs

Job Number 104650

Prepared for Westrock Coffee

30 Collins Industrial PI North Little Rock AR 72113

Table of Contents

AC Inspection as Found - MOTOR SHOP LR	AC Inspection - Rev. 2: 1LE15232DB234AB4-Z	1.0
AC Random Coil Rewind Report - MOTOR SHOP LR		2.0

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

Printed on 5/27/2025 Powered by INSPECTALL Table of Contents





AC Inspection as Found

Westrock Coffee

30 Collins Industrial PI North Little Rock, AR 72113

FolderID: 104650 FormID: 24514843

AC Inspection - Rev. 2

Location: MOTOR SHOP LR Serial Number: 1LE15232DB234AB4-Z

Description:125 HP SIEMANS

Hi-Speed Job Number:	104650
Manufacturer:	Siemens
Product Number:	1CV3282B
Spec/ID #:	UC2306/339217001
Serial Number:	1LE15232DB234AB4-Z
HP/kW:	125 (HP)
RPM:	1785 (RPM)
Frame:	IP55
Voltage:	460
Current:	136 (Amps)
Phase:	Three
Hz:	60 (Hz)
Service Factor:	1.15
Enclosure:	TEFC
# of Leads:	6
J-box Included:	Complete
Coupling/Sheave:	Coupling
Date Received:	05/21/2025
Bearing RTDs:	No
Stator RTDs:	No
Repair Stage:	Final
Rewind:	Yes
Shaft Machined Fit Repairs Required:	No
Bearing Housing Machined Fit Repairs Required:	No
Heaters:	No
Winding Type :	Random Wound
Bearing Type:	Rolling Element

Priorities Found: 2 - High

9 - Good

Overall Condition

1. Report Date 05/21/2025

Nameplate Picture















- 3. Photos of all six sides of the machine.
- Some pics on nameplate tab



















	4.	Describe the Overall Condition of the Equipment as Received Overloaded	
	5.	Distance from the end of the shaft to the Coupling/Sheave	2.125 inches
	6.	Is this a UL Listed Motor	(No) No
	7.	Is the motor water cooled or can be pressure checked before teardown	(No) No
In	Initial Mechanical/Electrical		
	8.	Does Shaft Turn Freely?	(Y) Yes
	-	Fan hitting something in fan cover	
	9.	Does the shaft require T.I.R in Lathe to identify additional repairs?	(No) No

10.	Does Shaft Have Visible Damage?	(No) No
11.	Assembled Shaft Runout	0 Inches
12.	Assembled Shaft End Play	inches
13.	Air Gap Variation <10%	
14.	Lead Condition	
15.	Lead Length	6 Inches
16.	Does it have Lugs?, If so what is the Stud Size?	(Yes) Yes
-	3/8 eyelet	
17.	Lead Numbers	1-6
18.	Are the Leads insulated with Chico or other material	(No) No
19.	Frame Condition	good
20.	Fan Condition	(F) Fail
-	Needs new fan melted off	
21.	Does motor have internal fan?	(No) No
22.	Broken or Missing Components	
Initial	Electrical Inspection	
	Insulation Resistance/Megger	Megohms
24.	Winding Resistance	
	1-2	2-3
25.	Perform Surge Test	
26.	Number of Stator Slots	48
27.	Stator Condition	overloaded
28.	Stator Thermistors/Ohms	142
29.	Stator Overloads/Ohms	
Mecha	anical Inspection	
30.	Drive End Bearing Brand	FAG
31.	Drive End Bearing Number-	NU317
32.	Drive End Bearing Qty.	1
33.	Drive End Bearing Type	(Roller) Roller Bearing
34.	Drive End Lubrication Type	(Grease) Grease Lubricated
	3	
36.	Drive End Wavy Washer/Snap-Ring Other Retention Device?	bearing cap
37.	Drive End Bearing Condition	loss of lubrication due to overload/misconnection
38.	Opposite Drive End Bearing Brand	3.3333333333
39.	Opposite Drive End Bearing Number-	6317
40.	Opposite Drive End Bearing Qty.	1
41.	Opposite Drive End Bearing Type	(Ball) Ball Bearing
42.	Opposite Drive End Lubrication Type	(Grease) Grease Lubricated
43.	Opposite Drive End Regging Inquistion or Crounding Paying?	
	Opposite Drive End Bearing Insulation or Grounding Device?	
44.	Opposite Drive End Wavy Washer/Snap-Ring Other Retention Device?	
44.	•	
44. 45.	Opposite Drive End Wavy Washer/Snap-Ring Other Retention Device?	
44. 45. 46.	Opposite Drive End Wavy Washer/Snap-Ring Other Retention Device? Opposite Drive End Bearing Condition	

49. Growler Test 50. Number of Rotor Bars 51. Rotor Condition 52. List the Parts needed for the Repair Below 53. Signature of Technician that Disassembled Motor Mechanical Fits- Rotor 54. Shaft Runout inches 55. Rotor Runout Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 65. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit Condition 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Saal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End Bearing Fit Condition 67. Bearing Cap Condition 68. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 68. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End - Endbell Bearing Fit Condition 69. Opposite Drive End Bearing Cap 60. Opposite Drive End - Endbell Bearing Fit Condition 60. Drive End Bearing Cap 61. Opposite Drive End Bearing Cap 62. List Machine Work Needed Below 70. Technician 71. Failure locations 72. Roto cause of failure 71. Failure locations 73. Roto cause of failure 74. Prailure locations 74. Roto cause of failure 75. Proposite Drive End Fits Seal				
51. Rotor Condition 52. List the Parts needed for the Repair Below 53. Signature of Technician that Disassembled Motor Mechanical Fits- Rotor 54. Shaft Runout inches 55. Rotor Runout Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 66. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit 0 Degrees 120 Degrees 50. Drive End Bearing Shaft Fit 0 Degrees 120 Degrees 50. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit Condition 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Pits Drive End Air Seal Opposite Drive End Bearing Fit O Degrees 120 Degrees 63. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit O Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Degrees 60 Degrees 120 Degrees 68. End Belf Air Seal Opposite Drive End Bearing Cap 68. End Belf Air Seal Opposite Drive End Bearing Cap 69. List Machine Work Needed Below 70. Technician 71. Failure locations 72. Roto cause of failure	49.	Growler Test		
52. List the Parts needed for the Repair Below 53. Signature of Technician that Disassembled Motor Mechanical Fits- Rotor 54. Shaft Runout 55. Rotor Runout Drive End Bearing Fit Rotor Body 56. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Opposite Drive End Bearing Shaft Fit Condition 63. Opposite Drive End Bearing Shaft Fit Condition 64. Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 65. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit Obegrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition 67. Bearing Cap Condition 68. End Belf Air Seal Opposite Drive End Bearing Cap 68. End Belf Air Seal Drive End Air Seal 69. List Machine Work Needed Below 70. Technician 71. Failure locations 72. Root cause of failure	50.	Number of Rotor Bars		
53. Signature of Technician that Disassembled Motor Mechanical Fits- Rotor 54. Shaft Runout Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 56. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit Condition 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Opposite Drive End Bearing Cap 69. List Machine Work Needed Below 70. Technician Root Cause of Falture 71. Failure locations 72. Root cause of failure	51.	Rotor Condition		
Mechanical Fits- Rotor Inches	52.	List the Parts needed for the Repair B	elow	
55. Rotor Runout Prive End Bearing Fit Rotor Body Opposite Drive End Bearing Coupling Fit Closest to Bearing Housing O Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft O Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit O Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit O Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits-Bearing Housings 63. Drive End - Endbell Bearing Fit O Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit O Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit O Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit O Degrees 60 Degrees 120 Degrees 67. Bearing Cap Condition 68. End Bell Air Seal Fits Drive End - Endbell Bearing Fit Condition 68. End Bell Air Seal Fits Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure Docations 72. Root cause of failure	53.	Signature of Technician that Disasser	nbled Motor	
55. Rotor Runout Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 56. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit Condition 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Degrees 60 Degrees 120 Degrees 66. End Bearing Cap Opposite Drive End Bearing Cap 68. End Beal Air Seal Fits Drive End Air Seal Opposite Drive End Bearing Cap 69. List Machine Work Needed Below 70. Technician 72. Root cause of Failure 75. Failure locations 77. Root cause of failure	Mecha	anical Fits- Rotor		
Drive End Bearing Fit Rotor Body Opposite Drive End Bearing 56. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician 72. Rott cause of failure	54.	Shaft Runout		inches
56. Coupling Fit Closest to Bearing Housing 0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failture 71. Failture locations 72. Root cause of failture	55.	Rotor Runout		
0 Degrees 90 Degrees 120 Degrees 57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit Condition 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Fits Drive End Air Seal Fits Drive End Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		Drive End Bearing Fit	Rotor Body	Opposite Drive End Bearing
57. Coupling Fit Closest to the end of the Shaft 0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Opposite Drive End Air Seal 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Opposite Drive End Bearing Cap 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Faillure 71. Failure locations 72. Root cause of Faillure	56.	Coupling Fit Closest to Bearing Housi	ng	
0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit		0 Degrees	90 Degrees	120 Degrees
0 Degrees 60 Degrees 120 Degrees 58. Drive End Bearing Shaft Fit				
58. Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician 70. Technician 71. Failure locations 72. Root cause of failure	57.			
0 Degrees 60 Degrees 120 Degrees 59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit Condition 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician 70. Technician 71. Failure locations 72. Root cause of failure		0 Degrees	60 Degrees	120 Degrees
59. Drive End Bearing Shaft Fit Condition 60. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 61. Drive End - Endbell Bearing Fit 0 Degrees 62. Drive End - Endbell Bearing Fit 0 Degrees 63. Drive End - Endbell Bearing Fit 0 Degrees 64. Drive End - Endbell Bearing Fit 0 Degrees 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition 68. End Bell Air Seal Fits 68. End Bell Air Seal Fits 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	58.	Drive End Bearing Shaft Fit		
60. Opposite Drive End Bearing Shaft Fit 0 Degrees 60 Degrees 120 Degrees 61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		0 Degrees	60 Degrees	120 Degrees
61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	59.	Drive End Bearing Shaft Fit Condition		
61. Opposite Drive End Bearing Shaft Fit Condition 62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	60.	Opposite Drive End Bearing Shaft Fit		
62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		0 Degrees	60 Degrees	120 Degrees
62. Shaft Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	61.	Opposite Drive End Bearing Shaft Fit	Condition	
Mechanical Fits- Bearing Housings 63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure				
63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		Drive End Air Seal	Opposite Drive End Air Seal	
63. Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	Mecha	anical Fits- Bearing Housings		
0 Degrees 60 Degrees 120 Degrees 64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure				
64. Drive End - Endbell Bearing Fit Condition 65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure			60 Degrees	120 Degrees
65. Opposite Drive End - Endbell Bearing Fit 0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure			5	Ü
0 Degrees 60 Degrees 120 Degrees 66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		-		
66. Opposite Drive End - Endbell Bearing Fit Condition 67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	65.	Opposite Drive End - Endbell Bearing	Fit	
67. Bearing Cap Condition Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		0 Degrees	60 Degrees	120 Degrees
Drive End Bearing Cap Opposite Drive End Bearing Cap 68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	66.	Opposite Drive End - Endbell Bearing	Fit Condition	
68. End Bell Air Seal Fits Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	67.	Bearing Cap Condition		
Drive End Air Seal Opposite Drive End Air Seal 69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		Drive End Bearing Cap	Opposite Drive End Bearing Cap	
69. List Machine Work Needed Below 70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure	68.	End Bell Air Seal Fits		
70. Technician Root Cause of Failure 71. Failure locations 72. Root cause of failure		Drive End Air Seal	Opposite Drive End Air Seal	
Root Cause of Failure 71. Failure locations 72. Root cause of failure	69.	List Machine Work Needed Below		
71. Failure locations 72. Root cause of failure	70.	Technician		
72. Root cause of failure	Root	Cause of Failure		
	71.	Failure locations		
Dynamic Balance Report	72.	Root cause of failure		
• • • • • • • • • • • • • • • • • • •	Dynar	nic Balance Report		



74.	Initial Balance Readings		
	Drive End	Opposite Drive End	
	1.14	3.48	
75.	Final Balance Readings		
	Drive End	Opposite Drive End	
	0.11	0.15	
76.	Technician		TH

Rewind

Assembly

I C WII	ii u			
77.	Core Test Results - Watts loss per Po	bund		
	Pre-Burnout	Post Burnout		
78.	Core Hot Spot Test			
	Pre-Burnout	Post-Burnout		
79.	Post Rewind Electrical Test- Insulation	n Resistance		Megohms
80.	Post Rewind Polarization Index			Polarization Index
81.	Post Rewind Winding Resistance			
	1-2	1-3	2-3	
82.	Post Rewind Surge Test			
83.	Post Rewind Hi-Pot			micro-amps
84.	Technician			





86. Photograph All Major Components prior to assembly

(Complete) Complete









87. Final Insulation Resistance Test

22,300 Megohms



lplay	
	play

0 inches

89. Assembled Shaft Runout

0 inches

90. Test Run Voltage			
Volts	Volts	Volts	
457	456	458	



Co sign TH

91. Test Run Amperage		
Amps	Amps	Amps
51.1	49.8	48.6



92.	92. Drive End Vibration Readings - Inches Per Second		
	Horizontal	Vertical	Axial
	0.08	0.04	0.02
93.	Opposite Drive End Vibration Reading	s - Inches Per Second	
	Horizontal	Vertical	Axial
	0.05	0.02	0.01
94.	Ambient Temperature - Fahrenheit		
95.	Drive End Bearing Temps - Fahrenhe	it	
	5 Minutes	10 Minutes	15 Minutes
96.	Opposite Drive End Bearing Temps -	Fahrenheit	
	5 Minutes	10 Minutes	15 Minutes
97.	Document Final Condition with Picture	es after paint	









98. Final Pics and QC Review

Co sign TH

RW



FolderID: 104650 FormID: 24526725



AC Random Coil Rewind Report

Westrock Coffee

30 Collins Industrial PI North Little Rock, AR 72113

MOTOR SHOP LR

Priorities Found: 5 - Good

Gene	ral	
1.	Job Number	104650
2.	Report Date	05/21/2025
3.	Customer	Westrock Coffee
Stato	· Winding	
4.	Core Length	14 "
5.	Core ID	11.625 "
6.	Back Iron Depth	1.625 "
7.	Slot Depth	1.2 "
8.	Tooth Width	0.375 "
9.	Number of Vents	0
10.	Vent Width	п
11.	Before Burnout Core loss	(P) Pass
12.	Flux Before Burnout	
13.	Watts before burnout	Watts
14.	Watts loss per lb. before burnout	1.23 W/lbs.
15.	After Burnout Core Loss	(P) Pass
16.	Flux After burnout	
17.	Watts After Burnout	Watts
18.	Watts loss per lb After Burnout	1.161 W/lbs.
19.	Core Iron Condition	
20.	RTD's	
21.	RTD's Reading	Ohm's
22.	Motor Heaters	
23.	Heater Qty.	
24.	Heater Voltage	Volts
25.	<u> </u>	Watts
2 6.	Thermistors	(Y) Yes
-	142 ohms	
27.	Number of Poles	4
28.	Slots	48
29.		
30.		
31.	Lead Markings	
	1-6	
32.	Grouping	
	12g of 2c	

33.	Multiple Wires	
34.	Wire Size	
	10 #1.25 metric 8 #1.4 metric	
35.	Turns per coil	6
36.	Pitch 1 to:	
-	1-10,12	
37.	Connection	
	1 wye delta	
38.	Lead Length	6 "
39.	Lead Size	none
40.	Number of Leads	6
41.	Megger Reading After Rewind	9045 Mohms



42. Coil Machine Slot

43. Coil Machine Tip

44. Coil Machine Pitch

45. Hi Pot Reading After Rewind

0.06233 Ua



46. Surge Pattern After Rewind

(P) Pass



47. Service Technician

3.5 conn and opp conn end



STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. APPLICABILITY. The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. SCOPE OF GOODS AND/OR SERVICES. The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only bee effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. <u>DELIVERY OF GOODS AND/OR SERVICES.</u> Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- **DELIVERY SITE AND TIME FOR PERFORMANCE.** Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have sixty (60) days to cure the alleged discrepancy and/or nonconformance. If Hi-Speed fails to cure in this time period, Buyer shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed. Buyer shall notify Hi-Speed and arrange for the return of the goods as required. Should such non-conforming services be rejected Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. <u>LIMITATION OF DAMAGES.</u> HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY.</u> The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. **GOVERNING LAW AND JURISDICTION.** Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. ABANDONED EQUIPMENT. Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER.</u> No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. **ASSIGNMENT.** The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. NO INDIVIDUAL LIABILITY. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.