

# EVERY DAY SINCE 1946

**Motor Shop Repairs** 

# Job Number 99353

Prepared for US MOTORS WARRANTY REPAIR

8100 W. FLORISSENT ST. LOUIS MO 63136

# Table of Contents

AC Recondition Repair Report



Hi-Speed Industrial Service 7030 Ryburn Dr Millington, Tn 38053 901-873-5300

**AC Recondition Repair Report** 

# US MOTORS WARRANTY REPAIR

8100 W. FLORISSENT ST. LOUIS, MO 63136

Priorities Found:	🔵 7 - High	🔵 17 - Good

## General

- 1. Job Number
- 2. Report Date
- 3. Customer
- For Lone Star Blower Co.

## Name Plate Information

4. Manufacturer









Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

FormID: 12769662

FolderID: 99353

2/7/2022 US Motors Warranty Division

99353

**US Motors** 







5.	Model	
6.	Serial Number	A 0820190501-0001 R 0002
7.	Horsepower	400
8.	KW	
9.	Volts	460
10.	Amps	426
11.	RPM	3565
12.	Frame	449TS
13.	Enclosure	TEFC
14.	Cycles	60
15.	Phase	3
16.	Service Factor	1.15
17.	Motor Mount Position	
Initial	Inspection	
18.	Number of Leads	12
19.	Lead Length	24 Inches
20.	Lead Size	
21.	Lead Condition	(P) Pass
22.	Lead Markings	1111, 2222, 3333

23. Lug Size, Condition, and Type



25.	Winding Rtd's Condition	(P) Pass
26.	Shaft Run Out	0.001
27.	Does Shaft Turn Freely	no
	Locked up	
28.	Does Shaft Have Visible Damage	no



29. Bearing Rtd's 



Bearing Rtd's Condition 30. ц. 108 ohms

# 31. Contamination

1.2

(Y) Yes

(P) Pass

A small amount of melted grease



32.	Frame Condition	(P) Pass
33.	Fan Condition	(P) Pass



34. Broken or missing components	
Initial Electric Test	
35. Resistance to Ground	7000 Mohm
36. Winding Resistance 1-2	
37. Winding Resistance 2-3	
38. Winding Resistance 1-3	
39. Resistive Imbalance	
40. Hi-Pot	Ua



42. Stator Condition





43. Failure Location	
Initial Rotor Inspection	
44. Rotor Type	cast aluminum
45. Air Gap <10% Variation	
46. Number of Rotor Bars	34
47. Number of Broken Rotor Bars	0





# 49. Rotor Condition Mechanical Inspection

50. Bearing Manufacture



51. Bearing DE Size



52. Bearing DE Type	ball
53. DE Bearing Qty.	1
54. Bearing ODE Size	6315-b-c3
55. Bearing ODE Type	ball

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

Printed on 2/10/2022



kbc

6315-b-c3

- 56. ODE Bearing Qty.
- 57. Insulated Bearing
- Shaft is insulated



- 58. Lubrication Type
- 59. Grease Condition



60. Bearing Retainers





Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.



(Y) Yes

pink grease

(F) Fail



1 no



61.	Shaft Grounding Device	(N) No
62.	DE Seal	(Y) Yes
•	Labrynth	
63.	DE Seal Type/Size	
64.	ODE Seal	(Y) Yes
	Labrynth	



65. ODE Seal Type/Size Root Cause of Failure

#### 66. Component Failure

#### drive end shaft, bearings, bearing cap







6	67.	Cause of Failure
6	58.	Comments
6	59.	Service Technician
Ма	chi	ne Fit Inspection Report
• 7	70.	Shaft Run Out (P) Pass
7	71.	Initial Shaft Run Out 0.001 "
7	72.	Final Shaft Run Out
• 7	73.	DE Bearing Shaft Fit (F) Fail



74.	DE Initial Shaft Bearing Fit Size 1	2.9515 "
75.	DE Initial Shaft Bearing Fit Size 2	2.9515 "
76.	DE Initial Shaft Bearing Fit Size 3	2.9515 "
77.	DE Finial Shaft Bearing Fit Size 1	
78.	DE Finial Shaft Bearing Fit Size 2	
79.	DE Finial Shaft Bearing Fit Size 3	
80	ODE Bearing Shaft Eit	(F) Fail

80. ODE Bearing Shaft FitUndersized

(F) Fail



81.	ODE Initial Shaft Bearing Fit Size 1	2.9527 "
82.	ODE Initial Shaft Bearing Fit Size 2	2.9523 "
83.	ODE Initial Shaft Bearing Fit Size 3	2.952 "
84.	ODE Finial Shaft Bearing Fit Size 1	
85.	ODE Finial Shaft Bearing Fit Size 2	
86.	ODE Finial Shaft Bearing Fit Size 3	
87.	DE Air Seal Shaft Fit	
88.	DE Initial Air Seal Shaft Size	
89.	DE Final Air Seal Shaft Size	
90.	ODE Air Seal Shaft Fit	
91.	ODE Initial Air Seal Shaft Size	
92.	ODE Final Air Seal Shaft Size	
93.	DE Endbell Fit	(F) Fail



94. DE Initial Endbell Fit Size 1

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

6.3027 "

<ul> <li>119. Balance Type</li> <li>120. Balance Operating Speed</li> <li>121. Start Left End</li> <li>122. Start Right End</li> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> </ul>	95.	DE Initial Englishell Ett Circo 2		
97. DE Final Endbell Fit Size 1 98. DE Final Endbell Fit Size 2 90. DE Final Endbell Fit Size 3 100. DE Endbell Fit Issulated (N) No 101. DE Endbell Fit Issulated (N) No 102. Initial Endbell Air Seal Fit Size 103. Final Endbell Fit Size 1 104. ODE Endbell Fit Size 4 105. ODE Initial Endbell Fit Size 1 105. ODE Initial Endbell Fit Size 1 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 100. ODE Final Endbell Fit Size 4 100. Endbell Fit Size 4 105. Service Technician 105. For Condition 104. Finish Left End 105. Service Technician 105. Service Technician 105		De Initial Endbell Fit Size 2	6.3027 "	
98. DE Finial Endbell Fit Size 2 99. DE Final Endbell Fit Size 3 100. DE Endbell Fit Issulated (N) No 101. DE Endbell Fit Issulated (N) No 102. Endbell Air Seal Fit Size 103. Finial Endbell Air Seal Fit Size 104. ODE Endbell Fit Size 1 105. ODE Initial Endbell Fit Size 2 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 2 109. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 2 100. ODE Final Endbell Fit Size 2 100. ODE Final Endbell Fit Size 3 100. ODE Final Endbell Fit Size 4	96.	DE Initial Endbell Fit Size 3	6.3027 "	
99. DE Final Endbell Fit Issuated       (N) No         100. DE Endbell Air Seal Fit Size       (P) Pass         103. Final Endbell Air Seal Fit Size       (P) Pass         104. ODE Endbell Fit       (P) Pass         105. ODE Initial Endbell Fit Size 1       6.3012 *         106. ODE Initial Endbell Fit Size 2       6.3012 *         107. ODE Initial Endbell Fit Size 1       6.3012 *         108. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Endbell Fit Insulated       (N) No         111. ODE Endbell Fit Size 3       (N) No         112. ODE Endbell Fit Size 1       (P) Pass         114. ODE Finial Endbell Fit Size       (P) Pass         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       Trever Hall         118. Service Technician       Trever Hall         212. Start Kight End       [2]         22. Start Kight End       [2]         23. Sta	97.	DE Final Endbell Fit Size 1		
100. DE Endbell Air Seal Fit         101. DE Endbell Air Seal Fit Size         102. Initial Endbell Air Seal Fit Size         103. Finial Endbell Air Seal Fit Size         104. ODE Endbell Fit Size 1         105. ODE Initial Endbell Fit Size 2         106. ODE Initial Endbell Fit Size 1         107. ODE Initial Endbell Fit Size 1         108. ODE Final Endbell Fit Size 3         109. ODE Final Endbell Fit Size 3         109. ODE Final Endbell Fit Size 3         101. ODE Final Endbell Fit Size 3         111. ODE Endbell Fit Size 3         112. ODE Initial Endbell Fit Size 3         113. ODE Final Endbell Fit Size 3         114. ODE Final Endbell Fit Size 3         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technican       Trevor Hall <b>Status Endbell</b> Seel Fit       111         118. Service Technican       (P) Pass         114. DOE Final Endbell Fit Size       (P) Pass         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Benvice Technican       Trevor Hall         22. Start Right End       (P)	98.	DE Finial Endbell Fit Size 2		
101. DE Endbell Air Seal Fit Size         103. Finial Endbell Air Seal Fit Size         104. ODE Endbell Fit       (P) Pass         # Housing is .001 oversized       6.3012 *         105. ODE Initial Endbell Fit Size 1       6.3012 *         106. ODE Initial Endbell Fit Size 2       6.3012 *         107. ODE Initial Endbell Fit Size 3       6.3012 *         108. ODE Final Endbell Fit Size 3       6.3012 *         109. ODE Final Endbell Fit Size 3       6.3012 *         100. ODE Final Endbell Fit Size 3       6.3012 *         111. ODE Endbell Fit Size 3       6.3012 *         112. ODE Endbell Fit Size 3       (N) No         113. ODE Initial Endbell Seal Fit Size       (P) Pass         114. ODE Endbell Seal Fit Size       (P) Pass         115. Foot Chatterss       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Motion Speed       113. Service Technician         119. Balance Type       113. Service Technician         120. Endbell Fit Bit M       114 Motion         121. Start Left End       115 Motion         122. Start Right End       114 Motion         123. Balancing Speedification       114 Motio	99.	DE Final Endbell Fit Size 3		
102. Initial Endbell Air Seal Fit Size         103. Finial Endbell Air Seal Fit Size         104. ODE Endbell Fit       (P) Pass         105. ODE Initial Endbell Fit Size 1       6.3012 *         106. ODE Initial Endbell Fit Size 1       6.3012 *         107. ODE Initial Endbell Fit Size 2       6.3012 *         108. ODE Final Endbell Fit Size 3       6.3012 *         109. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 3       (N) No         111. ODE Endbell Fit Size 3       (N) No         112. ODE Initial Endbell Seal Fit Size       (P) Pass         113. ODE Initial Endbell Seal Fit Size       (P) Pass         114. ODE Final Endbell Fit Size 5       (P) Pass         115. Foot Finateness       (P) Pass         116. Foot Condition       (P) Pass         117. Finage Condition       (P) Pass         118. Service Technician       Trevor Hall         Trevor Hall         Service Technician         Trevor Hall         Service Technician         Trevor Hall         Service Technician         Trevor Hall         Service Technician          (T) <tr< td=""><td>100.</td><td>DE Endbell Fit Insulated</td><td>(N) No</td></tr<>	100.	DE Endbell Fit Insulated	(N) No	
103. Finial Endbell Air Seal Fit Size         104. ODE Endbell Fit         105. ODE Initial Endbell Fit Size 1         106. ODE Initial Endbell Fit Size 2         107. ODE Initial Endbell Fit Size 3         108. ODE Final Endbell Fit Size 3         109. ODE Final Endbell Fit Size 3         100. ODE Final Endbell Fit Size 3         101. ODE Endbell Fit Size 3         102. ODE Final Endbell Fit Size 3         103. ODE Final Endbell Fit Size 3         114. ODE Endbell Air Seal Fit         113. ODE Initial Endbell Seal Fit Size         114. ODE Endbell Air Seal Fit Size         115. Foot Final Endbell Seal Fit Size         116. Foot Condition         117. Finage Condition         117. Finage Condition         118. Service Technician         Trevor Hall         MOMENTIAL Endbell Speed         112. Start Left End         113. Specification         114. Service Technician         Trevor Hall         MOMENTIAL Endbell Speed         117. Finage Condition         118. Service Technician         Trevor Hall         119. Balance Type         120. Balance Operating Speed         121. Start Left End         122. Strait Right End         123. Balancing S	101.	DE Endbell Air Seal Fit		
104. ODE Endbell Fit       (P) Pass         Housing Is .001 oversized       6.3012 *         105. ODE Initial Endbell Fit Size 1       6.3012 *         106. ODE Initial Endbell Fit Size 2       6.3012 *         107. ODE Initial Endbell Fit Size 3       6.3012 *         108. ODE Final Endbell Fit Size 1       6.3012 *         109. ODE Final Endbell Fit Size 2       6.3012 *         110. ODE Endbell Fit Size 3       6.3012 *         111. ODE Endbell Fit Size 3       (N) No         112. ODE Endbell Fit Size 3       (N) No         113. ODE Initial Endbell Seal Fit       (P) Pass         114. ODE Endbell Fit Noulated       (P) Pass         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall <b>Motion Report</b> 119. Balance Type         120. Balance Operating Speed       121. Start Left End         121. Start Left End       122. Start Right End         122. Start Right End       123. Balancing Specification         123. Balancing Specification       124. Finish Left End         124. Finish Right End       125. Finish Right End         125. Finish Right End       126. Service Technician	102.	Initial Endbell Air Seal Fit Size		
Housing is .001 oversized         105. ODE Initial Endbell Fit Size 1       6.3012 "         106. ODE Initial Endbell Fit Size 2       6.3012 "         107. ODE Initial Endbell Fit Size 1       6.3012 "         108. ODE Final Endbell Fit Size 2       6.3012 "         109. ODE Final Endbell Fit Size 3       6.3012 "         101. ODE Endbell Fit Size 3       6.3012 "         111. ODE Endbell Fit Size 3       (N) No         112. ODE Endbell Fit Insulated       (N) No         113. ODE Endbell Fit Size 3       (P) Pass         114. ODE Endbell Fit Size 3       (P) Pass         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall <b>Mathematic State St</b>	103.	Finial Endbell Air Seal Fit Size		
<ul> <li>Housing is .001 oversized</li> <li>ODE Initial Endbell Fit Size 1</li> <li>G.3012 "</li> <li>ODE Initial Endbell Fit Size 2</li> <li>G.3012 "</li> <li>ODE Finial Endbell Fit Size 3</li> <li>ODE Finial Endbell Fit Size 3</li> <li>ODE Finial Endbell Fit Size 3</li> <li>ODE Endbell Fit Insulated</li> <li>(N) No</li> <li>ODE Endbell Fit Insulated</li> <li>(N) No</li> <li>ODE Endbell Fit Insulated</li> <li>(N) No</li> <li>ODE Endbell Fit Insulated</li> <li>(P) Pass</li> <li>I15. Foot Flantess</li> <li>(P) Pass</li> <li>I16. Foot Condition</li> <li>(P) Pass</li> <li>I17. Flanges Condition</li> <li>(P) Pass</li> <li>I18. Service Technician</li> <li>Trevor Hall</li> <li>Start Left End</li> <li>I20. Balance Operating Speed</li> <li>I21. Start Left End</li> <li>I22. Start Right End</li> <li>I23. Finish Right End</li> <li>I24. Finish Right End</li> <li>I25. Finish Right End</li> <li>I26. Service Technician</li> <li>Karge Testing Reading</li> <li>I27. Megaar Testing Reading</li> <li>I28. Surge Testi</li> <li>I28. Surge Testi</li> <li>I29. Hi-Pot</li> </ul>	104.	ODE Endbell Fit	(P) Pass	
106. ODE Initial Endbell Fit Size 2       6.3012 *         107. ODE Initial Endbell Fit Size 3       6.3012 *         108. ODE Final Endbell Fit Size 1	<b>.</b>	Housing is .001 oversized		
107. ODE Initial Endbell Fit Size 3       6.3012 **         108. ODE Final Endbell Fit Size 1       109. ODE Final Endbell Fit Size 2         110. ODE Final Endbell Fit Size 3       (N) No         111. ODE Endbell Fit Insulated       (N) No         112. ODE Endbell Fit Insulated       (N) No         113. ODE Initial Endbell Seal Fit       (P) Pass         114. ODE Final Endbell Fit Size       (P) Pass         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Mathematica Service Technician         Trevor Hall         Mathematica Service Technician         Trevor Hall         Mathematica Service Technician         Trevor Hall         Mathematica Service Technician         Mathematica Service Technician         Mathematica Service Technician         Trevor Hall         119. Balance Type         112. Start Left End         123. Balancing Specification         124. Finish Left End         125. Finish Right End <td col<="" td=""><td>105.</td><td>ODE Initial Endbell Fit Size 1</td><td>6.3012 "</td></td>	<td>105.</td> <td>ODE Initial Endbell Fit Size 1</td> <td>6.3012 "</td>	105.	ODE Initial Endbell Fit Size 1	6.3012 "
108. ODE Final Endbell Fit Size 1         109. ODE Final Endbell Fit Size 2         111. ODE Endbell Fit Isulated       (N) No         112. ODE Endbell Fit Isulated       (N) No         113. ODE Initial Endbell Seal Fit Size       (P) Pass         114. ODE Final Endbell Seal Fit Size       (P) Pass         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Trevor Hall         Service Technician         Trevor Hall         Trevor Hall <td< td=""><td>106.</td><td>ODE Initial Endbell Fit Size 2</td><td>6.3012 "</td></td<>	106.	ODE Initial Endbell Fit Size 2	6.3012 "	
109. ODE Final Endbell Fit Size 2         110. ODE Final Endbell Fit Insulated         111. ODE Endbell Fit Insulated         112. ODE Endbell Air Seal Fit         113. ODE Initial Endbell Seal Fit Size         114. ODE Finial Endbell Seal Fit Size         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Trevor Hall         Mathematical State	107.	ODE Initial Endbell Fit Size 3	6.3012 "	
110. ODE Final Endbell Fit Issuated       (N) No         111. ODE Endbell Fit Insulated       (N) No         112. ODE Endbell Air Seal Fit       (N) No         113. ODE Initial Endbell Seal Fit Size       (P) Pass         114. ODE Finial Endbell Seal Fit Size       (P) Pass         115. Foot Condition       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Mathematication of the service Technician         Trevor Hall         Mathematication of the service Technician         Trevor Hall         Mathematication of the service Technician         Trevor Hall         Mathematication of the service Technician         Trevor Hall         Mathematication of the service Technician         Mathematication of the service Technician         Mathematication of the service Technician         Assembly and Final Test         127. Meggar Testing Reading         128. Surge Test         129. Hi-Pot	108.	ODE Final Endbell Fit Size 1		
111. ODE Endbell Fit Insulated(N) No112. ODE Endbell Air Seal Fit113. ODE Initial Endbell Seal Fit Size114. ODE Finial Endbell Seal Fit Size115. Foot Flatness(P) Pass116. Foot Condition(P) Pass117. Flange Condition(P) Pass118. Service TechnicianTrevor HallMathematical Service TechnicianTrevor Hall119. Balance Type120. Balance Operating Speed121. Start Left End122. Start Right End123. Balancing Specification124. Finish Left End125. Finish Right End125. Finish Right End126. Service TechnicianAssembly and Final Test127. Meggar Testing Reading128. Hi-Pot	109.	ODE Final Endbell Fit Size 2		
111. ODE Endbell Fit Insulated(N) No112. ODE Endbell Air Seal Fit113. ODE Initial Endbell Seal Fit Size114. ODE Finial Endbell Seal Fit Size115. Foot Flatness(P) Pass116. Foot Condition(P) Pass117. Flange Condition(P) Pass118. Service TechnicianTrevor HallMathematical Service TechnicianTrevor Hall119. Balance Type120. Balance Operating Speed121. Start Left End122. Start Right End123. Balancing Specification124. Finish Left End125. Finish Right End125. Finish Right End126. Service TechnicianAssembly and Final Test127. Meggar Testing Reading128. Hi-Pot				
112. ODE Endbell Air Seal Fit         113. ODE Initial Endbell Seal Fit Size         114. ODE Finial Endbell Seal Fit Size         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Mathematical Service Technician         Trevor Hall         Mathematical Service Technician         Balancing Repot         119. Balance Type         120. Balance Operating Speed       121.         121. Start Left End       122.         122. Start Right End       123.         123. Balancing Specification       124.         124. Finish Left End       125.         125. Finish Right End       126.         126. Service Technician       127.         Meggar Testing Reading         127. Meggar Testing Reading       128.         128. Surge Test       129. Hi-Pot	111.	ODE Endbell Fit Insulated	(N) No	
114. ODE Finial Endbell Seal Fit Size         115. Foot Flatness       (P) Pass         116. Foot Condition       (P) Pass         117. Flange Condition       (P) Pass         118. Service Technician       Trevor Hall         Trevor Hall         Selancing Report         119. Balance Type       Image: Colspan="2">Trevor Hall         120. Balance Operating Speed       Image: Colspan="2">Image: Colspan="2">Trevor Hall         121. Start Left End       Image: Colspan="2">Image: Colspan="2">Trevor Hall         122. Start Right End       Image: Colspan="2">Image: Colspan="2">Trevor Hall         123. Balance Type       Image: Colspan="2">Image: Colspan="2">Trevor Hall         124. Finish Left End       Image: Colspan="2">Image: Colspan="2">Trevor Hall         125. Finish Right End       Image: Colspan="2">Image: Colspan="2">Trevor Hall         126. Service Technician       Image: Colspan="2">Trevor Hall         127. Meggar Testing Reading       Image: Colspan="2">Testing Reading         128. Surge Test       Image: Colspan="2">Image: Colspan="2">Testing Reading         129. Hi-Pot       Image: Colspan="2">Testing Reading	112.	ODE Endbell Air Seal Fit		
115. Foot Flatness(P) Pass116. Foot Condition(P) Pass117. Flange ConditionTrevor Hall118. Service TechnicianTrevor HallMethods and the service TechnicianBalancing Report119. Balance Type120. Balance Operating Speed121. Start Left End122. Start Right End123. Balancing Specification124. Finish Left End125. Finish Right End126. Service TechnicianAssembly and Final Test127. Meggar Testing Reading128. Surge Test129. Hi-Pot	113.	ODE Initial Endbell Seal Fit Size		
116. Foot Condition       (P) Pass         117. Flange Condition       Trevor Hall         118. Service Technician       Trevor Hall         Mathematical Service Technician         Trevor Hall         Selancing Report         119. Balance Type          120. Balance Operating Speed          121. Start Left End          122. Start Right End          123. Balancing Specification          124. Finish Left End          125. Finish Right End          126. Service Technician          Assembly and Final Test         127. Meggar Testing Reading          128. Surge Test          129. Hi-Pot	114.	ODE Finial Endbell Seal Fit Size		
116. Foot Condition(P) Pass117. Flange ConditionTrevor Hall118. Service TechnicianTrevor HallTrevor HallTrevor HallSelancing Report119. Balance Type120. Balance Operating Speed121. Start Left End122. Start Right End123. Balancing Specification124. Finish Left End125. Finish Right End126. Service TechnicianAssembly and Final Test127. Meggar Testing Reading128. Surge Test129. Hi-Pot	115.	Foot Flatness	(P) Pass	
117. Flange Condition       Trevor Hall         118. Service Technician       Trevor Hall         Main and the service Technician         Balancing Report         119. Balance Type       10         120. Balance Operating Speed       10         121. Start Left End       10         122. Start Right End       10         123. Balancing Specification       10         124. Finish Left End       10         125. Finish Right End       10         126. Service Technician       10         Assembly and Final Test         127. Meggar Testing Reading         128. Surge Test       129. Hi-Pot				
118. Service TechnicianTrevor Hall118. Service TechnicianTrevor Hall119. Balance Type100119. Balance Type100120. Balance Operating Speed100121. Start Left End100122. Start Right End100123. Balancing Specification100124. Finish Left End100125. Finish Right End100126. Service Technician100Assembly and Final Test100127. Meggar Testing Reading100128. Surge Test100129. Hi-Pot100	116.	Foot Condition	(P) Pass	
<ul> <li>119. Balance Type</li> <li>120. Balance Operating Speed</li> <li>121. Start Left End</li> <li>122. Start Right End</li> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> </ul> Assembly and Final Test 127. Meggar Testing Reading 128. Surge Test 129. Hi-Pot	117.	Flange Condition		
<ul> <li>120. Balance Operating Speed</li> <li>121. Start Left End</li> <li>122. Start Right End</li> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> <li>Assembly and Final Test</li> <li>127. Meggar Testing Reading</li> <li>128. Surge Test</li> <li>129. Hi-Pot</li> </ul>	117.	Flange Condition		
<ul> <li>120. Balance Operating Speed</li> <li>121. Start Left End</li> <li>122. Start Right End</li> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> <li>Assembly and Final Test</li> <li>127. Meggar Testing Reading</li> <li>128. Surge Test</li> <li>129. Hi-Pot</li> </ul>	117. 118.	Flange Condition Service Technician		
<ul> <li>121. Start Left End</li> <li>122. Start Right End</li> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> <li>Assembly and Final Test</li> <li>127. Meggar Testing Reading</li> <li>128. Surge Test</li> <li>129. Hi-Pot</li> </ul>	117. 118. <b>Balan</b>	Flange Condition Service Technician		
<ul> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> <li>Assembly and Final Test</li> <li>127. Meggar Testing Reading</li> <li>128. Surge Test</li> <li>129. Hi-Pot</li> </ul>	117. 118. <b>Balan</b> 119.	Flange Condition Service Technician Cing Report Balance Type		
<ul> <li>123. Balancing Specification</li> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> <li>Assembly and Final Test</li> <li>127. Meggar Testing Reading</li> <li>128. Surge Test</li> <li>129. Hi-Pot</li> </ul>	117. 118. <b>Balano</b> 119. 120.	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed		
<ul> <li>124. Finish Left End</li> <li>125. Finish Right End</li> <li>126. Service Technician</li> </ul> Assembly and Final Test 127. Meggar Testing Reading 128. Surge Test 129. Hi-Pot	<ul> <li>117.</li> <li>118.</li> <li><b>Balane</b></li> <li>119.</li> <li>120.</li> <li>121.</li> </ul>	Flange Condition Service Technician Constraint Constraint Constrai		
<ul> <li>125. Finish Right End</li> <li>126. Service Technician</li> <li>Assembly and Final Test</li> <li>127. Meggar Testing Reading</li> <li>128. Surge Test</li> <li>129. Hi-Pot</li> </ul>	<ul> <li>117.</li> <li>118.</li> <li>3aland</li> <li>119.</li> <li>120.</li> <li>121.</li> <li>122.</li> </ul>	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed Start Left End Start Right End		
126. Service Technician         Assembly and Final Test         127. Meggar Testing Reading         128. Surge Test         129. Hi-Pot	<ul> <li>117.</li> <li>118.</li> <li>3alane</li> <li>119.</li> <li>120.</li> <li>121.</li> <li>122.</li> <li>123.</li> </ul>	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed Start Left End Start Right End Balancing Specification		
Assembly and Final Test 127. Meggar Testing Reading 128. Surge Test 129. Hi-Pot	<ul> <li>117.</li> <li>118.</li> <li>3aland</li> <li>119.</li> <li>120.</li> <li>121.</li> <li>122.</li> <li>123.</li> <li>124.</li> </ul>	Flange Condition         Service Technician         Image: Condition         Image: Condition         Cing Report         Balance Type         Balance Operating Speed         Start Left End         Start Right End         Balancing Specification         Finish Left End		
<ul><li>127. Meggar Testing Reading</li><li>128. Surge Test</li><li>129. Hi-Pot</li></ul>	<ul> <li>117.</li> <li>118.</li> <li>3alane</li> <li>119.</li> <li>120.</li> <li>121.</li> <li>122.</li> <li>122.</li> <li>123.</li> <li>124.</li> <li>125.</li> </ul>	Flange Condition         Service Technician         Image: Condition         cing Report         Balance Type         Balance Operating Speed         Start Left End         Start Right End         Balancing Specification         Finish Left End         Finish Left End		
128. Surge Test 129. Hi-Pot	<ul> <li>117.</li> <li>118.</li> <li>3alan</li> <li>119.</li> <li>120.</li> <li>121.</li> <li>122.</li> <li>123.</li> <li>124.</li> <li>125.</li> <li>126.</li> </ul>	Flange Condition         Service Technician         Service Technician         Image: Condition         cing Report         Balance Type         Balance Operating Speed         Start Left End         Start Right End         Balancing Specification         Finish Left End         Finish Right End         Service Technician		
129. Hi-Pot	117. 118. <b>Balane</b> 119. 120. 121. 122. 123. 124. 125. 126. <b>Assen</b>	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed Start Left End Start Right End Start Right End Balancing Specification Finish Left End Finish Left End Start Right End Balancing Specification		
	117. 118. 3alan 119. 120. 121. 122. 123. 124. 125. 126. <b>Assen</b> 127.	Flange Condition         Service Technician         Service Technician         Image: Condition         cing Report         Balance Type         Balance Operating Speed         Start Left End         Start Right End         Balancing Specification         Finish Left End         Finish Right End         Service Technician         mbly and Final Test         Meggar Testing Reading		
	117. 118. <b>3alan</b> 119. 120. 121. 122. 123. 124. 125. 126. <b>Assen</b> 127. 128.	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed Start Left End Start Right End Start Right End Balancing Specification Finish Left End Finish Right End Service Technician mbly and Final Test Meggar Testing Reading Surge Test		
131 Winding Resistance 2-3	117. 118. <b>3alan</b> 119. 120. 121. 122. 123. 124. 125. 126. <b>Assen</b> 127. 128. 129.	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed Start Left End Start Right End Start Right End Balancing Specification Finish Left End Finish Right End Service Technician mbly and Final Test Meggar Testing Reading Surge Test Hi-Pot		
	117. 118. <b>3alan</b> 119. 120. 121. 122. 123. 124. 125. 126. <b>Assen</b> 127. 128. 129. 130.	Flange Condition Service Technician Cing Report Balance Type Balance Operating Speed Start Left End Start Left End Start Right End Balancing Specification Finish Left End Finish Right End Service Technician Meggar Testing Reading Surge Test Hi-Pot Winding Resistance 1-2		
TOZ. WINNING NEOBILITUS TO	<ul> <li>117.</li> <li>118.</li> <li>3aland</li> <li>119.</li> <li>120.</li> <li>121.</li> <li>122.</li> <li>123.</li> <li>124.</li> <li>125.</li> <li>126.</li> <li>Assen</li> <li>127.</li> <li>128.</li> <li>129.</li> <li>130.</li> <li>131.</li> </ul>	Flange Condition         Service Technician         Service Technician         Service Technician         Cing Report         Balance Type         Balance Operating Speed         Start Left End         Start Right End         Balancing Specification         Finish Left End         Finish Right End         Service Technician         mbly and Final Test         Meggar Testing Reading         Surge Test         Hi-Pot         Winding Resistance 1-2         Winding Resistance 2-3		
133. Test Run Voltage Phase A	117. 118. <b>3alan</b> 119. 120. 121. 122. 123. 124. 125. 126. <b>Xssen</b> 127. 128. 129. 130. 131. 132.	Flange Condition         Service Technician         Service Technician         Cing Report         Balance Type         Balance Type         Balance Operating Speed         Start Left End         Start Right End         Balancing Specification         Finish Left End         Finish Right End         Service Technician         mbly and Final Test         Meggar Testing Reading         Surge Test         Hi-Pot         Winding Resistance 1-2         Winding Resistance 2-3         Winding Resistance 1-3		

135.	Test Run Voltage Phase B
136.	Test Run Amps B
137.	Test Run Voltage Phase C
138.	Test Run Amps C
139.	DE Horizontal Vibration Reading
140.	DE Vertical Vibration Reading
141.	DE Axial Vibration Reading
142.	ODE Horizontal Vibration Reading
143.	ODE Vertical Vibration Reading
144.	ODE Axial Vibration Reading
145.	Ambient Temp at start of Test Run
146.	Temp at 5 minutes
147.	Temp at 10 minutes
148.	Temp at 15 minutes
149.	Temp at 20 minutes
150.	Temp at 25 minutes
151.	Temp at 30 minutes
152.	Temp at 35 minutes
153.	Temp at 40 minutes
154.	Temp at 45 minutes
155.	Temp at 50 minutes
156.	Temp at 55 minutes
157.	Temp at 60 minutes
158.	Motor Paint
159.	Service Technician



# STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. <u>APPLICABILITY.</u> The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. <u>SCOPE OF GOODS AND/OR SERVICES.</u> The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only be effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. DELIVERY OF GOODS AND/OR SERVICES. Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- 6. DELIVERY SITE AND TIME FOR PERFORMANCE. Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

**TermsAndConditions** 

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. LIMITATION OF DAMAGES. HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY</u>. The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. <u>GOVERNING LAW AND JURISDICTION.</u> Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. <u>ABANDONED EQUIPMENT.</u> Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER</u>. No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. <u>ASSIGNMENT.</u> The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. <u>NO INDIVIDUAL LIABILITY</u>. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.