

# 

# Motor Shop Repairs

### Job Number 98239

Prepared for Bryce Corporation (10053-BRC)

450 S. Benton Searcy AR 72143

### **Table of Contents**



Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

Printed on 5/20/2021 Powered by INSPECTALL Table of Contents



Hi-Speed Industrial Service 7030 Ryburn Dr Millington, Tn 38053 901-873-5300

> FolderID: 98239 FormID: 10684179

### **DC Recondition Repair Report**

**Bryce Corporation (10053-BRC)** 450 S. Benton Searcy, AR 72143

Priorities Found: 18 - Good

Gene	General		
1.	Job Number	98239	
2.	Report Date	5/19/2021	
3.	Customer	BRYCE	
Name	Name Plate Information		

4. Manufacturer LENZE













5.	Model	GFQU 100 22	
6.	Serial Number		
7.	Horsepower	10.7	
8.	KW		
9.	Armature Volts	440	
10.	Armature Amps	27	
11.	Field Voltage	360	
12.	Field Amps	1.4	
13.	RPM	3200	

14.	Frame	100-22
15.	Enclosure	DP
16.	Service Factor	
17.	Motor Mount Position	
Initial	Inspection	
18.	Lead Length	
19.	Lead Size	
<b>2</b> 0.	Lead Condition	(P) Pass



21.	Lead Markings	B1B. B2B F1 F2
22.	Lug Size, Condition, and Type	
23.	Winding RTD's	
24.	Winding Rtd's Condition	
25.	Shaft Run Out	
26.	Does Shaft Turn Freely	no
27.	Does Shaft Have Visible Damage	
28.	Bearing Rtd's	(NA) Not Applicable
<b>2</b> 9.	Bearing Rtd's Condition	(NA) Not Applicable
30.	Contamination	
<b>3</b> 1.	Frame Condition	(P) Pass
<b>3</b> 2.	Fan Condition	(NA) Not Applicable
<ul><li>33.</li></ul>	Brush Condition	(P) Pass



34. Quantity of brushes

#### 35. Brush Holder Assembly Condition





36. Broken or missing components

#### **Initial Electric Test**

37. Armature Resistance to Ground

38. Field Resistance to Ground 65.480999999999 Mohm

39. Armature Hi-Pot

40. Field Hi-Pot

41. Armature Bar to Bar Test

(P) Pass

**753 Mohm** 





■ 42. DC field frame Drop Test

(P) Pass

43. DC Field Frame Polarity Check

44. Field Frame Condition pass wash and bake





45. Field Frame Failure Location

#### **Initial Armature Inspection**

- 46. Air Gap <10% Variation
- 47. Number of Commutator Bars
- 48. Growler Test
- 49. Commutator Condition
- 50. Armature Condition
- 51. Armature Failure Location

#### **Mechanical Inspection**

52. Bearing Manufacture NTN



53. Bearing DE Size 6306

54. Bearing DE Type ball bearing

55. Bearing ODE Size 6206



56. Bearing ODE Type 57. Insulated Bearing 58. Lubrication Type 58. Lubrication Type 59. Grease Condition 60. Bearing Retainers 7(Y) Yes 61. Shaft Grounding Device 61. Shaft Grounding Device 62. DE Seal 63. DE Seal Type/Size 64. ODE Seal 65. ODE Seal Type/Size 66. Component Failure 66. Component Failure 66. Component Failure 67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report 70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Bearing Fit 1 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit 1 75. DE Finial Shaft Bearing Fit 2 76. DE Initial Shaft Bearing Fit 3 77. DE Finial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit 81. (P) Pass 81. ODE Initial Shaft Bearing Fit 1 82. ODE Initial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 1 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 1 86. ODE Initial Shaft Bearing Fit 2 87. ODE Initial Shaft Bearing Fit 1 88. ODE Initial Shaft Bearing Fit 2 89. ODE Initial Shaft Bearing Fit 2 80. ODE Initial Shaft Bearing Fit 2 80. ODE Initial Shaft Bearing Fit 2 81. ODE Initial Shaft Bearing Fit 2 82. ODE Initial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 3 85. ODE Initial Shaft Bearing Fit 3 86. ODE Finial Shaft Bearing Fit 3			
58. Lubrication Type         grease           ● 59. Grease Condition         (NA) Not Applicable           ● 60. Bearing Retainers         (Y) Yes           61. Shaft Grounding Device         (NA) Not Applicable           62. DE Seal         (NA) Not Applicable           63. DE Seal Type/Size         (NA) Not Applicable           65. ODE Seal Type/Size         (NA) Not Applicable           86. Component Failure         66. Component Failure           67. Cause of Failure         68. Comments           69. Service Technician         48. Comments           69. Service Technician         48. Comments           69. Service Technician         49. Service Technician           Machine Fit Inspection Report         70. Shaft Run Out           71. Initial Shaft Run Out         71. Initial Shaft Run Out           72. Final Shaft Run Out         72. Final Shaft Bearing Fit 1         1.1813 "           75. DE Finial Shaft Bearing Fit 2         1.1813 "           76. DE Initial Shaft Bearing Fit 2         1.1813 "           77. DE Finial Shaft Bearing Fit 3         1.1813 "           80. ODE Bearing Shaft Fit         (P) Pass           81. ODE Initial Shaft Bearing Fit 1         1.1812 "           82. ODE Finial Shaft Bearing Fit 1         1.1812 "           83. ODE Init	56		ball bearing
<ul> <li>59. Grease Condition (NA) Not Applicable (Y) Yes</li> <li>61. Shaft Grounding Device (NA) Not Applicable (NA) Not Ap</li></ul>			no
60. Bearing Retainers (Y) Yes 61. Shaft Grounding Device (NA) Not Applicable 62. DE Seal (NA) Not Applicable 63. DE Seal Type/Size 64. ODE Seal Type/Size 65. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report 70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 75. DE Finial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 2 77. DE Finial Shaft Bearing Fit 2 78. DE Initial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2 86. ODE Finial Shaft Bearing Fit 2 87. ODE Finial Shaft Bearing Fit 1 88. ODE Initial Shaft Bearing Fit 2 89. ODE Finial Shaft Bearing Fit 2 80. ODE Initial Shaft Bearing Fit 2 81. Table Till Shaft Bearing Fit 2 82. ODE Finial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2	58	. Lubrication Type	grease
61. Shaft Grounding Device (NA) Not Applicable 62. DE Seal (NA) Not Applicable 63. DE Seal Type/Size 64. ODE Seal Type/Size 65. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report 70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 75. DE Finial Shaft Bearing Fit 1 76. De Initial Shaft Bearing Fit 2 77. DE Finial Shaft Bearing Fit 2 78. DE Initial Shaft Bearing Fit 3 79. DE Finial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2 86. ODE Initial Shaft Bearing Fit 2 87. ODE Finial Shaft Bearing Fit 1 88. ODE Initial Shaft Bearing Fit 2 89. ODE Initial Shaft Bearing Fit 2 80. ODE Initial Shaft Bearing Fit 2 81. ODE Initial Shaft Bearing Fit 2 82. ODE Finial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2	<b>9</b> 59	. Grease Condition	(NA) Not Applicable
62. DE Seal (NA) Not Applicable 63. DE Seal Type/Size 64. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report 70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 75. DE Finial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 2 77. DE Finial Shaft Bearing Fit 2 78. DE Initial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit 81. (P) Pass 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2 86. ODE Initial Shaft Bearing Fit 2 87. DE Initial Shaft Bearing Fit 3 88. ODE Initial Shaft Bearing Fit 1 89. ODE Initial Shaft Bearing Fit 1 80. ODE Initial Shaft Bearing Fit 1 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 3 86. ODE Initial Shaft Bearing Fit 2 87. ODE Initial Shaft Bearing Fit 2 88. ODE Initial Shaft Bearing Fit 2 89. ODE Initial Shaft Bearing Fit 2	<b>6</b> 0	. Bearing Retainers	(Y) Yes
63. DE Seal Type/Size 64. ODE Seal 65. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report 70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit 1 75. DE Finial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 2 77. DE Finial Shaft Bearing Fit 2 78. DE Finial Shaft Bearing Fit 3 79. DE Finial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2 86. ODE Finial Shaft Bearing Fit 2 87. In Initial Shaft Bearing Fit 3 88. ODE Initial Shaft Bearing Fit 3 89. ODE Bearing Shaft Fit 80. ODE Finial Shaft Bearing Fit 1 80. ODE Initial Shaft Bearing Fit 1 81. ODE Finial Shaft Bearing Fit 2 82. ODE Finial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2	61	. Shaft Grounding Device	(NA) Not Applicable
64. ODE Seal Type/Size  Root Cause of Failure  66. Component Failure  67. Cause of Failure  68. Comments  68. Comments  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  75. DE Finial Shaft Bearing Fit 1  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  1.1812 "  85. ODE Initial Shaft Bearing Fit 2  1.1812 "	62	. DE Seal	(NA) Not Applicable
65. ODE Seal Type/Size  Root Cause of Failure  66. Component Failure  67. Cause of Failure  68. Comments  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  9 73. DE Bearing Shaft Fit (P) Pass  74. DE Initial Shaft Bearing Fit 1 1.1813 "  75. DE Finial Shaft Bearing Fit 2 1.1813 "  77. DE Finial Shaft Bearing Fit 2 1.1813 "  77. DE Finial Shaft Bearing Fit 3 1.1813 "  79. DE Finial Shaft Bearing Fit 3 1.1813 "  80. ODE Bearing Shaft Fit (P) Pass  81. ODE Initial Shaft Bearing Fit 1 1.1812 "  82. ODE Finial Shaft Bearing Fit 1 1.1812 "  83. ODE Initial Shaft Bearing Fit 2 1.1812 "  84. ODE Finial Shaft Bearing Fit 2 1.1812 "	63	. DE Seal Type/Size	
Root Cause of Failure  66. Component Failure  67. Cause of Failure  68. Comments  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit 1  75. DE Finial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 2  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  (P) Pass  1.1813 "  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit 3  82. ODE Initial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	64	. ODE Seal	(NA) Not Applicable
66. Component Failure 67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report 70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 75. DE Initial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 1 77. DE Finial Shaft Bearing Fit 2 78. DE Initial Shaft Bearing Fit 3 79. DE Finial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2 86. ODE Initial Shaft Bearing Fit 2 87. In Initial Shaft Bearing Fit 3 88. ODE Initial Shaft Bearing Fit 1 88. ODE Initial Shaft Bearing Fit 1 88. ODE Initial Shaft Bearing Fit 1 89. ODE Finial Shaft Bearing Fit 1 80. ODE Finial Shaft Bearing Fit 1 80. ODE Initial Shaft Bearing Fit 1 80. ODE Finial Shaft Bearing Fit 2 80. ODE Initial Shaft Bearing Fit 2	65	. ODE Seal Type/Size	
67. Cause of Failure 68. Comments 69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out  9 73. DE Bearing Shaft Fit (P) Pass 74. DE Initial Shaft Bearing Fit 1 1.1813 " 75. DE Finial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 2 1.1813 " 77. DE Finial Shaft Bearing Fit 2 1.1813 " 78. DE Initial Shaft Bearing Fit 3 1.1813 " 79. DE Finial Shaft Bearing Fit 3 1.1813 " 79. DE Finial Shaft Bearing Fit 3 1.1813 " 10 DE Initial Shaft Bearing Fit 1 1.1812 " 11 DE Finial Shaft Bearing Fit 1 1.1812 " 1.1813 "	Root	Cause of Failure	
68. Comments 69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out  9 73. DE Bearing Shaft Fit (P) Pass 74. DE Initial Shaft Bearing Fit 1 1.1813 " 75. DE Finial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 2 1.1813 " 77. DE Finial Shaft Bearing Fit 2 1.1813 " 78. DE Initial Shaft Bearing Fit 3 1.1813 " 79. DE Finial Shaft Bearing Fit 3 1.1813 " 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit 1 1.1812 " 82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 2 86. ODE Initial Shaft Bearing Fit 2 87. ODE Initial Shaft Bearing Fit 2 88. ODE Initial Shaft Bearing Fit 2 89. ODE Finial Shaft Bearing Fit 2 80. ODE Finial Shaft Bearing Fit 2 80. ODE Initial Shaft Bearing Fit 2	66	. Component Failure	
Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit 1  75. DE Finial Shaft Bearing Fit 1  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	67	. Cause of Failure	
Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit 1  75. DE Finial Shaft Bearing Fit 1  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 2  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	68	. Comments	
70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit 1 75. DE Finial Shaft Bearing Fit 1 76. DE Initial Shaft Bearing Fit 2 77. DE Finial Shaft Bearing Fit 2 78. DE Initial Shaft Bearing Fit 3 79. DE Finial Shaft Bearing Fit 3 80. ODE Bearing Shaft Fit 81. ODE Initial Shaft Bearing Fit 1 82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Initial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 3 86. ODE Initial Shaft Bearing Fit 1 87. ODE Initial Shaft Bearing Fit 1 88. ODE Initial Shaft Bearing Fit 1 89. ODE Initial Shaft Bearing Fit 1 80. ODE Initial Shaft Bearing Fit 2 81. ODE Initial Shaft Bearing Fit 2 82. ODE Initial Shaft Bearing Fit 2 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 3 85. ODE Initial Shaft Bearing Fit 3 86. ODE Initial Shaft Bearing Fit 2 87. ODE Initial Shaft Bearing Fit 3	69	. Service Technician	
71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit 1  75. DE Finial Shaft Bearing Fit 2  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	Mach	nine Fit Inspection Report	
72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit 1  75. DE Finial Shaft Bearing Fit 1  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	70	. Shaft Run Out	
<ul> <li>73. DE Bearing Shaft Fit</li> <li>74. DE Initial Shaft Bearing Fit 1</li> <li>75. DE Finial Shaft Bearing Fit 2</li> <li>76. DE Initial Shaft Bearing Fit 2</li> <li>77. DE Finial Shaft Bearing Fit 2</li> <li>78. DE Initial Shaft Bearing Fit 3</li> <li>79. DE Finial Shaft Bearing Fit 3</li> <li>80. ODE Bearing Shaft Fit</li> <li>81. ODE Initial Shaft Bearing Fit 1</li> <li>82. ODE Finial Shaft Bearing Fit 1</li> <li>83. ODE Initial Shaft Bearing Fit 2</li> <li>84. ODE Finial Shaft Bearing Fit 2</li> <li>85. ODE Initial Shaft Bearing Fit 2</li> <li>86. ODE Initial Shaft Bearing Fit 2</li> <li>87. ODE Initial Shaft Bearing Fit 2</li> <li>88. ODE Initial Shaft Bearing Fit 2</li> <li>89. ODE Finial Shaft Bearing Fit 2</li> <li>80. ODE Finial Shaft Bearing Fit 2</li> <li>81. ODE Finial Shaft Bearing Fit 2</li> <li>82. ODE Finial Shaft Bearing Fit 2</li> <li>83. ODE Initial Shaft Bearing Fit 2</li> <li>84. ODE Finial Shaft Bearing Fit 3</li> <li>85. ODE Initial Shaft Bearing Fit 3</li> <li>86. ODE Initial Shaft Bearing Fit 3</li> <li>87. Initial Shaft Bearing Fit 2</li> <li>88. ODE Initial Shaft Bearing Fit 3</li> <li>89. ODE Initial Shaft Bearing Fit 3</li> <li>80. ODE</li></ul>	71	. Initial Shaft Run Out	
74. DE Initial Shaft Bearing Fit 1  75. DE Finial Shaft Bearing Fit 1  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	72	. Final Shaft Run Out	
75. DE Finial Shaft Bearing Fit 1  76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 2  86. ODE Initial Shaft Bearing Fit 2  87. ODE Initial Shaft Bearing Fit 2  88. ODE Finial Shaft Bearing Fit 2  89. ODE Initial Shaft Bearing Fit 2  80. ODE Initial Shaft Bearing Fit 2	<ul><li>73</li></ul>	. DE Bearing Shaft Fit	(P) Pass
76. DE Initial Shaft Bearing Fit 2  77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	74	. DE Initial Shaft Bearing Fit 1	1.1813 "
77. DE Finial Shaft Bearing Fit 2  78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	75	. DE Finial Shaft Bearing Fit 1	
78. DE Initial Shaft Bearing Fit 3  79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	76	. DE Initial Shaft Bearing Fit 2	1.1813 "
79. DE Finial Shaft Bearing Fit 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	77	. DE Finial Shaft Bearing Fit 2	
<ul> <li>80. ODE Bearing Shaft Fit</li> <li>81. ODE Initial Shaft Bearing Fit 1</li> <li>82. ODE Finial Shaft Bearing Fit 1</li> <li>83. ODE Initial Shaft Bearing Fit 2</li> <li>84. ODE Finial Shaft Bearing Fit 2</li> <li>85. ODE Initial Shaft Bearing Fit 3</li> <li>1.1812 "</li> </ul>	78	. DE Initial Shaft Bearing Fit 3	1.1813 "
81. ODE Initial Shaft Bearing Fit 1  82. ODE Finial Shaft Bearing Fit 1  83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	79	. DE Finial Shaft Bearing Fit 3	
82. ODE Finial Shaft Bearing Fit 1 83. ODE Initial Shaft Bearing Fit 2 84. ODE Finial Shaft Bearing Fit 2 85. ODE Initial Shaft Bearing Fit 3 1.1812 "	<b>80</b>	. ODE Bearing Shaft Fit	(P) Pass
83. ODE Initial Shaft Bearing Fit 2  84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	81	. ODE Initial Shaft Bearing Fit 1	1.1812 "
84. ODE Finial Shaft Bearing Fit 2  85. ODE Initial Shaft Bearing Fit 3  1.1812 "	82	. ODE Finial Shaft Bearing Fit 1	
85. ODE Initial Shaft Bearing Fit 3	83	. ODE Initial Shaft Bearing Fit 2	1.1812 "
·	84	. ODE Finial Shaft Bearing Fit 2	
86. ODE Finial Shaft Bearing Fit 3	85	. ODE Initial Shaft Bearing Fit 3	1.1812 "
	86	. ODE Finial Shaft Bearing Fit 3	

87.	DE Air Seal Shaft Fit	
88.	DE Initial Air Seal Shaft Size	
89.	DE Final Air Seal Shaft Size	
90.	ODE Air Seal Shaft Fit	
91.	ODE Initial Air Seal Shaft Size	
92.	ODE Final Air Seal Shaft Size	
93.	DE Endbell Fit	(P) Pass



94. DE Initial Endbell Fit Size 1	2.835 "
95. DE Final Endbell Fit Size 1	
96. DE Initial Endbell Fit Size 2	2.835 "
97. DE Finial Endbell Fit Size 2	
98. DE Initial Endbell Fit Size 3	2.835 "
99. DE Final Endbell Fit Size 3	
100. DE Endbell Fit Insulated	(NA) Not Applicable
101. DE Endbell Air Seal Fit	
102. Initial Endbell Air Seal Fit Size	
103. Finial Endbell Air Seal Fit Size	
104. ODE Endbell Fit	(P) Pass



105. ODE Endbell Fit Insulated	(NA) Not Applicable
106. ODE Endbell Air Seal Fit	
107. ODE Initial Endbell Seal Fit Size	
108. ODE Finial Endbell Seal Fit Size	





113. Service Technician RW

RW

#### **Balancing Report**

- 114. Balance Type
- 115. Balance Operating Speed
- 116. Start Left End
- 117. Start Right End
- 118. Balancing Specification
- 119. Finish Left End
- 120. Finish Right End
- 121. Service Technician

#### **Assembly and Final Test**

- 122. Armature Meggar Testing Reading
- 123. Armature Hi-Pot
- 124. Field Frame Meggar Testing Reading
- 125. Field Frame Hi-Pot
- 126. Test Run Field Voltage
- 127. Test Run Field Amps
- 128. Test Run Armature Voltage
- 129. Test Run Armature Amps
- 130. Brushes seated
- 131. DE Horizontal Vibration Reading
- 132. DE Vertical Vibration Reading
- 133. DE Axial Vibration Reading
- 134. ODE Horizontal Vibration Reading
- 135. ODE Vertical Vibration Reading
- 136. ODE Axial Vibration Reading

137.	Ambient Temp at start of Test Run
138.	Temp at 5 minutes
139.	Temp at 10 minutes
140.	Temp at 15 minutes
141.	Temp at 20 minutes
142.	Temp at 25 minutes
143.	Temp at 30 minutes
144.	Temp at 35 minutes
145.	Temp at 40 minutes
146.	Temp at 45 minutes
147.	Temp at 50 minutes
148.	Temp at 55 minutes
149.	Temp at 60 minutes
150.	Motor Paint
151.	Service Technician



#### STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. APPLICABILITY. The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. SCOPE OF GOODS AND/OR SERVICES. The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only bee effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. <u>DELIVERY OF GOODS AND/OR SERVICES.</u> Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- **DELIVERY SITE AND TIME FOR PERFORMANCE.** Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have sixty (60) days to cure the alleged discrepancy and/or nonconformance. If Hi-Speed fails to cure in this time period, Buyer shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed. Buyer shall notify Hi-Speed and arrange for the return of the goods as required. Should such non-conforming services be rejected Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. <u>LIMITATION OF DAMAGES.</u> HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY.</u> The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. **GOVERNING LAW AND JURISDICTION.** Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. ABANDONED EQUIPMENT. Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER.</u> No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. **ASSIGNMENT.** The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. NO INDIVIDUAL LIABILITY. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.