

# 

# **Motor Shop Repairs**

# Job Number 98546

Prepared for Peco Foods

Hwy 67 Pocahontas AR 72455

## **Table of Contents**



Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

Printed on 8/17/2021 Powered by INSPECTALL Table of Contents



FolderID: 98546

FormID: 11268830



## **AC Recondition Repair Report**

**Peco Foods** 

Hwy 67 Pocahontas, AR 72455

Hwy 67

Priorities Found: 2 - High 1 - Medium

17 - Good

# General 1. Job Number 98546 2. Report Date 8/3/2021 3. Customer 12125

#### **Name Plate Information**

4. Manufacturer







































5.	Model	0742	
6.	Serial Number	N0S0S20L6	
7.	Horsepower	3010	
8.	KW		
9.	Volts	460	
10.	Amps	73	
11.	RPM	1760	
12.	Frame		
13.	Enclosure	WPI	
14.	Cycles		
15.	Phase	3	
16.	Service Factor	1.15	
17.	Motor Mount Position		
Initial	Inspection		
18.	Number of Leads	9	

19. Lead Length 11 Inches



20.	Lead Size	
21.	Lead Condition	(P) Pass
22.	Lead Markings	1-9
23.	Lug Size, Condition, and Type	
24.	Winding RTD's	
25.	Winding Rtd's Condition	
26.	Shaft Run Out	
27.	Does Shaft Turn Freely	yes
28.	Does Shaft Have Visible Damage	
29.	Bearing Rtd's	
30.	Bearing Rtd's Condition	(NA) Not Applicable
31.	Contamination	
	NA	
32.	Frame Condition	(P) Pass
33.	Fan Condition	(NA) Not Applicable
34.	Broken or missing components	
	Bolt is broke that goes to J-box and J-box is missing	



### **Initial Electric Test**

- 35. Resistance to Ground
- 36. Winding Resistance 1-2
- 37. Winding Resistance 2-3

38.	Winding Resistance 1-3	
39.	Resistive Imbalance	
40.	Hi-Pot	
41.	Surge Test	(F) Fail
42.	Stator Condition	
12	Failure Location	ODE coil head



Initial Rotor Inspection			
44.	Rotor Type	cast aluminum	
45.	Air Gap <10% Variation		
46.	Number of Rotor Bars	40	
47.	Number of Broken Rotor Bars	0	
<b>48.</b>	Growler Test	(P) Pass	
<b>4</b> 9.	Rotor Condition	(P) Pass	
Mechanical Inspection			
50.	Bearing Manufacture		
51.	Bearing DE Size	6210	
52.	Bearing DE Type	ball bearing	
53.	DE Bearing Qty.	1	
54.	Bearing ODE Size	7310-BEP	
55.	Bearing ODE Type	thrust bearing	
56.	ODE Bearing Qty.	1	
57.	Insulated Bearing	na	
58.	Lubrication Type	grease	
59.	Grease Condition	(F) Fail	
	Old grease improperly lubricated		

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

60. Bearing Retainers (Y) Yes



61. Shaft Grounding Device 62. DE Seal Type/Size 63. DE Seal Type/Size 64. ODE Seal Type/Size 65. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments  Recomment Recommend rewind, new bearings, and new J-box 69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit Size 1 75. DE Initial Shaft Bearing Fit Size 2 76. DE Initial Shaft Bearing Fit Size 1 77. DE Finial Shaft Bearing Fit Size 1 78. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 1 78. DE Finial Shaft Bearing Fit Size 1 79. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 1 80. ODE Bearing Shaft Fit 81. ODE Initial Shaft Bearing Fit Size 2 82. ODE Initial Shaft Bearing Fit Size 2 83. ODE Initial Shaft Bearing Fit Size 2 84. ODE Finial Shaft Bearing Fit Size 2 85. ODE Finial Shaft Bearing Fit Size 2 86. ODE Finial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Shaft Bearing Fit Size 2 89. DE Finial Shaft Bearing Fit Size 3 80. ODE Finial Shaft Bearing Fit Size 2 80. ODE Finial Shaft Bearing Fit Size 3 80. ODE Finial Shaft Bearing Fit Size 2 80. ODE Finial Shaft Bearing Fit Size 2 80. ODE Finial Shaft Bearing Fit Size 3 81. ODE Finial Shaft Bearing Fit Size 3 82. ODE Finial Shaft Bearing Fit Size 3 83. DE Air Seal Shaft Fit 84. DE Finial Air Seal Shaft Fit 85. DE Finial Air Seal Shaft Size		0.4		
63. DE Seal Type/Size 64. ODE Seal 65. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments Recommend rewind, new bearings, and new J-box 69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit Size 1 75. DE Initial Shaft Bearing Fit Size 2 1.9688 " 76. DE Initial Shaft Bearing Fit Size 1 77. DE Finial Shaft Bearing Fit Size 2 1.9698 " 178. DE Finial Shaft Bearing Fit Size 2 1.9698 " 179. DE Finial Shaft Bearing Fit Size 2 1.9698 " 170. DE Finial Shaft Bearing Fit Size 2 1.9698 " 171. DE Finial Shaft Bearing Fit Size 3 1.969 " 172. DE Finial Shaft Bearing Fit Size 3 1.969 " 173. DE Finial Shaft Bearing Fit Size 3 1.969 " 174. DE Finial Shaft Bearing Fit Size 3 1.969 " 175. DE Finial Shaft Bearing Fit Size 3 1.969 " 176. DE Initial Shaft Bearing Fit Size 3 1.969 " 177. DE Finial Shaft Bearing Fit Size 3 1.969 " 180. ODE Bearing Shaft Fit 19689 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19687 " 19688 DE Initial Shaft Bearing Fit Size 3 1.9687 " 19687 " 19688 DE Initial Shaft Bearing Fit Size 3 1.9687 "			· · · · · · · · · · · · · · · · · · ·	
64. ODE Seal Type/Size  Root Cause of Failure 66. Component Failure 67. Cause of Failure 68. Comments Recommend rewind, new bearings, and new J-box 69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit Size 1 75. DE Initial Shaft Bearing Fit Size 2 76. DE Initial Shaft Bearing Fit Size 1 77. DE Finial Shaft Bearing Fit Size 2 78. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 3 80. ODE Bearing Shaft Fit 81. ODE Initial Shaft Bearing Fit Size 3 82. ODE Initial Shaft Bearing Fit Size 3 83. ODE Initial Shaft Bearing Fit Size 3 84. ODE Finial Shaft Bearing Fit Size 2 85. ODE Finial Shaft Bearing Fit Size 3 86. ODE Finial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Shaft Searing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Air Seal Shaft Size		-		(NA) Not Applicable
Root Cause of Failure  66. Component Failure  67. Cause of Failure  68. Comments Recommend rewind, new bearings, and new J-box  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 1  77. DE Finial Shaft Bearing Fit Size 2  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 2  84. ODE Initial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 3  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Shaft Searing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Fit		63.	DE Seal Type/Size	
Root Cause of Failure  66. Component Failure  67. Cause of Failure  68. Comments  Recomments  Recomment rewind, new bearings, and new J-box  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  1.9689 "  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 1  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Finial Shaft Bearing Fit Size 3  88. ODE Finial Shaft Bearing Fit Size 3  89. ODE Finial Shaft Bearing Fit Size 3  80. ODE Finial Shaft Bearing Fit Size 2  81. ODE Initial Shaft Bearing Fit Size 3  82. ODE Initial Shaft Bearing Fit Size 3  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 3  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size				(NA) Not Applicable
66. Component Failure Coil to coil short  68. Commends Recommend rewind, new bearings, and new J-box  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit Size 1 75. DE Initial Shaft Bearing Fit Size 2 1.9688 " 76. DE Initial Shaft Bearing Fit Size 1 77. DE Finial Shaft Bearing Fit Size 1 78. DE Finial Shaft Bearing Fit Size 1 79. DE Finial Shaft Bearing Fit Size 2 1.9688 "  80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit Size 1 1.9689 " 82. ODE Initial Shaft Bearing Fit Size 2 1.9687 " 83. ODE Initial Shaft Bearing Fit Size 3 1.9687 " 84. ODE Finial Shaft Bearing Fit Size 3 85. ODE Finial Shaft Bearing Fit Size 3 86. ODE Finial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit		65.	ODE Seal Type/Size	
67. Cause of Failure Coil to coil short  68. Comments Recommend rewind, new bearings, and new J-box  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit (P) Pass  74. DE Initial Shaft Bearing Fit Size 1 1.9689 " 75. DE Initial Shaft Bearing Fit Size 2 1.9688 " 76. DE Initial Shaft Bearing Fit Size 3 1.969 " 77. DE Finial Shaft Bearing Fit Size 1 78. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 2 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit Size 1 1.9689 " 82. ODE Initial Shaft Bearing Fit Size 2 1.9687 " 84. ODE Finial Shaft Bearing Fit Size 3 85. ODE Initial Shaft Bearing Fit Size 3 86. ODE Finial Shaft Bearing Fit Size 3 87. DE Finial Shaft Bearing Fit Size 3 88. ODE Finial Shaft Bearing Fit Size 3 89. ODE Initial Shaft Bearing Fit Size 3 80. ODE Initial Shaft Bearing Fit Size 3 81. ODE Initial Shaft Bearing Fit Size 3 82. ODE Initial Shaft Bearing Fit Size 3 83. ODE Finial Shaft Bearing Fit Size 3 84. ODE Finial Shaft Bearing Fit Size 3 85. ODE Finial Shaft Bearing Fit Size 3 86. ODE Finial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Air Seal Shaft Size	R	oot	Cause of Failure	
Coil to coil short  68. Comments Recommend rewind, new bearings, and new J-box  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 2  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  1.9689 "  82. ODE Initial Shaft Bearing Fit Size 2  1.9687 "  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 1  87. DE Air Seal Shaft Fit  88. DE Initial Shaft Searing Fit Size 3		66.	Component Failure	windings
68. Comments Recommend rewind, new bearings, and new J-box 69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out 71. Initial Shaft Run Out 72. Final Shaft Run Out 73. DE Bearing Shaft Fit 75. DE Initial Shaft Bearing Fit Size 1 76. DE Initial Shaft Bearing Fit Size 2 77. DE Finial Shaft Bearing Fit Size 1 78. DE Finial Shaft Bearing Fit Size 1 79. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 3 80. ODE Bearing Shaft Fit 80. ODE Initial Shaft Bearing Fit Size 1 81. ODE Initial Shaft Bearing Fit Size 2 82. ODE Initial Shaft Bearing Fit Size 3 83. ODE Initial Shaft Bearing Fit Size 3 84. ODE Finial Shaft Bearing Fit Size 1 85. ODE Finial Shaft Bearing Fit Size 2 86. ODE Finial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 88. DE Initial Air Seal Shaft Size		67.	Cause of Failure	
Recommend rewind, new bearings, and new J-box  69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  (P) Pass  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 1  79. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 2  79. DE Jenitial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 1  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Fit			Coil to coil short	
69. Service Technician  Machine Fit Inspection Report  70. Shaft Run Out  71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  (P) Pass  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 2  84. ODE Finial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 3  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Fit		68.	Comments	
Machine Fit Inspection Report         ● 70. Shaft Run Out       (P) Pass         71. Initial Shaft Run Out       (P) Pass         72. Final Shaft Run Out       (P) Pass         73. DE Bearing Shaft Fit       (P) Pass         74. DE Initial Shaft Bearing Fit Size 1       1.9689 "         75. DE Initial Shaft Bearing Fit Size 2       1.9688 "         76. DE Initial Shaft Bearing Fit Size 3       1.969 "         77. DE Finial Shaft Bearing Fit Size 1       1.969 "         78. DE Finial Shaft Bearing Fit Size 2       Poss Enial Shaft Bearing Fit Size 3         80. ODE Bearing Shaft Fit       (P) Pass         81. ODE Initial Shaft Bearing Fit Size 1       1.9689 "         82. ODE Initial Shaft Bearing Fit Size 2       1.9687 "         83. ODE Initial Shaft Bearing Fit Size 3       1.9687 "         84. ODE Finial Shaft Bearing Fit Size 1       1.9687 "         85. ODE Finial Shaft Bearing Fit Size 2       1.9687 "         86. ODE Finial Shaft Bearing Fit Size 3       1.9687 "         87. DE Air Seal Shaft Fit       88. DE Initial Air Seal Shaft Fit			Recommend rewind, new bearings, and new J-box	
<ul> <li>70. Shaft Run Out</li> <li>71. Initial Shaft Run Out</li> <li>72. Final Shaft Run Out</li> <li>73. DE Bearing Shaft Fit</li> <li>(P) Pass</li> <li>74. DE Initial Shaft Bearing Fit Size 1</li> <li>1.9689 "</li> <li>75. DE Initial Shaft Bearing Fit Size 2</li> <li>1.9688 "</li> <li>76. DE Initial Shaft Bearing Fit Size 3</li> <li>1.969 "</li> <li>77. DE Finial Shaft Bearing Fit Size 1</li> <li>78. DE Finial Shaft Bearing Fit Size 2</li> <li>79. DE Finial Shaft Bearing Fit Size 3</li> <li>80. ODE Bearing Shaft Fit</li> <li>(P) Pass</li> <li>81. ODE Initial Shaft Bearing Fit Size 1</li> <li>82. ODE Initial Shaft Bearing Fit Size 2</li> <li>83. ODE Initial Shaft Bearing Fit Size 3</li> <li>84. ODE Finial Shaft Bearing Fit Size 1</li> <li>85. ODE Finial Shaft Bearing Fit Size 2</li> <li>86. ODE Finial Shaft Bearing Fit Size 2</li> <li>87. DE Air Seal Shaft Fit</li> <li>88. DE Initial Air Seal Shaft Size</li> </ul>		69.	Service Technician	
71. Initial Shaft Run Out  72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  81. ODE Initial Shaft Bearing Fit Size 2  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 2  84. ODE Initial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 3  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Finial Shaft Bearing Fit Size 3  88. ODE Finial Shaft Bearing Fit Size 3  89. ODE Finial Shaft Bearing Fit Size 2  80. ODE Finial Shaft Bearing Fit Size 3  81. ODE Finial Shaft Bearing Fit Size 3  82. ODE Finial Shaft Bearing Fit Size 3  83. ODE Finial Shaft Bearing Fit Size 1  84. ODE Finial Shaft Bearing Fit Size 2  85. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size	M	lachi	ne Fit Inspection Report	
72. Final Shaft Run Out  73. DE Bearing Shaft Fit  74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 2  84. ODE Finial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 3  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Finial Shaft Bearing Fit Size 3  88. ODE Finial Shaft Bearing Fit Size 3  89. ODE Finial Shaft Bearing Fit Size 3  80. DE Finial Shaft Bearing Fit Size 3  81. ODE Finial Shaft Bearing Fit Size 3  82. ODE Finial Shaft Bearing Fit Size 3  83. ODE Finial Shaft Bearing Fit Size 2  84. ODE Finial Shaft Bearing Fit Size 3  85. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		70.	Shaft Run Out	(P) Pass
73. DE Bearing Shaft Fit 74. DE Initial Shaft Bearing Fit Size 1 75. DE Initial Shaft Bearing Fit Size 2 76. DE Initial Shaft Bearing Fit Size 3 77. DE Finial Shaft Bearing Fit Size 1 78. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 2 79. DE Finial Shaft Bearing Fit Size 3 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit Size 1 82. ODE Initial Shaft Bearing Fit Size 2 83. ODE Initial Shaft Bearing Fit Size 2 84. ODE Finial Shaft Bearing Fit Size 3 85. ODE Finial Shaft Bearing Fit Size 1 86. ODE Finial Shaft Bearing Fit Size 2 87. DE Air Seal Shaft Bearing Fit Size 3 88. DE Initial Shaft Bearing Fit Size 3 89. ODE Finial Shaft Bearing Fit Size 1		71.	Initial Shaft Run Out	
74. DE Initial Shaft Bearing Fit Size 1  75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 2  84. ODE Initial Shaft Bearing Fit Size 3  85. ODE Finial Shaft Bearing Fit Size 1  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		72.	Final Shaft Run Out	
75. DE Initial Shaft Bearing Fit Size 2  76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  ■ 80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  1.9689 "  82. ODE Initial Shaft Bearing Fit Size 2  1.9687 "  83. ODE Initial Shaft Bearing Fit Size 3  44. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		73.	DE Bearing Shaft Fit	(P) Pass
76. DE Initial Shaft Bearing Fit Size 3  77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		74.	DE Initial Shaft Bearing Fit Size 1	1.9689 "
77. DE Finial Shaft Bearing Fit Size 1  78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1 1.9689 "  82. ODE Initial Shaft Bearing Fit Size 2 1.9687 "  83. ODE Initial Shaft Bearing Fit Size 3 1.9687 "  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 2  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		75.	DE Initial Shaft Bearing Fit Size 2	1.9688 "
78. DE Finial Shaft Bearing Fit Size 2  79. DE Finial Shaft Bearing Fit Size 3  80. ODE Bearing Shaft Fit  (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		76.	DE Initial Shaft Bearing Fit Size 3	1.969 "
79. DE Finial Shaft Bearing Fit Size 3  ■ 80. ODE Bearing Shaft Fit (P) Pass  81. ODE Initial Shaft Bearing Fit Size 1 1.9689 "  82. ODE Initial Shaft Bearing Fit Size 2 1.9687 "  83. ODE Initial Shaft Bearing Fit Size 3 1.9687 "  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		77.	DE Finial Shaft Bearing Fit Size 1	
<ul> <li>80. ODE Bearing Shaft Fit</li> <li>81. ODE Initial Shaft Bearing Fit Size 1</li> <li>82. ODE Initial Shaft Bearing Fit Size 2</li> <li>83. ODE Initial Shaft Bearing Fit Size 3</li> <li>84. ODE Finial Shaft Bearing Fit Size 1</li> <li>85. ODE Finial Shaft Bearing Fit Size 2</li> <li>86. ODE Finial Shaft Bearing Fit Size 3</li> <li>87. DE Air Seal Shaft Fit</li> <li>88. DE Initial Air Seal Shaft Size</li> </ul>		78.	DE Finial Shaft Bearing Fit Size 2	
81. ODE Initial Shaft Bearing Fit Size 1  82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		79.	DE Finial Shaft Bearing Fit Size 3	
82. ODE Initial Shaft Bearing Fit Size 2  83. ODE Initial Shaft Bearing Fit Size 3  84. ODE Finial Shaft Bearing Fit Size 1  85. ODE Finial Shaft Bearing Fit Size 2  86. ODE Finial Shaft Bearing Fit Size 3  87. DE Air Seal Shaft Fit  88. DE Initial Air Seal Shaft Size		80.	ODE Bearing Shaft Fit	(P) Pass
<ul> <li>83. ODE Initial Shaft Bearing Fit Size 3</li> <li>84. ODE Finial Shaft Bearing Fit Size 1</li> <li>85. ODE Finial Shaft Bearing Fit Size 2</li> <li>86. ODE Finial Shaft Bearing Fit Size 3</li> <li>87. DE Air Seal Shaft Fit</li> <li>88. DE Initial Air Seal Shaft Size</li> </ul>		81.	ODE Initial Shaft Bearing Fit Size 1	1.9689 "
<ul> <li>84. ODE Finial Shaft Bearing Fit Size 1</li> <li>85. ODE Finial Shaft Bearing Fit Size 2</li> <li>86. ODE Finial Shaft Bearing Fit Size 3</li> <li>87. DE Air Seal Shaft Fit</li> <li>88. DE Initial Air Seal Shaft Size</li> </ul>		82.	ODE Initial Shaft Bearing Fit Size 2	1.9687 "
<ul> <li>85. ODE Finial Shaft Bearing Fit Size 2</li> <li>86. ODE Finial Shaft Bearing Fit Size 3</li> <li>87. DE Air Seal Shaft Fit</li> <li>88. DE Initial Air Seal Shaft Size</li> </ul>		83.	ODE Initial Shaft Bearing Fit Size 3	1.9687 "
<ul> <li>86. ODE Finial Shaft Bearing Fit Size 3</li> <li>87. DE Air Seal Shaft Fit</li> <li>88. DE Initial Air Seal Shaft Size</li> </ul>		84.	ODE Finial Shaft Bearing Fit Size 1	
87. DE Air Seal Shaft Fit 88. DE Initial Air Seal Shaft Size		85.	ODE Finial Shaft Bearing Fit Size 2	
88. DE Initial Air Seal Shaft Size		86.	ODE Finial Shaft Bearing Fit Size 3	
		87.	DE Air Seal Shaft Fit	
89. DE Final Air Seal Shaft Size		88.	DE Initial Air Seal Shaft Size	
		89.	DE Final Air Seal Shaft Size	

90	ODE Air Seal Shaft Fit	
91.		
	ODE Final Air Seal Shaft Size	
93.	DE Endbell Fit	(P) Pass
94.		3.5441 "
	DE Initial Endbell Fit Size 2	3.5441 "
	DE Initial Endbell Fit Size 2  DE Initial Endbell Fit Size 3	3.5441
	DE Final Endbell Fit Size 1	3.3443
• • •	DE Finial Endbell Fit Size 2	
99.	DE Endbell Fit Insulated	
	DE Endbell Air Seal Fit	
	Initial Endbell Air Seal Fit Size	
	Finial Endbell Air Seal Fit Size	
		(D) Doop
	ODE Endbell Fit ODE Initial Endbell Fit Size 1	(P) Pass
	ODE Initial Endbell Fit Size 2	4.3317 "
	ODE Initial Endbell Fit Size 2  ODE Initial Endbell Fit Size 3	4.3316 "
	ODE Final Endbell Fit Size 3  ODE Final Endbell Fit Size 1	4.3317 "
	ODE Final Endbell Fit Size 2	
	ODE Final Endbell Fit Size 3	
	ODE Endbell Fit Insulated	
	ODE Endbell Air Seal Fit	
	ODE Initial Endbell Seal Fit Size	
	ODE Finial Endbell Seal Fit Size	(NAN N. 4 A P I I
_	Foot Flatness	(NA) Not Applicable
	Foot Condition	(NA) Not Applicable
	Flange Condition	(P) Pass
	Service Technician	
	cing Report	
	Balance Type	
	Balance Operating Speed	
	Start Left End	
	Start Right End	
	Balancing Specification	
	Finish Left End	
	Finish Right End	
	Service Technician	
Assen	nbly and Final Test	

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.



128. Surge Test	(P) Pass
129. Hi-Pot	
130. Winding Resistance 1-2	
131. Winding Resistance 2-3	
132. Winding Resistance 1-3	
133. Test Run Voltage Phase A	456 Volts



134. Test Run Amps A18.1 Amps135. Test Run Voltage Phase B456 Volts



136. Test Run Amps B 17.7 Amps



138. Test Run Amps C	18 Amps
139. DE Horizontal Vibration Reading	
140. DE Vertical Vibration Reading	
141. DE Axial Vibration Reading	
142. ODE Horizontal Vibration Reading	
143. ODE Vertical Vibration Reading	
144. ODE Axial Vibration Reading	
145. Ambient Temp at start of Test Run	
146. Temp at 5 minutes	
147. Temp at 10 minutes	
148. Temp at 15 minutes	
149. Temp at 20 minutes	
150. Temp at 25 minutes	
151. Temp at 30 minutes	
152. Temp at 35 minutes	
153. Temp at 40 minutes	
154. Temp at 45 minutes	
155. Temp at 50 minutes	
156. Temp at 55 minutes	
157. Temp at 60 minutes	
158. Motor Paint	(P) Pass









### STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. APPLICABILITY. The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. SCOPE OF GOODS AND/OR SERVICES. The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only bee effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. <u>DELIVERY OF GOODS AND/OR SERVICES.</u> Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- **DELIVERY SITE AND TIME FOR PERFORMANCE.** Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have sixty (60) days to cure the alleged discrepancy and/or nonconformance. If Hi-Speed fails to cure in this time period, Buyer shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed. Buyer shall notify Hi-Speed and arrange for the return of the goods as required. Should such non-conforming services be rejected Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. <u>WARRANTIES.</u> Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. <u>LIMITATION OF DAMAGES.</u> HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY.</u> The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. **GOVERNING LAW AND JURISDICTION.** Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. ABANDONED EQUIPMENT. Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER.</u> No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. **ASSIGNMENT.** The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. NO INDIVIDUAL LIABILITY. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.