

EVERY DAY SINCE 1946

Motor Shop Repairs

Job Number 97575

Prepared for Reynolds Metals company

1333 highway 270 Malvern AR 72104

Table of Contents

AC Recondition Repair Report	1.0
AC Random Coil Rewind Report	2.0



AC Recondition Repair Report

Reynolds Metals company

1333 highway 270 Malvern, AR 72104

Bener	ral		
1.	Job Number	97575	
2.	Report Date		
3.	Customer	REYNOLDS	
Name	Plate Information		
4.	Manufacturer	RELIANCE	
5.	Model		
6.	Serial Number	L000KE	
7.	Horsepower	7.5	
8.	KW		
9.	Volts	460	
	Amps	11	
11.	RPM	875	
12.	Frame	256TY	
13.	Enclosure	TENV	
14.	Cycles	60	
15.	Phase	3	
16.			
17.	Motor Mount Position		
Initial	Inspection		
18.	Number of Leads	3	
19.	Lead Length	5 Inches	
20.	Lead Size	10	
21.	Lead Condition	(P) Pass	
22.	Lead Markings	metal tags	
23.	Lug Size, Condition, and Type		
24.	Winding RTD's	(NA) Not Applicable	
25.	Winding Rtd's Condition		
26.	Shaft Run Out		
27.	Does Shaft Turn Freely	no	
28.	Does Shaft Have Visible Damage	no	
29.	Bearing Rtd's		
30.	Bearing Rtd's Condition		
31.	Contamination		
32.	Frame Condition	(P) Pass	

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

FolderID: 97575 FormID: 9389742

	Broken or missing components	
Initial	Electric Test	
35.	Resistance to Ground	
36.	Winding Resistance 1-2	
37.	Winding Resistance 2-3	
38.	Winding Resistance 1-3	
39.	Resistive Imbalance	
40.	Hi-Pot	
41.	Surge Test	
	Stator Condition Overheated and iron damaged slightly	
43.	Failure Location	
Initial	Rotor Inspection	
	Rotor Type cast aluminum	
	Air Gap <10% Variation	
46.	-	
	Number of Broken Rotor Bars	
	Growler Test (P) Pas	5
-	Rotor Condition (P) Pas	
- ·	anical Inspection	
	Bearing Manufacture Koyo	_
	Bearing DE Size 6316	
	Bearing DE Type deep groove bal	
	DE Bearing Qty.	
54.		
55.	-	
	Bearing ODE Type deep groove al	
56.		
57.	5	
	Lubrication Type polyrex mixed with rec	
59.		4
	Bearing Retainers	
	Shaft Grounding Device	
	DE Seal	
	DE Seal Type/Size	
	ODE Seal	
	ODE Seal Type/Size	
	Cause of Failure	
	Component Failure DE Bearing seized up	
67.	Cause of Failure	
	Improper lube type added	
68.	Comments	
	Rewind recommended	
69.	Service Technician David Maclin	
	Dun 20	

Ma	achi	ne Fit Inspection Report	
		Shaft Run Out	(P) Pass
	71.	Initial Shaft Run Out	0.002 "
	72.	Final Shaft Run Out	"
	73.	DE Bearing Shaft Fit	(P) Pass
	74.	DE Initial Shaft Bearing Fit Size 1	3.149 "
	75.	DE Initial Shaft Bearing Fit Size 2	3.1492 "
	76.	DE Initial Shaft Bearing Fit Size 3	3.1492 "
		DE Finial Shaft Bearing Fit Size 1	
	78.	DE Finial Shaft Bearing Fit Size 2	
	79.	DE Finial Shaft Bearing Fit Size 3	
	80.	ODE Bearing Shaft Fit	(P) Pass
	81.	ODE Initial Shaft Bearing Fit Size 1	3.1497 "
		ODE Initial Shaft Bearing Fit Size 2	3.1496 "
	83.	ODE Initial Shaft Bearing Fit Size 3	3.1497 "
	84.	ODE Finial Shaft Bearing Fit Size 1	
		ODE Finial Shaft Bearing Fit Size 2	
	86.	ODE Finial Shaft Bearing Fit Size 3	
	87.	DE Air Seal Shaft Fit	
	88.	DE Initial Air Seal Shaft Size	
	89.	DE Final Air Seal Shaft Size	
	90.	ODE Air Seal Shaft Fit	
	91.	ODE Initial Air Seal Shaft Size	
	92.	ODE Final Air Seal Shaft Size	
	93.	DE Endbell Fit	(P) Pass
	94.	DE Initial Endbell Fit Size 1	6.6935 "
	95.	DE Initial Endbell Fit Size 2	6.6935 "
	96.	DE Initial Endbell Fit Size 3	6.6935 "
	97.	DE Final Endbell Fit Size 1	
	98.	DE Finial Endbell Fit Size 2	
	99.	DE Final Endbell Fit Size 3	
	100.	DE Endbell Fit Insulated	
	101.	DE Endbell Air Seal Fit	
	102.	Initial Endbell Air Seal Fit Size	
	103.	Finial Endbell Air Seal Fit Size	
	104.	ODE Endbell Fit	(P) Pass
	105.	ODE Initial Endbell Fit Size 1	6.6932 "
	106.	ODE Initial Endbell Fit Size 2	6.6929 "
	107.	ODE Initial Endbell Fit Size 3	6.6932 "
	108.	ODE Final Endbell Fit Size 1	
	109.	ODE Final Endbell Fit Size 2	
	110.	ODE Final Endbell Fit Size 3	
	111.	ODE Endbell Fit Insulated	
	112.	ODE Endbell Air Seal Fit	
	113.	ODE Initial Endbell Seal Fit Size	
	114.	ODE Finial Endbell Seal Fit Size	
	115.	Foot Flatness	

- 116. Foot Condition
- 117. Flange Condition
- 118. Service Technician

David Maclin

1)// U

Del	- Devent		
	cing Report		
	Balance Type		
	Balance Operating Speed		
	Start Left End		
	Start Right End		
	Balancing Specification		
	Finish Left End		
	Finish Right End		
	Service Technician		_
	nbly and Final Test		Ο
	Meggar Testing Reading	Mohm	
	Surge Test	(P) Pass	
	Hi-Pot	Ua	
130.	Winding Resistance 1-2		
	Winding Resistance 2-3		
132.	Winding Resistance 1-3		
133.	Test Run Voltage Phase A	Volts	P56
	Test Run Amps A		
135.	Test Run Voltage Phase B		
	Test Run Amps B		
	Test Run Voltage Phase C		
	Test Run Amps C		
	DE Horizontal Vibration Reading		
140.	DE Vertical Vibration Reading		
141.	DE Axial Vibration Reading		
142.	ODE Horizontal Vibration Reading		
	ODE Vertical Vibration Reading		
	ODE Axial Vibration Reading		
145.	Ambient Temp at start of Test Run		
146.	Temp at 5 minutes		
147.	Temp at 10 minutes		
148.	Temp at 15 minutes		
149.	Temp at 20 minutes		
150.	Temp at 25 minutes		
151.	Temp at 30 minutes		
152.	Temp at 35 minutes		
153.	Temp at 40 minutes		
154.	Temp at 45 minutes		
155.	Temp at 50 minutes		
156.	Temp at 55 minutes		

157. Temp at 60 minutes

158. Motor Paint

159. Service Technician

Degrees F. (P) Pass P136 **Chris Wiley**

hois Elibo





P1.1





P5.5



P5.9



P5.6:





P5.4






P5.8:



P136.12



P5.3:

P56.10

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

P136.11



P136.13



P136.14



FolderID: 97575 FormID: 9457648

AC Random Coil Rewind Report

Reynolds Metals company 1333 highway 270

Malvern, AR 72104

Priorities Found:

Priorities Found:				
General				
1.	Job Number	97575		
2.	Report Date			
3.	Customer	REYNOLDS		
Name	lame Plate Information			
4.	Manufacturer	RELIANCE		
5.	Model			
6.	Serial Number	L000KE		
7.	Horsepower	7.5		
8.	KW			
9.	Volts	460		
10.	Amps	11		
11.	RPM	875		
12.	Frame	256TY		
13.	Enclosure	TENV		
14.	Cycles	60		
15.	Phase	3		
16.	Service Factor			
17.	Motor Mount Position	F1		
Initial	Inspection			
18.	Number of Leads			
19.	Lead Length			
20.	Lead Size			
21.	Lead Condition			
22.	Lead Markings			
23.	Lug Size, Condition, and Type			
24.	Winding RTD's			
25.	Winding Rtd's Condition			
26.	Shaft Run Out			
27.	Does Shaft Turn Freely			
28.	Does Shaft Have Visible Damage			
29.	Bearing Rtd's			
30.	Bearing Rtd's Condition			
31.	Contamination			
32.	Frame Condition			
33.	Fan Condition			
34.	Broken or missing components			

Initial	Electric Test
	Resistance to Ground
	Winding Resistance 1-2
	Winding Resistance 2-3
	Winding Resistance 1-3
	Resistive Imbalance
	Hi-Pot
	Surge Test
	Stator Condition
43.	Failure Location
Initial	Rotor Inspection
44.	Rotor Type
45.	Air Gap <10% Variation
46.	Number of Rotor Bars
47.	Number of Broken Rotor Bars
48.	Growler Test
49.	Rotor Condition
Mecha	anical Inspection
50.	Bearing Manufacture
51.	Bearing DE Size
	Bearing DE Type
	DE Bearing Qty.
	Bearing ODE Size
	Bearing ODE Type
	ODE Bearing Qty.
	Insulated Bearing
	Lubrication Type
	Grease Condition
	Bearing Retainers
	Shaft Grounding Device
-	DE Seal Type/Size
	ODE Seal
	ODE Seal Type/Size
	Cause of Failure
	Component Failure
	Cause of Failure
	Comments
	Service Technician
	Winding
	Core Length
	Core ID
	Back Iron Depth
	Slot Depth
	Tooth Width
	Number of Vents
76.	Vent Width

77	Before Burnout Core loss
	Flux Before Burnout
	Watts before burnout
	Watts loss per lb. before burnout
	After Burnout Core Loss
	Flux After burnout
	Watts After Burnout
	Watts loss per lb After Burnout
	Core Iron Condition
	RTD's
	RTD's Reading
	Motor Heaters
	Heater Qty.
	Heater Voltage
	Heater Wattage
	Thermistors
93.	Number of Poles
94.	Slots
95.	Number of Coils
96.	Coil Weight
97.	Lead Markings
98.	Grouping
99.	Multiple Wires
100.	Wire Size
	Turns per coil
	Pitch 1 to:
	Connection
	Lead Length
	Lead Size
	Number of Leads
	Megger Reading After Rewind Coil Machine Slot
	Coil Machine Siot
	Coil Machine Tip
	Hi Pot Reading After Rewind
	Surge Pattern After Rewind
	Service Technician
Machi	ne Fit Inspection Report
	Shaft Run Out
115.	Initial Shaft Run Out
116.	Final Shaft Run Out
117.	DE Bearing Shaft Fit
118.	DE Initial Shaft Bearing Fit 1
119.	DE Initial Shaft Fit
	DE Finial Shaft Bearing Fit 1
	DE Initial Shaft Bearing Fit 2
122.	DE Finial Shaft Bearing Fit 2

122. DE Initial Shaft Bearing Fit 3 124. DE Finial Shaft Bearing Fit 1 125. ODE Initial Shaft Bearing Fit 1 126. ODE Initial Shaft Bearing Fit 1 127. ODE Finial Shaft Bearing Fit 1 128. ODE Initial Shaft Bearing Fit 2 129. ODE Finial Shaft Bearing Fit 2 130. ODE Initial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DE Finial Shaft Bearing Fit 3 133. DE Finial Shaft Bearing Fit 3 134. ODE Finial Shaft Bearing Fit 3 135. ODE Finial Shaft Bearing Fit 3 136. ODE Finial Shaft Bearing Fit 3 137. ODE Finial Shaft Bearing Fit 3 138. DE Finital Air Seal Shaft Size 139. DE Chobel Fit 139. DE Chobel Fit Size 1 140. DE Finial Endbel Fit Size 1 141. DE Initial Endbel Fit Size 2 142. DE Finital Endbel Fit Size 2 143. DE Finital Endbel Fit Size 3 144. DE Finital Endbel Fit Size 3 145. DE Endbel Fit Soulat 146. DE Endbel Fit Soulat 147. Initial Endbel Fit Size 3 148. DE Endbel Fit Soulat Soal Fit Size 149. ODE Endbel Fit Soulat Soal Fit Size 144. DE Endbel Fit Soulat Soal Fit Size 145. DE Endbel Fit Soulat Soal Fit		
126. ODE Bearing Shaft Fit 127. ODE Finial Shaft Bearing Fit 1 128. ODE Initial Shaft Bearing Fit 1 129. ODE Finial Shaft Bearing Fit 2 120. ODE Finial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DDE Finial Shaft Bearing Fit 3 133. DE Finial Shaft Bearing Fit 3 134. DDE Finial Shaft Bearing Fit 3 135. DE Finial Shaft Size 136. ODE Kriska Shaft Size 137. ODE Final Air Seal Shaft Fit 138. DE Endbalt State Size 139. DE Endbalt Size Sal Shaft Size 139. DE Endbalt Fit Fit 139. DE Endbalt Fit Size 1 140. DE Final Endbalt Fit Size 2 141. DE finial Endbalt Fit Size 3 142. DE Finial Endbalt Fit Size 3 143. DE Endbalt Fit Size 3 144. DE Finial Endbalt Fit Size 3 145. DE Endbalt Fit Size 3 146. DE Endbalt Fit Size 3 147. Initial Endbalt Fit Size 3 148. DE Endbalt Fit Seal Fit Size 149. ODE Endbalt Fit Seal Fit Size 140. DE Endbalt Fit Seal Fit Size 141. DE Initial Endbalt Seal Fit Size 142. DE Endbalt Fit Seal Fit Size 143. DE Endbalt Fit Seal Fit Size 144. DE Endbalt Fit Se	123.	DE Initial Shaft Bearing Fit 3
126. ODE Initial Shaft Bearing Fit 1 127. ODE Finial Shaft Bearing Fit 2 28. ODE Initial Shaft Bearing Fit 2 130. ODE Initial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DDE Initial Shaft Bearing Fit 3 133. DE Initial Shaft Bearing Fit 3 134. DE Finial Shaft Bearing Fit 3 135. DE Initial Air Seal Shaft Size 136. ODE Initial Air Seal Shaft Size 137. ODE Finial Air Seal Shaft Size 138. DE Endball Fit Size 1 139. ODE Initial Air Seal Shaft Size 139. ODE Initial Air Seal Shaft Size 139. DE Initial Endball Fit Size 1 140. DE Finial Endball Fit Size 1 141. DE Initial Endball Fit Size 2 142. DE Finial Endball Fit Size 2 143. DE Initial Endball Fit Size 3 144. DE Finial Endball Fit Size 3 145. DE Endball Air Seal Fit 146. DE Endball Air Seal Fit 147. Initial Endball Fit Size 1 148. Dirial Endball Fit Size 1 149. ODE Endball Air Seal Fit Size 140. DE Endball Air Seal Fit Size 151. ODE Endball Fit Insulated 152. ODE Initial Endball Fit Size 153. ODE Finial Endball Seal Fit Size	124.	DE Finial Shaft Bearing Fit 3
127. ODE Finial Shaft Bearing Fit 1 128. ODE Initial Shaft Bearing Fit 2 30. ODE Initial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DE Air Seal Shaft Fit 133. DE Initial Air Seal Shaft Size 134. DDE Finial Air Seal Shaft Size 135. ODE Air Seal Shaft Fit 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Initial Air Seal Shaft Size 139. DDE Initial Air Seal Shaft Size 139. DE Initial Air Seal Shaft Size 139. DE Initial Air Seal Shaft Size 139. DE Initial Chebell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 2 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Fit Insulated 147. Initial Endbell Fit Size 3 148. Finial Endbell Fit Size 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Size 151. ODE Endbell Fit Size 152. ODE Initial Endbell Fit Size 153. ODE Endbell Fit Size 154. Foot	125.	ODE Bearing Shaft Fit
128. ODE Initial Shaft Bearing Fit 2 129. ODE Finial Shaft Bearing Fit 3 130. ODE Initial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DE Initial Shaft State Initial Air Seal Shaft Size 133. DE Initial Air Seal Shaft Size 134. DDE Finial Air Seal Shaft Size 135. ODE Air Seal Shaft Size 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. ODE Finital Air Seal Shaft Size 139. DE Initial Air Seal Shaft Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Finial Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Size 3 146. DE Endbell Fit Size 3 147. DE Finial Endbell Fit Size 3 148. Finial Endbell Fit Size 3 144. DE Finial Endbell Fit Size 3 145. DE Endbell Fit Nesueted 146. DE Endbell Fit Size 4 147. Initial Endbell Fit Size 5 148. Finial Endbell Fit Size 5 149. ODE Endbell Fit Size 5 150. DE Endbell Fit Size 6 151. ODE Endbel Air Seal Fit Size 7	126.	ODE Initial Shaft Bearing Fit 1
129. ODE Finial Shaft Bearing Fit 2 130. ODE Initial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DE Air Seal Shaft Fit 133. DE Initial Air Seal Shaft Size 134. DE Final Air Seal Shaft Size 135. ODE Air Seal Shaft Fit 136. ODE Final Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Endbell Fit 139. DE Initial Air Seal Shaft Size 131. DE Initial Air Seal Shaft Size 132. DE Final Air Seal Shaft Size 133. DE Endbell Fit 139. DE Initial Air Seal Shaft Size 139. DE Initial Air Seal Shaft Size 1 140. DE Final Endbell Fit Size 2 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Fit Insulated 147. Initia Endbell Air Seal Fit Size 148. Finial Endbell Fit Size 5 150. ODE Endbell Fit Insulated 151. ODE Endbell Fit Size 153. ODE Finital Endbell Size Fit Size 154. Foot Flatmess 155. Foot Condition 156. Finage Condetion 157. Service Technician	127.	ODE Finial Shaft Bearing Fit 1
130. ODE Initial Shaft Bearing Fit 3 131. ODE Finial Shaft Bearing Fit 3 132. DE Air Seal Shaft Fit 133. DE Initial Air Seal Shaft Size 134. DE Final Air Seal Shaft Size 135. ODE Air Seal Shaft Fit 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. ODE Initial Air Seal Shaft Size 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 2 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Size 3 146. DE Endbell Fit Size 3 147. Initial Endbell Fit Size 3 148. DE Final Endbell Fit Size 3 149. ODE Endbell Fit Size 3 140. DE Endbell Fit Size 3 141. DE Final Endbell Fit Size 3 142. DE Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Size 3 146. DE Endbell Fit Insulated 150. ODE Endbell Air Seal Fit Size 151. ODE Endbell Fit Insulated 152. ODE Initial Endbell Seal Fit Size 153. ODE Final Endbe	128.	ODE Initial Shaft Bearing Fit 2
131. ODE Finial Shaft Bearing Fit 3 132. DE hirtikal Air Seal Shaft Size 133. DE Initial Air Seal Shaft Size 134. DE Finial Air Seal Shaft Size 135. ODE Air Seal Shaft Size 136. ODE Inital Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Endball Fit 139. DE Endball Fit Size 1 141. DE Final Endball Fit Size 1 142. DE Final Endball Fit Size 2 143. DE Initial Endball Fit Size 3 144. DE Final Endball Fit Size 3 145. DE Endball Fit Size 3 146. DE Endball Fit Size 3 147. DE Final Endball Fit Size 3 148. DE Final Endball Fit Size 3 149. DE Final Endball Fit Size 3 144. DE Final Endball Fit Size 3 145. DE Endball Air Seal Fit Size 146. DE Endball Air Seal Fit Size 147. Initial Endball Air Seal Fit Size 148. Die Endball Air Seal Fit Size 150. ODE Endball Fit Insulated 151. ODE Endball Fit Insulated 152. ODE Initial Endball Seal Fit Size 153. ODE Final Endball Seal Fit Size 154. Foot Final Endball Seal Fit Size 155. Foot Condition 156. Finage Condition 157. Service Technician<	129.	ODE Finial Shaft Bearing Fit 2
132. DE Air Seal Shaft Fit 133. DE Initial Air Seal Shaft Size 134. DE Final Air Seal Shaft Fit 135. ODE Air Seal Shaft Fit 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Endoell Fit 139. DE Initial Air Seal Shaft Size 139. DE Initial Endoell Fit Size 1 140. DE Final Endoell Fit Size 2 141. DE Initial Endoell Fit Size 2 142. DE Final Endoell Fit Size 3 144. DE Final Endoell Fit Size 3 145. DE Endoell Fit Size 3 146. DE Endoell Fit Size 3 147. Initial Endoell Fit Size 3 148. Final Endoell Fit Size 3 144. DE Final Endoell Fit Size 3 145. DE Endoell Air Seal Fit Size 146. DE Endoell Fit Insulated 147. Initial Endoell Air Seal Fit Size 148. Finial Endoell Air Seal Fit Size 150. ODE Endoell Fit Insulated 151. ODE Endoell Fit Insulated 152. ODE Initial Endoell Seal Fit Size 153. ODE Endoell Fit Insulated 154. Foot Final Endoell Seal Fit Size 155. ODE Condition 156. Flange Condition 157. Service Technician Balance Operating Speed	130.	ODE Initial Shaft Bearing Fit 3
133. DE Initial Air Seal Shaft Size 134. DE Final Air Seal Shaft Size 135. ODE Air Seal Shaft Size 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Endbell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Size 3 146. DE Endbell Fit Size 3 147. Initial Endbell Fit Size 3 148. Final Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Air Seal Fit Size 146. DE Endbell Air Seal Fit Size 147. Initial Endbell Fit Size 3 148. Final Endbell Fit Size 3 149. ODE Endbell Air Seal Fit Size 149. ODE Endbell Air Seal Fit Size 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Endbell Air Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Foot Condition 157. Service Technician	131.	ODE Finial Shaft Bearing Fit 3
134. DE Final Air Seal Shaft Size 135. ODE Air Seal Shaft Size 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Endbell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Size 3 146. DE Endbell Fit Size 3 147. Initial Endbell Fit Size 3 148. Dia Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Air Seal Fit 146. DE Endbell Fit Insulated 147. Initial Endbell Fit Size 1 148. Final Endbell Fit Size 1 149. ODE Endbell Fit Naulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Fit Insulated 152. ODE Initial Endbell Seal Fit Size 153. ODE Condition 154. Foot Flatness 155. Foot Condition 155. Foot Condition 156. Flatge Condition 157. Service Technician Balance Type 158. Balance Operating Speed 160	132.	DE Air Seal Shaft Fit
135. ODE Air Seal Shaft Fit 136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Endbell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Finial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Fit Insulated 147. Initial Endbell Fit Size 3 148. DE Final Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Air Seal Fit Size 146. DE Endbell Air Seal Fit Size 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Fit Insulated 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Finial Endbell Seal Fit Size 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specific	133.	DE Initial Air Seal Shaft Size
136. ODE Initial Air Seal Shaft Size 137. ODE Final Air Seal Shaft Size 138. DE Initial Endbell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 2 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Air Seal Fit 146. DE Endbell Air Seal Fit 1size 3 147. Initial Endbell Air Seal Fit Size 148. Final Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Air Seal Fit 1size 3 146. DE Endbell Air Seal Fit Size 147. Initial Endbell Air Seal Fit Size 148. Final Endbell Air Seal Fit Size 149. ODE Endbell Air Seal Fit Size 140. DE Endbell Air Seal Fit Size 151. ODE Endbell Air Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Final Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Type 158. Balance Type 159. Balance Operating Speed 160. Stat Left End <t< th=""><th>134.</th><th>DE Final Air Seal Shaft Size</th></t<>	134.	DE Final Air Seal Shaft Size
137. ODE Final Air Seal Shaft Size 138. DE Endbell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 2 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 144. DE Endbell Fit Insulated 145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. Final Endbell Air Seal Fit Size 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Type 158. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End	135.	ODE Air Seal Shaft Fit
138. DE Endbell Fit 139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Finial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 144. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 5ize 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Final Endbell Seal Fit Size 154. Foot Endbell Seal Fit Size 155. Foot Condition 156. Flage Condition 157. Service Technician Balancing Report 158. Balance Operating Speed 169. Start Right End 161. Start Right End 162. Service Technician 163. Finish Left End 164. Finish Right End 165. Service Technician	136.	ODE Initial Air Seal Shaft Size
139. DE Initial Endbell Fit Size 1 140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Finial Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Fit Insulated 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Fit Insulated 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Right End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Finise Kight End 165. Service Technician	137.	ODE Final Air Seal Shaft Size
140. DE Final Endbell Fit Size 1 141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. DDE Endbell Air Seal Fit Size 149. ODE Endbell Air Seal Fit Size 149. ODE Endbell Air Seal Fit Size 149. ODE Endbell Air Seal Fit Size 150. ODE Endbell Fit Insulated 151. ODE Endbell Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Final Endbell Seal Fit Size 154. Foot Condition 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician	138.	DE Endbell Fit
141. DE Initial Endbell Fit Size 2 142. DE Final Endbell Fit Size 3 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 144. DE Endbell Fit Insulated 145. DE Endbell Air Seal Fit 146. DE Endbell Air Seal Fit Size 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician	139.	DE Initial Endbell Fit Size 1
142. DE Finial Endbell Fit Size 2 143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Air Seal Fit Size 149. ODE Endbell Fit 150. ODE Endbell Fit Insulated 151. ODE Endbell Fit Insulated 152. ODE Initial Endbell Seal Fit Size 153. ODE Endbell Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Report 163. Belfication 164. Finish Right End 165. Service Technician	140.	DE Final Endbell Fit Size 1
143. DE Initial Endbell Fit Size 3 144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. DOE Endbell Fit Insulated 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Fit Insulated 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balanceing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician	141.	DE Initial Endbell Fit Size 2
144. DE Final Endbell Fit Size 3 145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. Final Endbell Air Seal Fit Size 149. ODE Endbell Fit Insulated 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Type 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Right End 164. Finish Right End 165. Service Technician		
145. DE Endbell Fit Insulated 146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Fit 150. ODE Endbell Fit 151. ODE Endbell Air Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician	143.	DE Initial Endbell Fit Size 3
146. DE Endbell Air Seal Fit 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Fit 150. ODE Endbell Fit Insulated 151. ODE Endbell Seal Fit 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician	144.	DE Final Endbell Fit Size 3
 147. Initial Endbell Air Seal Fit Size 148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Fit 150. ODE Endbell Fit Insulated 151. ODE Endbell Seal Fit Size 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Type 158. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 	145.	DE Endbell Fit Insulated
148. Finial Endbell Air Seal Fit Size 149. ODE Endbell Fit 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician	146.	DE Endbell Air Seal Fit
149. ODE Endbell Fit 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician		
 150. ODE Endbell Fit Insulated 151. ODE Endbell Air Seal Fit 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Type 158. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 		
 151. ODE Endbell Air Seal Fit 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balance Type 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		
 152. ODE Initial Endbell Seal Fit Size 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 		
 153. ODE Finial Endbell Seal Fit Size 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 	151.	ODE Endbell Air Seal Fit
 154. Foot Flatness 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 		
 155. Foot Condition 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 		
 156. Flange Condition 157. Service Technician Balancing Report 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test 		
157. Service TechnicianBalancing Report158. Balance Type159. Balance Operating Speed160. Start Left End161. Start Right End162. Balancing Specification163. Finish Left End164. Finish Right End165. Service TechnicianAssembly and Final Test		
Balancing Report158. Balance Type159. Balance Operating Speed160. Start Left End161. Start Right End162. Balancing Specification163. Finish Left End164. Finish Right End165. Service TechnicianAssembly and Final Test		-
 158. Balance Type 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		
 159. Balance Operating Speed 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		
 160. Start Left End 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		
 161. Start Right End 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		
 162. Balancing Specification 163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		
163. Finish Left End 164. Finish Right End 165. Service Technician Assembly and Final Test		-
164. Finish Right End 165. Service Technician Assembly and Final Test		
165. Service Technician Assembly and Final Test		
Assembly and Final Test		
•		
166. Meggar Testing Reading		•
	166.	Meggar Testing Reading

167.	Surge Test
168.	Hi-Pot
169.	Winding Resistance 1-2
170.	Winding Resistance 2-3
171.	Winding Resistance 1-3
172.	Test Run Voltage Phase A
173.	Test Run Amps A
174.	Test Run Voltage Phase B
175.	Test Run Amps B
176.	Test Run Voltage Phase C
177.	Test Run Amps C
178.	DE Horizontal Vibration Reading
179.	DE Vertical Vibration Reading
180.	DE Axial Vibration Reading
181.	ODE Horizontal Vibration Reading
182.	ODE Vertical Vibration Reading
183.	ODE Axial Vibration Reading
184.	Ambient Temp at start of Test Run
185.	Temp at 5 minutes
186.	Temp at 10 minutes
187.	Temp at 15 minutes
188.	Temp at 20 minutes
189.	Temp at 25 minutes
190.	Temp at 30 minutes
191.	Temp at 35 minutes
192.	Temp at 40 minutes
193.	Temp at 45 minutes
194.	Temp at 50 minutes
195.	Temp at 55 minutes
196.	Temp at 60 minutes
197.	Motor Paint
198.	Service Technician



STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. <u>APPLICABILITY.</u> The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. <u>SCOPE OF GOODS AND/OR SERVICES.</u> The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only be effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. DELIVERY OF GOODS AND/OR SERVICES. Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- 6. DELIVERY SITE AND TIME FOR PERFORMANCE. Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

TermsAndConditions

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. LIMITATION OF DAMAGES. HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY</u>. The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. <u>GOVERNING LAW AND JURISDICTION.</u> Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. <u>ABANDONED EQUIPMENT.</u> Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER</u>. No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. <u>ASSIGNMENT.</u> The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. <u>NO INDIVIDUAL LIABILITY</u>. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.