

EVERY DAY SINCE 1946

Motor Shop Repairs

Job Number 98015

Prepared for MIDWEST MOBILE WATER

555 BARGE CHANNEO RD ST PAUL MN 55107

Table of Contents

AC Recondition Repair Report



Hi-Speed Industrial Service 7030 Ryburn Dr Millington, Tn 38053 901-873-5300

> 98015 3/23/2021

> > LLC.

HYDROMATIC

MIDWEST MOBILE WATER JET

FolderID: 98015 FormID: 10291395

AC Recondition Repair Report

MIDWEST MOBILE WATER

555 BARGE CHANNEO RD ST PAUL, MN 55107

Priorities Found: 🛑 2 - High	🔵 9 - Good
General	
1. Job Number	

- 2. Report Date
- 3. Customer

Name Plate Information

4. Manufacturer















5.	Model	4 S4M750M3-4 86	
6.	Serial Number	21535	
7.	Horsepower	7.5	
8.	KW		
9.	Volts	230	
10.	Amps	23.2	
11.	RPM		
12.	Frame		
13.	Enclosure	SUMP PUMP	
14.	Cycles	60	
15.	Phase	3	
16.	Service Factor		
17.	Motor Mount Position		
Initial	Initial Inspection		
18.	Number of Leads	9	
19.	Lead Length	15 Inches	
20	Lood Cine		

20. Lead Size







22.	Lead Markings	1-9
23.	Lug Size, Condition, and Type	
24.	Winding RTD's	
25.	Winding Rtd's Condition	
26.	Shaft Run Out	0.001
27.	Does Shaft Turn Freely	yes
28.	Does Shaft Have Visible Damage	no

29. Bearing Rtd's





30.	Bearing Rtd's Condition	
31.	Contamination	
32.	Frame Condition	(P) Pass
33.	Fan Condition	
34.	Broken or missing components	
	Top cap seal tights	
Initial	Electric Test	
35.	Resistance to Ground	
36.	Winding Resistance 1-2	
37.	Winding Resistance 2-3	
38.	Winding Resistance 1-3	
39.	Resistive Imbalance	
40.	Hi-Pot	
• 41.	Surge Test	(F) Fail
42.	Stator Condition	rewind



43. Failure Location

Initial Rotor Inspection

44. Rotor Type



45.	Air Gap <10% Variation	
46.	Number of Rotor Bars	44
47.	Number of Broken Rotor Bars	0
48.	Growler Test	(P) Pass

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.



leads/connection

cast aluminum

49.	Rotor Condition	(P) Pass
Mecha	anical Inspection	
50.	Bearing Manufacture	ntn
51.	Bearing DE Size	6308
52.	Bearing DE Type	ball
53.	DE Bearing Qty.	1
54.	Bearing ODE Size	6206
55.	Bearing ODE Type	ball
56.	ODE Bearing Qty.	1
57.	Insulated Bearing	
58.	Lubrication Type	oil
59.	Grease Condition	
60.	Bearing Retainers	
61.	Shaft Grounding Device	
62.	DE Seal	(Y) Yes



(63.	DE Seal Type/Size	carbon ceramic 1 1/2x 2 1/8 quantity of 2
(64.	ODE Seal	
(65.	ODE Seal Type/Size	
Ro	ot (Cause of Failure	
(66.	Component Failure	windings/bearings/top cap/power cords
(67.	Cause of Failure	
		Shorted leads	
(68.	Comments	
(69.	Service Technician	
Ма	chi	ne Fit Inspection Report	
	70.	Shaft Run Out	(P) Pass
-	71.	Initial Shaft Run Out	0.001 "
-	72.	Final Shaft Run Out	
	73.	DE Bearing Shaft Fit	(P) Pass
	74.	DE Initial Shaft Bearing Fit Size 1	1.5751 "
-	75.	DE Initial Shaft Bearing Fit Size 2	1.5751 "
	76.	DE Initial Shaft Bearing Fit Size 3	1.5751 "
-	77.	DE Finial Shaft Bearing Fit Size 1	

78. DE Finial Shaft Bearing Fit Size 3 (P) Pass 80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit Size 1 1.1815* 82. ODE Initial Shaft Bearing Fit Size 3 1.1815* 83. ODE Finial Shaft Bearing Fit Size 3 1.1815* 84. ODE Finial Shaft Bearing Fit Size 3 1.1815* 85. ODE Finial Shaft Bearing Fit Size 2			
80. ODE Bearing Shaft Fit (P) Pass 81. ODE Initial Shaft Bearing Fit Size 1 1.1815 * 82. ODE Initial Shaft Bearing Fit Size 2 1.1815 * 83. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 84. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 85. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 86. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 87. DE Finial Shaft Bearing Fit Size 3 1.1815 * 88. DE Hindial Air Seal Shaft Size 1.1815 * 90. ODE Air Seal Shaft Fit 1.1815 * 91. ODE Finial Air Seal Shaft Size 1.1815 * 92. ODE Final Air Seal Shaft Size 1.1815 * 93. DE Endbell Fit Size 1 3.5442 * 94. DE Initial Endbell Fit Size 1 3.5442 * 95. DE Initial Endbell Fit Size 1 3.5442 * 96. DE Finial Endbell Fit Size 1 1.1815 * 97. DE Endbell Air Seal Fit Size 3 3.5442 * 98. DE Finial Endbell Fit Size 1 2.4416 * 100. DE Endbell Air Seal Fit Size 1 2.4416 * 101. DE Endbell Air Seal Fit Size 1 2.4416 * 102. ODE Finial Endbell Fit Size 1 2.4416 *	78	5. DE Finial Shaft Bearing Fit Size 2	
81. ODE Initial Shaft Bearing Fit Size 1 1.1815 * 82. ODE Initial Shaft Bearing Fit Size 2 1.1815 * 83. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 84. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 85. ODE Finial Shaft Bearing Fit Size 3	79	DE Finial Shaft Bearing Fit Size 3	
82. ODE Initial Shaft Bearing Fit Size 2 1.1815 * 83. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 84. ODE Finial Shaft Bearing Fit Size 2 1.1815 * 85. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 86. ODE Finial Shaft Bearing Fit Size 3 1.1815 * 87. DE Air Seal Shaft Fit 1.1815 * 89. DE Finial Air Seal Shaft Size 1.1815 * 91. ODE Finial Air Seal Shaft Size 1.1815 * 92. ODE Finial Air Seal Shaft Size 1.1815 * 93. DE Endbell Fit (P) Pass 94. DE Initial Endbell Fit Size 1 3.5442 * 95. DE Initial Endbell Fit Size 1 3.5442 * 96. DE Initial Endbell Fit Size 1 3.5442 * 97. DE Finial Endbell Fit Size 3 3.5442 * 98. DE Finial Endbell Fit Size 1 2.4416 * 100. DE Endbell Fit Size 3 3.5442 * 98. DE Finial Endbell Fit Size 3 3.5442 * 99. DE Finial Endbell Fit Size 1 2.4416 * 101. DE Endbell Fit Size 3 2.4416 *	80	. ODE Bearing Shaft Fit	(P) Pass
83. ODE Initial Shaft Bearing Fit Size 3 1.1815* 84. ODE Finial Shaft Bearing Fit Size 1	81	. ODE Initial Shaft Bearing Fit Size 1	1.1815 "
83. ODE Initial Shaft Bearing Fit Size 3 1.1815* 84. ODE Finial Shaft Bearing Fit Size 1	82	. ODE Initial Shaft Bearing Fit Size 2	1.1815 "
94. ODE Finial Shaft Bearing Fit Size 1 95. ODE Finial Shaft Bearing Fit Size 3 87. DE Ar Seal Shaft Fit 98. DE Initial Air Seal Shaft Size 90. ODE Finial Shaft Bearing Fit Size 3 90. DE Initial Air Seal Shaft Size 90. ODE Air Seal Shaft Fit 91. ODE Initial Air Seal Shaft Size 92. ODE Final Air Seal Shaft Size 93. DE Endell Fit 93. DE Endell Fit (P) Pass 94. DE Initial Endell Fit Size 1 95. DE Endell Fit Size 2 96. DE Initial Endell Fit Size 3 97. DE Final Endell Fit Size 1 98. DE Endell Fit Size 3 99. DE Final Endell Fit Size 3 90. DE Endell Air Seal Shaft Size 3 91. DE Endell Fit Size 3 92. DE Endell Fit Insulated 93. DE Endell Fit Insulated 94. DE Endell Fit Insulated 95. ODE Initial Endell Fit Size 3 96. ODE Initial Endell Fit Size 1 97. ODE Endell Fit Size 1 97. DE Endell Air Seal Fit Size 1 98. DE Endell Air Seal Fit Size 1 99. DE Final Endell Fit Size 3 99. DE Final Endell Fit Size 3 99. DE Final Endell Fit Size 3 99. DE F		-	1.1815 "
85. ODE Finial Shaft Bearing Fit Size 3 86. DDE Finial Shaft Bearing Fit Size 3 87. DE Air Seal Shaft Fit 89. DE Finial Air Seal Shaft Size 90. ODE Air Seal Shaft Size 91. ODE Tinial Air Seal Shaft Size 92. ODE Finial Air Seal Shaft Size 93. DE Endbell Fit 94. DE Initial Endbell Fit Size 1 95. DE Initial Endbell Fit Size 1 96. DE Initial Endbell Fit Size 1 97. DE Finial Endbell Fit Size 1 98. DE Finial Endbell Fit Size 1 99. DE Finial Endbell Fit Size 3 90. DE Finial Endbell Fit Size 3 91. DE Endbell Air Seal Fit Size 3 92. DE Finial Endbell Fit Size 3 93. DE Finial Endbell Air Seal Fit Size 3 94. DE Initial Endbell Air Seal Fit Size 3 95. DE Initial Endbell Fit Size 1 96. DE Finial Endbell Fit Size 1 97. DE Finial Endbell Fit Size 1 98. DE Finial Endbell Fit Size 1 99. DE Finial Endbell Fit Size 1 90. DE Endbell		-	
86. ODE Finial Shaft Bearing Fit Size 3 87. DE Finial Air Seal Shaft Fit 89. DE Finial Air Seal Shaft Size 90. ODE Air Seal Shaft Size 91. ODE Initial Air Seal Shaft Size 92. ODE Final Air Seal Shaft Size 93. DE Endeal Fit 93. DE Endbell Fit 93. DE Endbell Fit Size 1 93. DE Initial Endbell Fit Size 2 94. DE Initial Endbell Fit Size 1 95. DE Initial Endbell Fit Size 3 96. DE Finial Endbell Fit Size 1 97. DE Finial Endbell Fit Size 2 99. DE Finial Endbell Fit Size 3 90. DE Endbell Fit Insulated 101. DE Endbell Fit Size 3 102. Initial Endbell Fit Size 1 103. DE Endbell Fit Insulated 104. ODE Endbell Fit Size 1 105. ODE Initial Endbell Fit Size 1 106. ODE Endbell Fit Size 1 107. ODE Endbell Fit Size 1 108. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 101. ODE Final Endbell Fit Size 1 102. ODE Initial Endbell Fit Size 3 103. ODE Final Endbell Fit Size 3 104. ODE Final Endbell Fit Size 3 105. ODE Final Endbell Fit Size 3 106. ODE Final Endbell Fit Size 3		-	
87. DE Air Seal Shaft Fit 88. DE Initial Air Seal Shaft Size 90. DE Air Seal Shaft Fit 91. ODE Air Seal Shaft Fit 92. ODE Final Air Seal Shaft Size 93. DE Endbell Fit 93. DE Endbell Fit 94. DE Initial Air Seal Shaft Size 95. DE Hotell Fit 96. DE Initial Endbell Fit Size 1 97. DE Final Endbell Fit Size 3 98. DE Endbell Fit Size 1 99. DE Final Endbell Fit Size 1 99. DE Final Endbell Fit Size 3 90. DE Final Endbell Fit Size 1 91. DE Endbell Air Seal Fit Size 1 92. ODE Endbell Fit Size 3 93. DE Endbell Fit Size 3 94. DE Endbell Fit Size 1 95. DE Endbell Fit Size 1 96. DE Endbell Fit Size 1 97. DE Final Endbell Fit Size 3 98. DE Endbell Fit Size 3 99. DE Endbell Fit Size 1 90. DE Endbell Fit Size 3 914. ODE Endbell Fit Size 3 915. ODE Initial Endbell Fit Size 3 916. ODE Initial Endbell Fit Size 3 917. ODE Endbell Fit Size 3 918. ODE Final Endbell Fit Size 3 919. ODE Final Endbell Fit Size 3 910. ODE Final Endbell Fit Size 3		-	
88. DE Initial Air Seal Shaft Size 90. DDE Air Seal Shaft Size 91. ODE Initial Air Seal Shaft Size 92. ODE Final Air Seal Shaft Size 93. DE Endbell Fit 94. DE Initial Endbell Fit Size 1 95. DE Initial Endbell Fit Size 1 96. DE Initial Endbell Fit Size 1 97. DE Final Endbell Fit Size 2 98. DE Finital Endbell Fit Size 1 99. DE Finital Endbell Fit Size 3 90. DE Finital Endbell Fit Size 3 91. DE Endbell Fit Size 3 92. DE Finital Endbell Fit Size 3 93. DE Finial Endbell Fit Size 3 94. DE Entital Endbell Fit Size 3 95. DE Finial Endbell Fit Size 4 96. DE Finial Endbell Fit Size 4 97. DE Endbell Air Seal Fit 98. DE Finial Endbell Fit Size 5 99. DE Finial Endbell Fit Size 4 90. DE Endbell Air Seal Fit 91. DE Endbell Fit Size 1 92. DE Initial Endbell Fit Size 1 93. DE Initial Endbell Fit Size 1 94. ODE Initial Endbell Fit Size 1 95. ODE Initial Endbell Fit Size 1 96. ODE Final Endbell Fit Size 1 97. ODE Endbell Fit Insulated 98. ODE Final Endbell Fit Size 1		-	
89. DE Final Air Seal Shaft Size 90. ODE Air Seal Shaft Size 91. ODE Initial Air Seal Shaft Size 92. ODE Final Air Seal Shaft Size 93. DE Endbell Fit (P) Pass 94. DE Initial Endbell Fit Size 1 3.5442 " 95. DE Initial Endbell Fit Size 2 3.5442 " 96. DE Initial Endbell Fit Size 3 3.5442 " 97. DE Final Endbell Fit Size 1 3.5442 " 98. DE Final Endbell Fit Size 3 3.5442 " 99. DE Final Endbell Fit Size 3 3.5442 " 99. DE Final Endbell Fit Size 3 3.5442 " 90. DE Final Endbell Fit Size 3 3.5442 " 91. DE Final Endbell Fit Size 1 3.5442 " 92. DE Final Endbell Fit Size 3 4.542 " 93. DE Final Endbell Fit Size 3 (P) Pass 104. DE Endbell Fit Size 1 2.4416 " 105. ODE Initial Endbell Fit Size 1 2.4416 " 106. ODE Initial Endbell Fit Size 1 2.4416 " 107. ODE Initial Endbell Fit Size 3 2.4416 " 108. ODE Final Endbell Fit Size 3 2.4416 " 109. ODE Final Endbell Fit Size 3 2.4416 " 110. ODE Final Endbell Fit Size 3 2.4416 " 111. ODE Endbell Fit Size 3	-		
90. ODE Air Seal Shaft Size 92. ODE Final Air Seal Shaft Size 93. DE Endbell Fit (P) Pass 94. DE Initial Kroel Shaft Size 3.5442* 95. DE Initial Endbell Fit Size 1 3.5442* 96. DE Initial Endbell Fit Size 2 3.5442* 96. DE Initial Endbell Fit Size 3 3.5442* 96. DE Final Endbell Fit Size 1 3.5442* 97. DE Final Endbell Fit Size 1 3.5442* 98. DE Final Endbell Fit Size 1 3.5442* 99. DE Final Endbell Fit Size 1 5.442* 99. DE Final Endbell Fit Size 3 5.442* 90. DE Endbell Fit Insulated (P) Pass 100. DE Endbell Fit Insulated (P) Pass 101. DE Endbell Fit Size 1 2.4416* 102. Initial Endbell Fit Size 1 2.4416* 103. ODE Initial Endbell Fit Size 3 2.4416* 104. ODE Endbell Fit Size 2 2.4416* 105. ODE Initial Endbell Fit Size 3 2.4416* 106. ODE Initial Endbell Fit Size 3 2.4416* 109. ODE Final Endbell Fit Size 1 2.4416* 109. ODE Final Endbell Fit Size 3 2.4416* 110. ODE Endbell Fit Size 3			
91. ODE Initial Air Seal Shaft Size 92. ODE Final Air Seal Shaft Size 93. DE Endbell Fit (P) Pass 94. DE Initial Endbell Fit Size 1 3.5442 * 95. DE Initial Endbell Fit Size 2 3.5442 * 96. DE Initial Endbell Fit Size 3 3.5442 * 97. DE Final Endbell Fit Size 1 3.5442 * 98. DE Finial Endbell Fit Size 3 3.5442 * 99. DE Final Endbell Fit Size 3 3.5442 * 90. DE Endbell Fit Size 3 4.542 * 91. DE Endbell Fit Size 3 5.442 * 92. DE Final Endbell Fit Size 3 5.442 * 93. DE Endbell Fit Size 3 5.442 * 94. DE Endbell Fit Size 3 5.442 * 95. DE Endbell Fit Size 1 5.25 96. DE Endbell Fit Size 1 2.4416 * 97. DE Initial Endbell Fit Size 3 2.4416 * 96. ODE Initial Endbell Fit Size 3 2.4416 * 97. ODE Initial Endbell Fit Size 3 2.4416 * 98. ODE Final Endbell Fit Size 3 2.4416 * 99. DE Final Endbell Fit Size 3 2.4416 * 99. ODE Final Endbell Fit Size 3 2.4416 * 99. ODE Final Endbell Fit Size 3 2.4416 * 99. ODE Final Endbell Fit S			
92. ODE Final Air Seal Shaft Size 93. DE Endbell Fit (P) Pass 94. DE Initial Endbell Fit Size 1 3.5442 " 95. DE Initial Endbell Fit Size 2 3.5442 " 96. DE Initial Endbell Fit Size 3 3.5442 " 97. DE Final Endbell Fit Size 1 3.5442 " 98. DE Finial Endbell Fit Size 2 3.5442 " 99. DE Final Endbell Fit Size 3 3.5442 " 90. DE Endbell Fit Insulated T 101. DE Endbell Fit Size 3 T 102. Initial Endbell Fit Size 1 (P) Pass 103. Finial Endbell Fit Size 1 2.4416 " 104. ODE Endbell Fit Naulated (P) Pass 105. ODE Initial Endbell Fit Size 1 2.4416 " 106. ODE Final Endbell Fit Size 3 2.4416 " 107. ODE Final Endbell Fit Size 3 2.4416 " 108. ODE Final Endbell Fit Size 3 2.4416 " 109. ODE Final Endbell Fit Size 3 1.4112 110. ODE Endbell Fit Insulated T 111. ODE Endbell Fit Size 3 T 112. ODE Endbell Fit Size 3 T 113. ODE Initial Endbell Seal Fit Size T 114. ODE Final Endbell Seal Fit Size T 115. Foot Flatness </td <td></td> <td></td> <td></td>			
93. DE Endbell Fit (P) Pass 94. DE Initial Endbell Fit Size 1 3.5442 " 95. DE Initial Endbell Fit Size 2 3.5442 " 96. DE Initial Endbell Fit Size 3 3.5442 " 97. DE Final Endbell Fit Size 1 3.5442 " 98. DE Finial Endbell Fit Size 2 3.5442 " 99. DE Final Endbell Fit Size 3 3.5442 " 90. DE Endbell Fit Insulated			
94. DE Initial Endbell Fit Size 1 3.5442 " 95. DE Initial Endbell Fit Size 2 3.5442 " 96. DE Initial Endbell Fit Size 3 3.5442 " 97. DE Final Endbell Fit Size 1	-		
95. DE Initial Endbell Fit Size 2 3.5442 " 96. DE Initial Endbell Fit Size 3 3.5442 " 97. DE Final Endbell Fit Size 1	-		
96. DE Initial Endbell Fit Size 3 3.5442 " 97. DE Final Endbell Fit Size 1			
97. DE Final Endbell Fit Size 1 98. DE Final Endbell Fit Size 2 99. DE Final Endbell Fit Insulated 100. DE Endbell Fit Insulated 101. DE Endbell Air Seal Fit 102. Initial Endbell Air Seal Fit Size 103. Final Endbell Fit Size 1 104. ODE Endbell Fit Size 1 105. ODE Initial Endbell Air Seal Fit Size 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 4 109. ODE Final Endbell Fit Size 3 101. ODE Final Endbell Fit Size 3 102. Initial Endbell Fit Size 3 103. For Eatnese 104. ODE Final Endbell Fit Size 3 105. ODE Initial Endbell Fit Size 3 106. ODE Final Endbell Fit Size 3 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Air Seal Fit 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Final Endbell Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Start Edt End 119. Balance Operating Speed 120. Balance Operating Speed 121. Start Lef			3.5442 "
98. DE Final Endbell Fit Size 2 99. DE Final Endbell Fit Size 3 100. DE Endbell Fit Insulated 101. DE Endbell Air Seal Fit 102. Initial Endbell Air Seal Fit Size 103. Finial Endbell Fit Size 1 104. ODE Initial Endbell Fit Size 2 105. ODE Initial Endbell Fit Size 1 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Size 3 112. ODE Endbell Fit Size 3 113. ODE Initial Endbell Seal Fit Size 114. ODE Final Endbell Seal Fit Size 115. Foot Flantess 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End	96	5. DE Initial Endbell Fit Size 3	3.5442 "
99. DE Final Endbell Fit Isualated 100. DE Endbell Air Seal Fit 101. DE Endbell Air Seal Fit 102. Initial Endbell Air Seal Fit Size 103. Finial Endbell Air Seal Fit Size 104. ODE Endbell Fit Size 1 105. ODE Initial Endbell Fit Size 2 106. ODE Initial Endbell Fit Size 3 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 3 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Size 3 112. ODE Endbell Fit Size 3 113. ODE Initial Endbell Seal Fit Size 114. ODE Final Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End	97	. DE Final Endbell Fit Size 1	
100. DE Endbell Fit Insulated 101. DE Endbell Air Seal Fit 102. Initial Endbell Air Seal Fit Size 103. Finial Endbell Air Seal Fit Size 104. ODE Endbell Fit 105. ODE Initial Endbell Fit Size 1 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 1 109. ODE Final Endbell Fit Size 2 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Size 3 112. ODE Endbell Fit Size 3 113. ODE Initial Endbell Fit Size 114. ODE Finial Endbell Fit Size 1 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician 208 209 2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2021 2031 2041 2045 2046 2047 2048 2049 2040	98	. DE Finial Endbell Fit Size 2	
101. DE Endbell Air Seal Fit 102. Initial Endbell Air Seal Fit Size 103. Finial Endbell Air Seal Fit Size 104. ODE Endbell Fit 105. ODE Initial Endbell Fit Size 1 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 2 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Size 3 112. ODE Endbell Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Selance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End	99	. DE Final Endbell Fit Size 3	
102. Initial Endbell Air Seal Fit Size 103. Finial Endbell Air Seal Fit Size 104. ODE Endbell Fit 105. ODE Initial Endbell Fit Size 1 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 1 109. ODE Final Endbell Fit Size 2 109. ODE Final Endbell Fit Size 3 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Insulated 112. ODE Endbell Seal Fit Size 113. ODE Initial Endbell Seal Fit Size 114. ODE Final Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician 208alance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End	10	0. DE Endbell Fit Insulated	
103. Finial Endbell Air Seal Fit Size 104. ODE Endbell Fit 105. ODE Initial Endbell Fit Size 1 106. ODE Initial Endbell Fit Size 2 107. ODE Initial Endbell Fit Size 3 108. ODE Final Endbell Fit Size 3 109. ODE Final Endbell Fit Size 2 100. ODE Final Endbell Fit Size 3 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Insulated 112. ODE Endbell Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Final Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Service Technician 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End	10	1. DE Endbell Air Seal Fit	
104. ODE Endbell Fit (P) Pass 105. ODE Initial Endbell Fit Size 1 2.4416 " 106. ODE Initial Endbell Fit Size 2 2.4416 " 107. ODE Initial Endbell Fit Size 3 2.4416 " 108. ODE Final Endbell Fit Size 1 2.4416 " 109. ODE Final Endbell Fit Size 2 1 110. ODE Final Endbell Fit Size 3 1 111. ODE Endbell Fit Insulated 1 112. ODE Endbell Air Seal Fit 1 113. ODE Initial Endbell Seal Fit Size 1 114. ODE Final Endbell Seal Fit Size 1 115. Foot Flatness 1 116. Foot Condition 1 117. Flange Condition 1 118. Service Technician 1 8alancing Report 1 119. Balance Type 1 120. Balance Operating Speed 1 121. Start Left End 1 122. Start Right End 1	10	2. Initial Endbell Air Seal Fit Size	
105. ODE Initial Endbell Fit Size 12.4416 "106. ODE Initial Endbell Fit Size 22.4416 "107. ODE Initial Endbell Fit Size 32.4416 "108. ODE Final Endbell Fit Size 12.4416 "109. ODE Final Endbell Fit Size 2	10	3. Finial Endbell Air Seal Fit Size	
106. ODE Initial Endbell Fit Size 2 2.4416 " 107. ODE Initial Endbell Fit Size 3 2.4416 " 108. ODE Final Endbell Fit Size 1 2.4416 " 109. ODE Final Endbell Fit Size 2	10	4. ODE Endbell Fit	(P) Pass
107. ODE Initial Endbell Fit Size 32.4416 "108. ODE Final Endbell Fit Size 1109. ODE Final Endbell Fit Size 2110. ODE Final Endbell Fit Size 3111. ODE Endbell Fit Insulated112. ODE Endbell Air Seal Fit113. ODE Initial Endbell Seal Fit Size114. ODE Final Endbell Seal Fit Size115. Foot Flatness115. Foot Condition117. Flange Condition117. Flange Condition118. Service Technician119. Balance Type119. Balance Operating Speed120. Balance Operating Speed121. Start Left End122. Start Right End122. Start Right End	10	5. ODE Initial Endbell Fit Size 1	2.4416 "
 108. ODE Final Endbell Fit Size 1 109. ODE Final Endbell Fit Size 2 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Insulated 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 	10	6. ODE Initial Endbell Fit Size 2	2.4416 "
 109. ODE Final Endbell Fit Size 2 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Insulated 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 119. Balance Operating Speed 120. Balance Operating Speed 121. Start Left End 122. Start Right End 	10	7. ODE Initial Endbell Fit Size 3	2.4416 "
 109. ODE Final Endbell Fit Size 2 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Insulated 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 119. Balance Operating Speed 120. Balance Operating Speed 121. Start Left End 122. Start Right End 	10	3. ODE Final Endbell Fit Size 1	
 110. ODE Final Endbell Fit Size 3 111. ODE Endbell Fit Insulated 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 111. ODE Endbell Fit Insulated 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician 3alancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 112. ODE Endbell Air Seal Fit 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 113. ODE Initial Endbell Seal Fit Size 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 114. ODE Finial Endbell Seal Fit Size 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balance Type 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 115. Foot Flatness 116. Foot Condition 117. Flange Condition 118. Service Technician Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 116. Foot Condition 117. Flange Condition 118. Service Technician Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
 117. Flange Condition 118. Service Technician Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End 			
118. Service Technician Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End			
Balancing Report 119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End			
119. Balance Type 120. Balance Operating Speed 121. Start Left End 122. Start Right End			
120. Balance Operating Speed 121. Start Left End 122. Start Right End			
121. Start Left End 122. Start Right End			
122. Start Right End			
123. Balancing Specification		-	
	12	3. Balancing Specification	

124	Finish Left End
	Finish Right End Service Technician
	nbly and Final Test
	Meggar Testing Reading
	Surge Test
	Hi-Pot
	Winding Resistance 1-2
	Winding Resistance 2-3
	Winding Resistance 1-3
	Test Run Voltage Phase A
	Test Run Amps A
	Test Run Voltage Phase B
	Test Run Amps B
	Test Run Voltage Phase C
	Test Run Amps C
139.	DE Horizontal Vibration Reading
140.	DE Vertical Vibration Reading
141.	DE Axial Vibration Reading
142.	ODE Horizontal Vibration Reading
143.	ODE Vertical Vibration Reading
144.	ODE Axial Vibration Reading
145.	Ambient Temp at start of Test Run
146.	Temp at 5 minutes
147.	Temp at 10 minutes
148.	Temp at 15 minutes
149.	Temp at 20 minutes
150.	Temp at 25 minutes
151.	Temp at 30 minutes
152.	Temp at 35 minutes
153.	Temp at 40 minutes
154.	Temp at 45 minutes
155.	Temp at 50 minutes
156.	Temp at 55 minutes
157.	Temp at 60 minutes
158.	Motor Paint
159.	Service Technician



STANDARD TERMS AND CONDITIONS FOR PURCHASE OF GOOD AND/OR SERVICES

- 1. <u>APPLICABILITY.</u> The sale of any and all goods and/or services by Mock, Inc. d/b/a Hi-Speed Industrial Service ("Hi-Speed") shall be specifically conditioned upon and subject to the following terms and conditions which are incorporated by reference into any contracts and purchase orders with Hi-Speed, and which shall form and become a part of any agreement related thereto. Buyer's acceptance of any offer or quotation made by Hi-Speed for sale of any goods or services is expressly made subject to the terms and conditions set forth herein and to be so effective, Buyer need not sign or approve these Terms and Conditions to be bound hereunder provided a copy of same is provided to Buyer through any means. None of the terms and conditions contained herein may be added to, expanded, changed, modified, superseded or otherwise altered except as revised in writing and duly executed by Hi-Speed, and all orders received by Hi-Speed shall be governed only by the terms and conditions contained herein, notwithstanding any terms, conditions or provisions of any purchase order, release order, authorization or any other form issued by the Buyer. Hi-Speed hereby objects to any additional, modified, changed, deleted, altered or other terms and conditions not contained herein and notifies Buyer that any such terms or provisions are expressly rejected by Hi-Speed.
- 2. PRICE. All quoted prices shall remain firm and binding for a period of thirty (30) days from the date of quotation or for the period specifically stated in the quotation. The price for any and all goods and/or services ordered or approved by Buyer after thirty (30) days from the date of any quotation are subject to any increase in price that may occur after the expiration of thirty (30) days from the issuance of the quotation and the date the Buyer releases any shipment.
- 3. <u>SCOPE OF GOODS AND/OR SERVICES.</u> The goods and/or services provided by Hi-Speed pursuant to any quotation shall be limited exclusively to those goods and/or services expressly identified therein. Hi-Speed does not assume any responsibility and/or liability for the failure to provide any other goods and/or services not identified in any quotation. Modifications, additions or deletions to or from the scope referenced in any quotation shall only be effective if evidenced in writing and signed by Hi-Speed. The sale of any of all goods and/or services affected by such modification, addition or deletion shall be subject to these same Standard Terms and Conditions whether or not referenced therein.
- 4. <u>BILLING AND PAYMENT TERMS.</u> Hi-Speed shall invoice Buyer for all goods and/or services as same are rendered at the address listed on the quotation. Payments for all goods and/or services shall be due thirty (30) days from the date of the current invoice or as otherwise set forth in the quotation. Late payments are subject to a late fee of 5% of the total invoice amount. Recurring late payments may lead to a deposit requirement on future services or sale of goods. Buyer shall be liable to Hi-Speed for any and all fees and expenses incurred by Hi-Speed to collect any invoices or to enforce these Standard Terms and Conditions, including but not limited to, attorney's fees.
- 5. DELIVERY OF GOODS AND/OR SERVICES. Unless otherwise identified in the quotation, all shipments are F.O.B. Hi-Speed's warehouse and the title to and all risk of loss with respect to any goods shipped shall pass to Buyer when such goods are delivered to the carrier at Hi-Speed's warehouse. Hi-Speed will use its best efforts to affect delivery by the date or dates specified in the quotation. However, Hi-Speed shall not be liable for delay in or failure to make shipment, or to perform services, by any identified date for any reason whatsoever, including but not limited to, causes beyond its reasonable control, such as strikes, fires, floods, epidemics, quarantines, restrictions, severe weather, embargos, acts of God, or public enemy, war, riot, delays in transportation or the inability to obtain necessary labor, materials or manufacturing facilities.
- 6. DELIVERY SITE AND TIME FOR PERFORMANCE. Hi-Speed and Buver agree that time is of the essence for the purchase order and that Buyer shall fully cooperate with Hi-Speed in order to allow Hi-Speed full access to prosecute its work diligently and in an orderly manner. Buyer shall assist Hi-Speed in every way possible to avoid delaying, disrupting or interfering with the progress of Hi-Speed's work at the project site. In the event Hi-Speed's work is delayed, hindered, suspended, disrupted, re-sequenced or interfered with or rendered less efficient or more costly or adversely affected in any way as a result of acts or omissions of Buyer or other contractors or employees of Buyer or by any other reason beyond Hi-Speed's control and without the fault of Hi-Speed, then, in such event, Buyer shall be liable to Hi-Speed for any damages, additional costs, expenses, labor, materials, man hours, acceleration costs, overtime, additional jobsite overhead, extended home office overhead, and any and all other direct and indirect expenses of whatsoever nature or kind, caused in whole or in part, as a result of any of the above-referenced occurrences. Hi-Speed's project records will be the basis for computing the additional costs and damages of Hi-Speed's labor, materials, expenses and overhead related to such changes. BUYER WARRANTS THAT THE SITE FOR DELIVERY OR INSTALLATION OF ANY GOODS AND/OR FOR THE PERFORMANCE OF ANY SERVICES SHALL BE READY AND ADEQUATE FOR HI-SPEED'S DELIVERY OF GOODS AND/OR PERFORMANCE OF SERVICES AND THAT HI-SPEED SHALL HAVE FULL ACCESS THERETO, FREE OF ALL OBSTRUCTIONS. BUYER SHALL ASSUME ALL EXTRA COSTS ASSOCIATED WITH HI-SPEED'S INABILITY TO INSTALL ANY GOODS OR PERFORM ANY SERVICES AS A RESULT OF BUYER'S FAILURE TO COMPLY WITH THIS PROVISION. HI-SPEED MAY NOT INSPECT THE SITE PRIOR TO DELIVERY AND/OR INSTALLATION OF GOODS AND/OR PERFORMANCE OF SERVICES AND MAKES NO WARRANTY AS TO THE SUFFICIENCY OF THE SITE FOR THE DELIVERY AND/OR INSTALLATION OF GOODS AND/OR THE PERFORMANCE OF SERVICES AT SUCH SITE.
- 7. INSPECTION/ACCEPTANCE. All goods and services ordered pursuant to any quotation shall be subject to inspection by Buyer after delivery or performance to determine conformity with the quotation and/or purchase order and Hi-Speed's advertised or published specifications. Buyer shall have a period of thirty (30) days from shipment of goods at the delivery destination specified in the quotation within which to inspect the goods for conformity with the quotation, order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. Buyer shall have a period of thirty (30) days following completion of any services within which to inspect the services for conformity with the quotation, purchase order and/or Hi-Speed's advertised and published specifications and to provide Hi-Speed with written notice of any discrepancy or rejection. If the goods delivered or services performed do not so conform, upon delivery of notice to Hi-Speed of any discrepancy, nonconformance or rejection, Hi-Speed shall have the right to reject such goods or services. After the cure period, goods that have been delivered and rejected, in whole or in part, shall be returned to Hi-Speed. Buyer shall notify Hi-Speed and arrange for the return of the goods as required. Should such non-conforming services be rejected Hi-Speed shall, at its sole cost, re-perform the non-conforming services. Inspection or failure to inspect on any occasion shall not affect Buyer's rights under the warranty provisions herein.
- 8. WARRANTIES. Hi-Speed warrants that all goods shall conform in all material aspects to the goods identified in the quotation to Buyer and/or purchase order, and Hi-Speed makes to Buyer the manufacturer's express warranty for any goods sold to Buyer, which is offered by the manufacturer at the time of acceptance of any quotation by Buyer. This warranty is conditioned upon the installation, operation, and maintenance of the goods in accordance with the manufacturer's recommendations and/or standard industry practice and the goods at all times being operated or used under normal operating conditions for which they were designed. Hi-Speed, at its sole option, will repair or

replace any defective or non-conforming goods in accordance with the applicable manufacturer's warranty. Warranty for any defective or incorrect parts is limited to the repair or replacement of those parts. Hi-Speed warrants that all services will conform in all material respects to the description of services identified in the quotation and will be performed in a good and workmanlike manner in accordance with industry practices and standards. Should the services be reasonably rejected or not conform with the foregoing warranties, Hi-Speed shall, at its sole cost, re-perform the defective or nonconforming services. Notwithstanding the foregoing, these warranties do not extend to goods or services to the extent that such goods have been subject to misuse, neglect or abuse not caused by Hi-Speed or have been used in violation of the approved written instructions furnished to Buyer. THE FOREGOING REPRESENTS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY HI-SPEED WITH RESPECT TO ALL GOODS SOLD AND IS IN LIEU OF ALL OTHER WARRANTIES EITHER EXPRESS OR IMPLIED. HI-SPEED EXPRESSLY DISCLAIMS ALL OTHER WARRANTIES INCLUDING MERCHANTABILITY AND FITNESS FOR A PARTICLAR USE OR PURPOSE. BUYER WAIVES ANY CLAIM THAT THESE EXCLUSIONS OR LIMITATIONS DEPRIVE IT OF AN ADEQUATE REMEDY AT EQUITY OR LAW OR CAUSE THIS AGREEMENT TO FAIL IN ITS ESSENTIAL PURPOSE. BUYER SHALL BE ENTITLED TO NO OTHER REMEDY OTHER THAN AS SET FORTH HEREIN, REGARDLESS OF THE CLAIM OR CAUSE OF ACTION, WHETHER BASED IN CONTRACT, TORT, NEGLIGENCE, GOODS LIABILITY, STRICT LIABILITY OR OTHERWISE.

- 9. LIMITATION OF DAMAGES. HI-SPEED SHALL HAVE NO LIABILITY TO BUYER WITH RESPECT TO THE SALE OR DELIVERY OF ANY GOODS OR THE REPAIR THEREOF OR WITH RESPECT TO THE SALE OR PERFORMANCE OF ANY SERVICES, FOR LOST PROFITS, SPECIAL, CONSEQUENTIAL, EXEMPLARY, PUNITIVE OR INCIDENTAL DAMAGES OF ANY KIND OR NATURE WHETHER ARISING IN CONTRACT, TORT, GOODS LIABILITY OR OTHERWISE, EVEN IF HI-SPEED WAS ADVISED OF THE POSSIBILITY OF SUCH LOSS OR DAMAGES. HI-SPEED SHALL NOT BE LIABLE FOR ANY DAMAGES OR DELAYS CAUSED BY ANY FAILURE TO MAKE ANY DELIVERY OF GOODS BY ANY EXPECTED TIME OR DATE OR THE FAILURE TO PROVIDE OR COMPLETE ANY SERVICES BY ANY EXPECTED DATE OR TIME. IN NO EVENT SHALL HI-SPEED BE LIABLE TO BUYER FOR ANY DAMAGES WHATSOEVER IN EXCESS OF THE TOTAL PRICE PAID FOR ALL GOODS AND/OR SERVICES HEREUNDER OR REFERENCED IN ANY QUOTATION OR THE PURCHASE ORDER.
- 10. <u>SEVERABILITY</u>. The partial or complete invalidity of any provision of these Standard Terms and Conditions shall not affect the enforceability of the remainder of these Standard Terms and Conditions. If any provision is found to be invalid or unenforceable, that portion shall be modified to make it enforceable or shall be stricken and the remainder of these Standard Terms and Conditions shall enforced.
- 11. <u>GOVERNING LAW AND JURISDICTION.</u> Any controversy arising out of any quotation, the purchase order, the goods sold or delivered, repair or replacement thereof, or any services provided pursuant to any quotation or any purchase order, or these Standard Terms and Conditions shall be governed by the laws of the state of Tennessee without regard to any choice of law provisions and any cause of action related in any manner thereto shall be brought only in the state or federal courts of Shelby County, Tennessee.
- 12. <u>ABANDONED EQUIPMENT.</u> Hi-Speed requires that Buyer promptly pick up or provide shipment instructions for Buyer equipment or other Buyer property in Hi-Speed's possession. If equipment or other Buyer property is left with Hi-Speed and not picked up within six (6) months after Hi-Speed's final action related to the applicable property (e.g. evaluation, teardown, estimate, completion of services), Hi-Speed will consider such property abandoned and may dispose of it in accordance with applicable law. Buyer agrees to hold Hi-Speed harmless for any damage or claim for such abandoned property and acknowledges that Hi-Speed may discard or recycle it at Hi-Speed's sole and absolute discretion. Specifically, Hi-Speed may sell Buyer's abandoned property at a private or public sale and retain the proceeds to offset Hi-Speed's storage, inspection and servicing costs. For the avoidance of doubt, Hi-Speed reserves its statutory and other lawful liens for unpaid charges related to abandoned property.
- 13. FORCE MAJEURE. Neither party shall be responsible for any delay or failure in performance of any party of the quotation, purchase order or these Standard Terms and Conditions to the extent that such delays or failures are caused by fire, flood, earth quake, explosion, war, embargo, government requirement, civil or military authority, acts of God, or any other circumstances beyond its reasonable control and not involving any fault or negligence on the party affected ("Condition"). If any such Condition occurs, the party delayed or unable to perform shall promptly give written notice to the other party and, if such Condition remains at the end of thirty (30) days, the party affected by the other party's delay and inability to perform may elect to (i) terminate such order or part thereof, or (ii) suspend the order for the duration of the Condition, if the Buyer is the suspending party, buy elsewhere comparable material to be sold under the order and apply to any commitment the purchase price of such purchase, and resume performance of the order once the Condition ceases, with an option in the affected party to extend the period of this order up to the length of the time the Condition endures.
- 14. <u>NONWAIVER</u>. No course of dealing or failure of either party to strictly enforce any term, right, or condition of these Standard Terms and Conditions will be construed as a waiver of such term, right or condition. Any waiver by Hi-Speed will only be in writing and will waive no succeeding breach of a term, right or condition.
- 15. <u>ASSIGNMENT.</u> The rights and obligations of the parties shall neither be assigned nor delegated without the prior written consent of the other party. However, any party may assign or delegate its respective rights and obligations, in whole or in part, (i) to any subsidiary, (ii) pursuant to other financing, merger or reorganization or (iii) pursuant to any sale or transfer of substantially all of the assets of the assigning party. These Standard Terms and Conditions shall bind the heirs, successors and assigns of the parties hereto.
- 16. <u>NO INDIVIDUAL LIABILITY</u>. Notwithstanding any other agreement to the contrary, the Buyer agrees that in no event will the Buyer hold and HI-Speed owner, director, officer or employee personally liable for unintentional tortious conduct or conduct that constitutes the breach of any contract between HI-Speed and the Buyer, even if the HI-Speed owner, director, officer or employee is or could be construed to be a party to such contract.