



AC Recondition Repair Report

FolderID: 97551
FormID: 9377546

ENVIRONMENTAL PROCESS SYSTEM

30 WINDWOOD LOOP
CONWAY, AR 72034

General

- | | |
|----------------|--------------------------------|
| 1. Job Number | 97551 |
| 2. Report Date | |
| 3. Customer | ENVIROMENTAL PROCESS
SYSTEM |

Name Plate Information

- | | |
|--------------------------|-----------------|
| 4. Manufacturer | DODGE |
| 5. Model | PART# 247160 ED |
| 6. Serial Number | |
| 7. Horsepower | |
| 8. KW | |
| 9. Volts | |
| 10. Amps | |
| 11. RPM | |
| 12. Frame | |
| 13. Enclosure | |
| 14. Cycles | |
| 15. Phase | |
| 16. Service Factor | |
| 17. Motor Mount Position | |

Initial Inspection

- | |
|------------------------------------|
| 18. Number of Leads |
| 19. Lead Length |
| 20. Lead Size |
| 21. Lead Condition |
| 22. Lead Markings |
| 23. Lug Size, Condition, and Type |
| 24. Winding RTD's |
| 25. Winding Rtd's Condition |
| 26. Shaft Run Out |
| 27. Does Shaft Turn Freely |
| 28. Does Shaft Have Visible Damage |
| 29. Bearing Rtd's |
| 30. Bearing Rtd's Condition |
| 31. Contamination |
| 32. Frame Condition |
| 33. Fan Condition |

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

34. Broken or missing components
Initial Electric Test
35. Resistance to Ground
36. Winding Resistance 1-2
37. Winding Resistance 2-3
38. Winding Resistance 1-3
39. Resistive Imbalance
40. Hi-Pot
41. Surge Test
42. Stator Condition
43. Failure Location
Initial Rotor Inspection
44. Rotor Type
45. Air Gap <10% Variation
46. Number of Rotor Bars
47. Number of Broken Rotor Bars
48. Growler Test
49. Rotor Condition
Mechanical Inspection
50. Bearing Manufacture
51. Bearing DE Size
52. Bearing DE Type
53. DE Bearing Qty.
54. Bearing ODE Size
55. Bearing ODE Type
56. ODE Bearing Qty.
57. Insulated Bearing
58. Lubrication Type
59. Grease Condition
60. Bearing Retainers
61. Shaft Grounding Device
62. DE Seal
63. DE Seal Type/Size
64. ODE Seal
65. ODE Seal Type/Size
Root Cause of Failure
66. Component Failure
67. Cause of Failure
68. Comments
69. Service Technician
Machine Fit Inspection Report
70. Shaft Run Out
71. Initial Shaft Run Out
72. Final Shaft Run Out
73. DE Bearing Shaft Fit
74. DE Initial Shaft Bearing Fit Size 1
75. DE Initial Shaft Bearing Fit Size 2
76. DE Initial Shaft Bearing Fit Size 3

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

77.	DE Finial Shaft Bearing Fit Size 1
78.	DE Finial Shaft Bearing Fit Size 2
79.	DE Finial Shaft Bearing Fit Size 3
80.	ODE Bearing Shaft Fit
81.	ODE Initial Shaft Bearing Fit Size 1
82.	ODE Initial Shaft Bearing Fit Size 2
83.	ODE Initial Shaft Bearing Fit Size 3
84.	ODE Finial Shaft Bearing Fit Size 1
85.	ODE Finial Shaft Bearing Fit Size 2
86.	ODE Finial Shaft Bearing Fit Size 3
87.	DE Air Seal Shaft Fit
88.	DE Initial Air Seal Shaft Size
89.	DE Final Air Seal Shaft Size
90.	ODE Air Seal Shaft Fit
91.	ODE Initial Air Seal Shaft Size
92.	ODE Final Air Seal Shaft Size
93.	DE Endbell Fit
94.	DE Initial Endbell Fit Size 1
95.	DE Initial Endbell Fit Size 2
96.	DE Initial Endbell Fit Size 3
97.	DE Final Endbell Fit Size 1
98.	DE Finial Endbell Fit Size 2
99.	DE Final Endbell Fit Size 3
100.	DE Endbell Fit Insulated
101.	DE Endbell Air Seal Fit
102.	Initial Endbell Air Seal Fit Size
103.	Finial Endbell Air Seal Fit Size
104.	ODE Endbell Fit
105.	ODE Initial Endbell Fit Size 1
106.	ODE Initial Endbell Fit Size 2
107.	ODE Initial Endbell Fit Size 3
108.	ODE Final Endbell Fit Size 1
109.	ODE Final Endbell Fit Size 2
110.	ODE Final Endbell Fit Size 3
111.	ODE Endbell Fit Insulated
112.	ODE Endbell Air Seal Fit
113.	ODE Initial Endbell Seal Fit Size
114.	ODE Finial Endbell Seal Fit Size
115.	Foot Flatness
116.	Foot Condition
117.	Flange Condition
118.	Service Technician
Balancing Report	
119.	Balance Type
120.	Balance Operating Speed
121.	Start Left End
122.	Start Right End
123.	Balancing Specification

Hi-Speed Industrial Service disclaims all warranties, both express and implied, relating to the information, reports, opinions and analysis disclosed to the Customer by Hi-Speed. Hi-Speed shall not be liable for any errors or omissions, or any losses, injury or damages arising from the use of such information, reports, opinions and analysis by the Customer.

124.	Finish Left End
125.	Finish Right End
126.	Service Technician
Assembly and Final Test	
127.	Meggar Testing Reading
128.	Surge Test
129.	Hi-Pot
130.	Winding Resistance 1-2
131.	Winding Resistance 2-3
132.	Winding Resistance 1-3
133.	Test Run Voltage Phase A
134.	Test Run Amps A
135.	Test Run Voltage Phase B
136.	Test Run Amps B
137.	Test Run Voltage Phase C
138.	Test Run Amps C
139.	DE Horizontal Vibration Reading
140.	DE Vertical Vibration Reading
141.	DE Axial Vibration Reading
142.	ODE Horizontal Vibration Reading
143.	ODE Vertical Vibration Reading
144.	ODE Axial Vibration Reading
145.	Ambient Temp at start of Test Run
146.	Temp at 5 minutes
147.	Temp at 10 minutes
148.	Temp at 15 minutes
149.	Temp at 20 minutes
150.	Temp at 25 minutes
151.	Temp at 30 minutes
152.	Temp at 35 minutes
153.	Temp at 40 minutes
154.	Temp at 45 minutes
155.	Temp at 50 minutes
156.	Temp at 55 minutes
157.	Temp at 60 minutes
158.	Motor Paint
159.	Service Technician